Content A-Z



# OWNER'S HANDBOOK. BMW 2 SERIES COUPÉ.





# WELCOME TO BMW.

## Owner's Handbook.

Congratulations on your choice of a BMW.

The better you are acquainted with your vehicle, the easier you will find it is to operate in traffic. We therefore request:

Please read the Owner's Handbook before setting out in your new BMW. Also use the Integrated Owner's Handbook in your vehicle. It contains important information on how to operate your vehicle, helping you get the most out of your BMW's technical features. It also contains information to help keep your BMW operating safely on the road and maintain its full resale value.

When the vehicle leaves the factory, the printed Owner's Handbook is the most up-to-date version. After a vehicle software update – for example, a Remote Software Upgrade – the Integrated Owner's Handbook for the vehicle will contain updated information.

Supplementary information is provided in further on-board literature.

We wish you a safe and pleasant journey.

# TABLE OF CONTENTS

NOTES

After a vehicle software update – for example, a Remote Software Upgrade – the Integrated Owner's Handbook for the vehicle will contain updated information.

110125
Notes 6
★ QUICK REFERENCE
Getting in22
Adjustment and operation
On the move
<b>↓</b> CONTROLS
Vehicle cockpit
Sensors in the vehicle
Vehicle operating condition46
BMW iDrive
BMW Remote Software Upgrade
Personal settings
Opening and closing
Seats, mirrors and steering wheel
Carrying children safely 113
Driving
Displays
Lights
Safety
Driving stability control systems
Driver assistance systems
Parking
Driving comfort
Air conditioning
Interior equipment249
Storage compartments
Luggage compartment

## DRIVING HINTS

Driving precautions	262
Trailer operation	269
Saving fuel	277
MOBILITY	
Refuelling	284
Wheels and tyres	
Engine compartment	311
Operating fluids	314
Maintenance	
Replacing parts	328
Help in case of a breakdown	333
Care	
Q REFERENCE	
Technical data	
Seats for child restraint systems	354
Appendix	356
Everything from $\Delta$ to $7$	

© 2022 Bayerische Motoren Werke

Aktiengesellschaft

Munich, Germany

Not to be reproduced, wholly or in part, without written permission from BMW AG, Munich. English ID8  $\,$  VI/22, -

Printed on environmentally friendly paper, bleached without chlorine, suitable for recycling.

## Notes

# About this Owner's Handbook

#### Orientation

The quickest way to find information on a particular topic or feature is to consult the alphabetical index.

For an overview of the vehicle, we recommend the quick reference in the Owner's Handbook.

## Validity of Owner's Handbook

#### Vehicle production

When the vehicle leaves the factory, the contents of the printed Owner's Handbook are up to date. Any updates introduced after the copy deadline may result in discrepancies between the printed Owner's Handbook and the Integrated Owner's Handbook in the vehicle.

Notes on updates can be found in the appendix of the printed Owner's Handbook for the

#### After a software update in the vehicle

After a vehicle software update, for example, via Remote Software Upgrade, the Integrated Owner's Handbook for the vehicle will contain the latest information.

# Owner's Handbook for Navigation, Entertainment, Communication

The Owner's Handbook for Navigation, Entertainment, Communication is available as a printed book from Service.

These topics are also covered in the Integrated Owner's Handbook in the vehicle.

## Media overview

#### General

Content from the Owner's Handbook can be accessed through various media. The Owner's Handbook is available in the following media:

- ▶ Printed Owner's Handbook.
- Integrated Owner's Handbook in the vehicle.

#### Printed Owner's Handbook

The printed Owner's Handbook shows all standard equipment, national-market equipment and optional equipment which is offered or will be offered on a model-specific basis.

# Integrated Owner's Handbook in the vehicle

#### Principle

The Integrated Owner's Handbook shows all standard equipment, national-market equipment and optional equipment which is offered or will be offered on a model-specific basis. The Integrated Owner's Handbook can be shown on the control display.

## Selecting the Owner's Handbook

- 1. "MENU"
- 2. "All apps"
- 3. "Owner's Handbook"
- 4. Select the required method of accessing the contents.

## Scrolling within the Owner's Handbook

Swipe up or down until the next or previous contents are displayed.

#### Context-sensitive help

#### General

The Integrated Owner's Handbook can be accessed from any menu. Depending on the selected function, the associated description or the main menu of the Integrated Owner's Handbook is displayed.

#### Selecting context-sensitive help from a menu

- 1. Press and hold the desired menu item.
- 2. "General help"

# Selecting context-sensitive help from a Check Control message

To switch directly from the Check Control message on the control display:

"Owner's Handbook"

## Supplementary Owner's Handbooks

Please also pay attention to the Supplementary Owner's Handbooks which are provided along with the on-board literature as required.

# Additional sources of information

## Service Partner

A Service Partner of the manufacturer will be happy to answer any further questions.

#### Internet

Vehicle information and general information on BMW – on technology, for example – are available on the Internet: www.bmw.com.

## BMW Driver's Guide App

The BMW Driver's Guide App shows all standard equipment, national-market equipment and optional equipment which is offered or will

be offered on a model-specific basis. The app can be displayed on smartphones and tablets.

### BMW Driver's Guide web version

BMW Driver's Guide Web shows all standard, national-market and optional equipment which is offered or will be offered on a model-specific basis. BMW Driver's Guide Web can be displayed on any current browser.

## Icons and displays

#### Icons in the Owner's Handbook

#### Icon Meaning

- Precautions that must be followed in order to avoid the possibility of injury to yourself and to others as well as serious damage to the vehicle.
- Measures that can be taken to help protect the environment.
- "..." Texts on a display in the vehicle for selecting functions.
- >...< Commands for the voice control system.
- >>...< Replies by the voice control system.

## **Actions**

Actions that need to be carried out are shown as a numbered list. The list of steps must be carried out in the specified sequence.

- 1. First action.
- 2. Second action.

#### Lists

Alternative options and lists of items with no implied sequence are shown as bullet point lists:

- First option.
- Second option.

#### Icon on components and assemblies

**This symbol on a vehicle component** indicates that further information on the component is available in the Owner's Handbook.

## Vehicle equipment

This Owner's Handbook shows all models and all standard equipment, national-market equipment and optional equipment which is offered or will be offered on a model-specific basis, i.e. in the model range. As a result, this Owner's Handbook may also contain descriptions and illustrations of equipment, systems and functions which are not installed in the vehicle in question, for example due to:

- Selected optional equipment.
- National-market version or national-market equipment.
- Possibility of subsequent enabling and software updates.

This also applies to safety-relevant functions and systems.

Before starting a journey, check whether a piece of equipment or a function that is described is available in the vehicle. Information about whether a function is currently available in the vehicle or whether and when the function can be installed in the vehicle can be obtained from a Service Partner of the manufacturer or another aualified Service Partner.

If a piece of equipment, system or function is described in the Owner's Handbook, this does not mean that it will be available in the vehicle.

Please comply with the relevant laws and reaulations when using the corresponding functions and systems.

If certain equipment and models are not described in this Owner's Handbook, refer to the Supplementary Owner's Handbooks provided.

In right-hand drive vehicles, some operating elements are arranged differently from those shown in this Owner's Handbook.

## Production date

The production date of your vehicle can be found at the bottom of the body pillar on the driver's door.

The production date is defined as the calendar month and the calendar year in which the vehicle body and the transmission assemblies are ioined and the vehicle is driven or moved from the production line.

## Status of the Owner's Handbook

#### General

The high standards of safety and quality that characterise the vehicles are ensured through ongoing development. On rare occasions, this may mean that the features described in this handbook will vary from those in your vehicle.

#### For Australia/New Zealand: general

When reading this Owner's Handbook, please bear the following in mind: to ensure that our vehicles continue to embody the highest quality and safety standards, we pursue a policy of continuous, ongoing development. Because modifications in the design of both vehicles and accessories may be introduced at any time, your own vehicle's equipment may vary from that described in this manual. For the same reason, it is also impossible to quarantee that all descriptions will be completely accurate in all respects.

We must therefore request your understanding of the fact that the manufacturer of your vehicle is unable to recognise legal claims based on discrepancies between the data, illustrations and descriptions in this Owner's Handbook and your own vehicle's equipment. Please note, too, that some of the optional equipment described in this Owner's Handbook is not available on Australian models due to restrictions imposed by Australian Design Rules and other requirements.

Should you require any further information, please contact your Service Partner or a qualified specialist workshop, who will be pleased to advise you.

#### Validity of Owner's Handbook

#### Vehicle production

When the vehicle leaves the factory, the contents of the printed Owner's Handbook are up to date. Any updates introduced after the copy deadline may result in discrepancies between the printed Owner's Handbook and the Integrated Owner's Handbook in the vehicle.

Notes on updates can be found in the appendix of the printed Owner's Handbook for the vehicle.

#### After a software update in the vehicle

After a vehicle software update, for example, via Remote Software Upgrade, the Integrated Owner's Handbook for the vehicle will contain the latest information.

## Your own safety

#### Intended use

Please comply with the following when using the vehicle:

- Owner's Handbook.
- Information attached to the vehicle. Do not remove stickers.
- > Technical data of the vehicle.
- ➤ The applicable laws and safety standards of the country in which the vehicle is used.
- Vehicle papers and legal documents.

#### Warranty

The vehicle is technically designed for the operating conditions and approval (homologation) requirements of the country to which it was first delivered. If the vehicle is to be driven in another country, it may need to first be adapted to any different operating conditions and approval requirements prevailing in that country. If the vehicle does not comply with the homologation requirements in a certain country, no warranty claims can be lodged there for the vehicle. Warranty claims may also be invalidated if the electrical system has been modified, for example through the use of control units, hardware, or software which the vehicle manufacturer classifies as unsuitable. A Service Partner is able to provide further information.

Note: in addition to the warranty required by law, the selling Authorised BMW Retailers or the selling BMW AG subsidiaries in Germany grant additional benefits with the purchase of new BMW vehicles within the framework of the BMW Warranty Booklet. More information: www.bmw.de/qualitaetsbrief.

## Maintenance and repairs

The advanced technology used in your vehicle, for example the state-of-the-art materials and high-performance electronics, requires appropriate maintenance and repair methods.

Consequently, the manufacturer of the vehicle recommends having relevant work carried out by a BMW Service Partner. If you choose to use a different specialist workshop, BMW recommends using one that performs the corre-

sponding work, such as maintenance and repair, in accordance with BMW specifications and that employs properly trained personnel. In the Owner's Handbook, facilities of this kind are referred to as "another qualified Service Partner or a specialist workshop".

If work such as maintenance and repair is carried out incorrectly, it could result in subsequent damage with associated safety risks.

Incorrectly performed work on the vehicle paintwork can cause components, for example the radar sensors, to fail or malfunction, resulting in a safety hazard.

#### Parts and accessories

BMW recommends using parts and accessories that are approved by BMW and are therefore suitable for this purpose.

You are recommended to consult a BMW Service Partner for advice on genuine BMW parts and accessories, other BMW approved products and expert advice on all related matters.

The safety and compatibility of these products in conjunction with BMW vehicles have been checked by BMW.

BMW accepts product responsibility for genuine BMW parts and accessories. However, BMW cannot accept liability for parts or accessory products of any kind which it has not approved.

BMW is unable to assess each third-party product of outside origin as to its suitability for use on BMW vehicles without safety risk. Likewise no guarantee can be assumed even if the product has been granted official approval in a specific country. Tests performed for such approvals cannot always cover all operating conditions for BMW vehicles, and some of them therefore are insufficient.

# Vehicle data and data protection

## Responsibility and rights

#### Responsibility for data

Within the scope of data protection directives and legislation, the manufacturer of the vehicle is responsible for processing personal data which is collected when the vehicle is used or from web pages, customer support, online services, and marketing campaigns.

#### Personal identification

Every vehicle has a unique vehicle identification number. Depending on the country, and with the assistance of the relevant authorities, the registered keeper can be identified from the vehicle identification number and the number plate. There are also other ways of tracing data collected in the vehicle back to the driver or registered keeper, for example via the Connected Drive account used.

#### Data protection laws

In accordance with current data protection law, vehicle users have certain rights vis-à-vis the vehicle manufacturer or companies that collect or process their personal data.

Vehicle users have a free and comprehensive right of access to their personal data which has been collected and held by organisations.

Such organisations could be:

- Vehicle manufacturer.
- Ouglified Service Partners.
- Specialist workshops.
- Service providers.

Vehicle users may request information about what personal data has been saved, what it is used for and where it has come from. Proof of ownership or use is required in order to obtain this information.

The right of access also extends to information about data that has been transferred to other companies or bodies.

Please refer to the vehicle manufacturer's website for the applicable data protection policy. This data protection policy contains information about the right to have data deleted or corrected. The vehicle manufacturer's website also provides its contact details and those of its data protection officer.

The registered keeper can have the data stored in the vehicle read out by a Service Partner of the manufacturer, or another qualified Service Partner, or a specialist workshop, for a fee, as necessary.

Vehicle data is read out by the socket for onboard diagnosis, which is required by law.

## Data processing

The collection of personal data may be necessary to enable the manufacturer of the vehicle to fulfil obligations to the customer or to legislators, or to offer high-quality products and services.

These include, for example:

- ➤ To fulfill contractual obligations regarding the sale, servicing and repair of vehicles, for example sales processes, maintenance.
- ➤ To fulfill contractual obligations regarding the provision of digital vehicle services, for example BMW ConnectedDrive.
- ➤ To safeguard product quality and the research and development of new products, and to optimise service processes.
- ➤ To perform sales, service and administration processes, including branches and National Sales Companies.
- ➤ To provide customer support, for example contract processing.
- To conduct advertising communication and market research on the basis of personal consent.

- To fulfill legal obligations, for example information regarding Technical Campaigns.
- ▶ To process warranty claims.

#### Data collection

#### Type of data collected

Depending on the situation, the following personal data may be collected.

#### Contact details

- Name, address, telephone number.
- ▶ Email address.

#### Personal data

- Personal information provided by customers, for example date of birth, education, household size or occupation.
- Data to determine identity, for example driver's licence.

#### Contract data

- Customer number, contract number, booked online services.
- ▶ Stored payment information, for example credit card number.

#### Credit rating

- ▶ Information about transactions.
- Information about fraud or criminal offences.

#### Interests

Information provided by the customer regarding areas of interest, for example product preferences, hobbies, and other personal preferences.

#### Use of web pages and communication

- Information on how web pages are used and whether messages are opened or forworded.
- Account information regarding online services, customer portals, and prospective customer portals.

#### Transaction and interaction data

Information on the purchasing of products and services, interactions with customer support and participation in market research studies.

# Use of apps and services of the vehicle manufacturer

Information on the use of apps on mobile devices and online services.

#### Information on vehicle functions and settings

Information on functions and settings in the vehicle, for example when using online services.

#### Vehicle-related sensor data and usage data

Data generated or processed in the vehicle.

- Driver assistance systems: processing of sensor data which is used to evaluate the vehicle's surroundings or the driver's behaviour.
- ▶ Personal settings: settings saved in the vehicle profile, for example seat setting.
- Multimedia, navigation, for example destinations.

#### Time of data collection

Personal data may be collected at the following times:

- When the customer makes direct contact with the manufacturer of the vehicle, for example via the web page.
- When requesting information on products and services or direct purchases, for example on web pages or in apps.

- When making direct purchases, for example on the web page.
- When purchasing services directly, for example online services.
- When the customer responds to direct marketing activities, for example when personal data is provided.
- When using vehicles, products, services and digital offers, for example web pages, apps.
- When communicating personal data through qualified partners of the vehicle manufacturer or through third-party providers, provided that data protection requirements are met.
- When providing personal data through certified address providers, provided that data protection requirements are met.
- When vehicle data, including the vehicle identification number, is read out during service, maintenance and repair activities.

## Data in the vehicle

#### General

A number of electronic control devices are installed in your vehicle. Electronic control units process data that they receive from vehicle sensors, generate themselves, or exchange with one another, for example. Many of the control units are necessary for safe operation of the vehicle, or provide assistance while driving, for example driver assistance systems. There are also control devices which manage comfort or infotainment functions.

Data saved in the vehicle can be deleted at any time. This data is only transmitted to third parties if expressly requested in the course of using online services. The transfer depends on the settings selected for using the services.

#### Sensor data

Driver assistance systems, for example Active Cruise Control, Collision Warning, or Attentive-

ness Assistant, process sensor data which is used to evaluate the vehicle's surroundings or the driver's behaviour.

These include, for example:

- Status messages relating to the vehicle and its individual components, for example wheel speed, wheel circumferential velocity, deceleration, lateral acceleration, fastened seat belts.
- ▶ Ambient conditions, for example temperature, rain sensor signals.

The data is processed within the vehicle and is usually transient. It is only saved for longer than the operating period if it is required in order to provide services agreed with the customer.

#### Electronic components

Electronic components, for example control devices and vehicle keys, contain components for storing technical information. Information about the vehicle condition, component use and wear, maintenance requirements, events or faults can be stored temporarily or permanently.

This information generally documents the condition of a component, a module, a system or the vehicle's surroundings, including:

- Operating states of system components, for example fill levels, tyre inflation pressure, battery status.
- Malfunctions and faults of important system components, for example lights and brakes.
- ▶ Responses of the vehicle to particular driving situations, for example triggering of an airbag, activation of the driving stability control systems.
- ▶ Information on vehicle-damaging events.

The data is required so that the control units can perform their functions. It is also used for detecting and rectifying malfunctions, as well as to optimise vehicle functions.

Most of this data is transient and is only processed within the vehicle itself. Only a small proportion of the data is stored in event or fault memories in response to specific circumstances.

### Personal settings

Convenience functions, such as seat, climate or light settings, enhance the driving experience. The personal settings for these functions can be saved in a BMW ID or in a profile within the vehicle and retrieved as required, for example if the settings have been changed in the meantime by another driver. Depending on the equipment, these profiles can be saved in the vehicle manufacturer's secure data systems. When the driver changes vehicle, these saved profiles can simply be applied to a different vehicle.

The vehicle settings stored in a BMW ID or vehicle profile can be changed or deleted at any time.

## Multimedia and navigation

Data can be additionally imported into the vehicle entertainment and communication system, for example, via smartphone. The imported data can be processed within the vehicle, for example to play the user's favourite music.

Depending on the equipment, this data includes:

- Multimedia data, such as music or photos, for playback in an integrated multimedia system.
- Address book data for use in conjunction with an integrated hands-free system or an integrated navigation system.
- ▶ Destinations: depending on the equipment, route guidance can be started automatically using destinations learned by the navigation system.
- Data on usage of Internet services.

This data may be saved locally in the vehicle or stored on a device that has been connected to

the vehicle, for example, a smartphone or USB stick.

### Service data

#### General

When services are required, for example repairs, service operations, warranty work and quality assurance measures, this technical information can be read out from the vehicle together with the vehicle identification number.

#### Stored data

Electronic vehicle components may contain data storage medium which store technical information relating to the vehicle condition, events and faults. The data required for service measures is processed locally and is deleted automatically once the work is complete. A Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop can read out the information. During servicing and repair work, data is read out by the socket for on-board diagnosis using special diagnosis systems and sent to the vehicle manufacturer. The customer is entitled to withhold consent to the data being read out and forwarded.

## Optimising service processes

The vehicle manufacturer maintains documentation relating to each vehicle to ensure the best possible service is provided. Within the scope of legal requirements, this documentation may be made available to authorised third parties, for example specialist workshops.

The authorised third parties may only use this data for the purposes of performing the service or repair order in question. This prevents work from being duplicated unnecessarily on the vehicle, for example.

#### Ensuring product quality

The data logs the technical conditions of the vehicle and helps in locating faults, complying with warranty obligations and improving qualitv.

To ensure product quality and the development of new products, data on the usage of individual components and systems, for example, lights, brake, electric windows, displays, can be read out. This data helps the vehicle manufacturer to optimise the design of components and systems. Data analysis also provides the basis for Technical Campaigns and mandatory recalls.

Furthermore, the manufacturer has product monitoring obligations to meet in line with product liability law. To fulfil these obligations, the vehicle manufacturer requires technical data from the vehicle.

#### Goodwill and warranty claims

Data from the vehicle can also be used to check customer warranty claims. If goodwill or warranty claims are asserted, the data is read out and transferred to the vehicle manufacturer to resolve the claims promptly.

Fault and event memories in the vehicle can be reset when a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop performs repair or servicing work.

#### Control over data

You may request the stopping of data transfers to the vehicle manufacturer for the purpose of ensuring product quality and optimising service processes.

#### Legal requirements regarding data disclosure

According to current law, the vehicle manufacturer is obliged to provide the authorities with any data it has stored. Data is provided to the

extent required and on a case-by-case basis, for example to investigate a criminal offence.

Current law also gives state bodies authorisation to read out data from the vehicle themselves for individual cases. Information can be read out from the airbag control unit, etc. to shed light on the circumstances of an accident, for example.

Within the framework of legal obligations in the EU, certain vehicle consumption data, such as fuel or energy consumption and distance travelled, also called OBFCM data, is sent to the EU Commission by the vehicle manufacturer. The registered keeper may refuse to provide this data for this purpose.

#### Mobile devices

Depending on the equipment, mobile devices such as smartphones can be connected to the vehicle to control smartphone functions from the vehicle, for example Apple CarPlay. Sound and images from the mobile device may be played back or displayed through the multimedia system in the vehicle, for example.

Selected information is transferred to the mobile device at the same time. Depending on the type of integration, this includes position data and other general vehicle information, for example. This enables optimum use of selected apps, for example navigation and music playback. How the data is processed further is determined by the provider of the particular app being used.

#### Services

#### General

If the vehicle has a wireless network connection, data can be exchanged between the vehicle and other systems, for example with BMW ConnectedDrive.

#### Services from the vehicle manufacturer

The various functions of online services provided by the vehicle manufacturer are described at appropriate points, for example in the Owner's Handbook or on the manufacturer's web page. The relevant legal information pertaining to data protection is also given.

Personal data may be used to provide online services. Data is exchanged over a secure connection, for example with the vehicle manufacturer's data systems set up for this purpose.

Any collection, processing and use of personal data above and beyond that needed to provide the services always requires legal permission, a contractual agreement or consent of the user.

#### BMW ConnectedDrive

BMW ConnectedDrive networks the vehicle with a number of digital services. When these services are used, only the data stored in the vehicle and required to provide the service is transferred online, for example information on identifying and locating the vehicle. Usage is based on a contractual agreement with the user.

In individual cases, the transfer of data is triggered as a result of predefined events, such as an intelligent emergency call. The wireless network connection is established via an in-vehicle transmitter and receiver unit or via personal mobile devices brought into the vehicle, for example smartphones. Data transfer can be deactivated on request.

The wireless network connection enables online functions to be used. These include online services and apps supplied by the vehicle manufacturer or by other providers.

#### Services from other providers

When using online services from other providers, these services are the responsibility of the relevant provider and subject to their data protection conditions and terms of use. The ve-

hicle manufacturer has no influence over the data that is exchanged.

Information as to how personal data is collected and used in relation to services from third parties, the scope of such data and its purpose, can be obtained from the relevant provider.

#### Personal decision

Every user decides for themselves whether they wish to enter into a contract for a service such as BMW ConnectedDrive. Information on the extent of data processing and the content involved is provided in writing before the service is acquired and forms part of the vehicle handover.

The user has the option to deactivate the services at any time and consequently to stop the data processing required for the services. It is also possible to have the entire data connection activated or deactivated. Excluded from this are functions and services which are required by law, for example emergency call systems.

#### Transparency concerning vehicle data

BMW CarData provides transparency in handling vehicle data with the use of BMW ConnectedDrive. BMW CarData enables users to control whether vehicle data being processed in the context of BMW ConnectedDrive is transferred to third parties. Users can decide for each individual service offering whether data access is to be granted or refused to third parties, for example to insurance companies.

An archive can also be requested from BMW CarData at any time. The archive provides information on the data that has been transmitted and saved in the context of BMW ConnectedDrive. BMW CarData can only be accessed by third-party providers via the vehicle manufacturer's servers. Direct access to the vehicle and its data is not permitted.

More information on BMW CarData is available on the BMW ConnectedDrive Customer Portal.

## Statutory emergency call system

#### Principle

The eCall emergency call system required by law enables manual or automatic emergency calls to be made, for example in the event of an accident.

The emergency calls are answered by the public rescue coordination centre.

#### General

For information on the eCall statutory onboard emergency call system based on the 112 emergency call, as well as its operation and its functions, see the chapter on emergency calls.

The eCall service based on the 112 emergency call is a public service of general interest and is provided free of charge.

If a serious accident occurs, the legal emergency call system is activated automatically by on-board sensors as standard practice. It is also triggered automatically if the vehicle is equipped with an intelligent emergency call system that fails to work in the event of a serious accident.

The legal emergency call system can also be triggered manually if required.

If a critical system failure occurs that would put the eCall statutory emergency call system out of operation, the vehicle occupants receive a warning.

For further information:

- ▶ Emergency call, see page 335.
- ▶ Malfunction, see page 336.

#### Information on data processing

The eCall statutory emergency call system processes personal data in accordance with the following regulations:

- Protection of personal data: Regulation (EU) 2016/679 of the European Parliament and of the Council.
- Protection of personal data: Directive 2002/58/EC of the European Parliament and of the Council.

Personal data is only processed for the purpose of transmitting eCall emergency calls to the single European emergency call number 112.

#### SIM card

The legal emergency call system operates via mobile radio through the SIM card installed in the vehicle. The SIM card is not permanently connected to the mobile phone network; rather, it remains connected only as long as the emergency call is active.

#### Data types and their recipients

The legal emergency call system may only collect and process the following data:

- The vehicle identification number for rapidly identifying the vehicle, for example the model.
- ▶ Vehicle type, for example passenger car.
- ➤ Type of vehicle drive, for estimating risks during recovery, e.g. fire hazard.
- ➤ The vehicle's position at the time of the accident, its last three locations and the direction of travel in order to locate the vehicle more quickly on very complex route sections, for example.
- ▶ A log of the automatic system activation, along with the time stamp.
- Control information, which tells rescue services whether the emergency call was triggered automatically or manually, for example.

- ▶ A time stamp for determining the time of the accident in order to optimise the deployment plans of the rescue services.
- ➤ The direction of travel for establishing which side of the carriageway is affected, for example.

The authorities of the state in whose territory the eCall system emergency call is made determine which emergency call centres receive and process the statutory emergency call.

### Data processing configuration

The legal emergency call system ensures that the data stored on the system memory can only be accessed outside the system once an emergency call is triggered.

The data collected for the legal emergency call system is only saved in the vehicle and sent to the rescue coordination centre when an emergency call is triggered.

The legal emergency call system ensures that it cannot be traced and that it is not tracked continuously during normal operation.

The legal emergency call system ensures that the data in the internal system memory is deleted automatically and continuously.

The vehicle's location data is continuously overwritten in the system's internal memory so that only the vehicle's last three locations - which the system needs for normal operation - are ever stored.

The activity data log of the eCall statutory emergency call system is retained only for as long as is necessary to handle the eCall emergency call and under no circumstances for any longer than 13 hours after the eCall emergency call was triggered.

# Rights of individuals affected by data processing

The individual affected by data processing, for example the registered keeper, has the right to access the data and can request that their personal data, as well as data whose processing does not comply with legal requirements, be corrected, deleted, or restricted as applicable. Each time that data is corrected, deleted or blocked in line with these regulations, the third parties to whom the data was transmitted must be notified, insofar as this is reasonably practical.

The individual affected by data processing has the right to file a complaint with the relevant data protection body if they believe that their rights have been violated as a result of having their personal data processed.

For matters relating to access rights, please contact a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

## Intelligent emergency call system

#### Principle

The intelligent emergency call system enables manual or automatic emergency calls to be placed, for example in the event of an accident.

The emergency calls are answered by an emergency call centre appointed by the vehicle manufacturer.

In addition to the intelligent emergency call system, the legal emergency call system is present in the vehicle and is active depending on the situation.

The registered keeper has the right to use either the intelligent emergency call system or the legal emergency call system.

For further information:

Emergency call, see page 335.

#### Legal basis

The intelligent emergency call system processes personal data in accordance with the following regulations:

- Protection of personal data: Regulation (EU) 2016/679 of the European Parliament and of the Council.
- Protection of personal data: Directive 2002/58/EC of the European Parliament and of the Council.

The ConnectedDrive contract concluded for this feature, as well as the relevant laws, ordinances, and directives of the European Parliament and the European Council, provide the legal basis for the activation and function of the Intelligent Emergency Call system.

The relevant ordinances and directives govern the protection of individuals in terms of processing personal data.

The intelligent emergency call system processes personal data in accordance with European directives on the protection of personal data.

The Intelligent Emergency Call system processes personal data only with the registered keeper's consent.

The Intelligent Emergency Call system and other services providing additional benefit may only process personal data with the express consent of the individual affected by data processing, for example the registered keeper.

#### SIM card

The intelligent emergency call system operates via mobile radio through the SIM card installed in the vehicle. The SIM card is permanently logged into the mobile phone network so a connection setup can be established quickly. The data is sent to the vehicle manufacturer in emergencies.

## Improving quality

The vehicle manufacturer also uses the data sent as part of an emergency call to improve product and service quality.

#### Position determination

Only the provider of the mobile phone network is able to determine the position of the vehicle based on mobile phone mast locations. The network operator is not able to link the vehicle identification number to the phone number of the installed SIM card. Only the vehicle manufacturer is able to link the vehicle identification number to the phone number of the installed SIM card.

#### Log data for emergency calls

The log data for emergency calls is saved in a vehicle memory. The oldest log data is regularly deleted. The log data includes information on when and where an emergency call was placed, for example in the event of an accident. In exceptional cases, the log data can be read out from the vehicle memory. The log data is usually read out only if a court order has been issued and is only possible when the relevant devices are connected directly to the vehicle.

## Automatic emergency call

The system is designed so that it automatically triggers an emergency call if the vehicle sensors detect an accident of corresponding severity.

#### Sent information

If an emergency call is made by the intelligent emergency call system, the same information is sent to the appointed emergency call centre as is normally sent to the public rescue coordination centre by the legal emergency call system.

Furthermore, the intelligent emergency call system also conveys the following additional information to an emergency call centre appointed by the vehicle manufacturer and, where applicable, to the public rescue coordination centre:

► Accident data, for example the direction of the collision as detected by the vehicle sen-

- sors in order to assist the rescue services in their deployment plans.
- Contact data, for example the phone number of the installed SIM card and the driver's phone number, if available, so that those involved in the accident can be contacted quickly if necessary.

#### Data storage

The data relating to a placed emergency call is saved in the vehicle. The data contains information about the emergency call, for example the place and time it was made.

The emergency call centre saves audio recordings of the emergency call.

Audio recordings of the customer are saved for 24 hours, in case details of the emergency call need to be analysed. After that, the audio recordings are deleted. Audio recordings of the emergency call centre employee are saved for 24 hours for quality assurance purposes.

### Disclosure of personal data

The data obtained in the context of an intelligent emergency call is only used to process the emergency call. If legally obliged to do so, the vehicle manufacturer will disclose the data it has processed and, where applicable, still has saved.

#### Statutory emergency call system

The owner of a vehicle equipped with an intelligent emergency call system and the legal emergency call system is entitled to use the on-board emergency call system instead of the intelligent emergency call feature.

To request deactivation, please contact a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

The legal emergency call system is always on standby in addition to the intelligent emergency call system. The legal emergency call system takes over the emergency call function

if the intelligent emergency call system is not operational for technical reasons, for example if the emergency call centre appointed by the vehicle manufacturer cannot be reached.

The eCall statutory emergency call system uses the infrastructure of the 112 public emergency call number.

The system can be configured so that emergency calls are always made by the legal emergency call system and not by the intelligent emergency call system. Have the setting configured by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

# Vehicle identification number

#### General

Depending on the national-market equipment, the vehicle identification number is located at different positions in the vehicle. This chapter describes all the positions that are possible for the model range.

## Engine compartment



The vehicle identification number is engraved in the engine compartment, on the right side of vehicle.

## Type plate on right-hand side



The vehicle identification number is on the type plate on the right-hand side of vehicle.

## Type plate on left-hand side



The vehicle identification number is on the type plate on the left-hand side of vehicle.

#### Windscreen



The vehicle identification number is additionally located behind the windscreen.

## iDrive

It is also possible to display the vehicle identification number via iDrive.

- 1. "MENU"
- 2. "All apps"
- 3. "Mobile devices"
- 4. "Settings"
- 5. "Vehicle ID (VIN):"



# Getting in

## Opening and closing

## Vehicle key



Buttons on the vehicle key.

## Icon Meaning



Unlock.



Lock.



Unlock the luggage compartment.



Home lights.

#### Access to vehicle interior

## Unlocking with the vehicle key



Press the button on the vehicle key.

Depending on the settings, this will unlock the driver's door only, or all vehicle access points. If only the driver's door is unlocked, press the button on the vehicle key again to unlock the other vehicle access points.

#### Locking with the vehicle key

1. Close the driver's door.



Press the button on the vehicle key.

All vehicle access points are locked.

## Central locking buttons

#### Overview



The central locking system buttons are located on the front door.



Lock.



Unlock.

#### Locking the vehicle



Press the button with the front doors closed.

The fuel filler flap remains unlocked.


## Unlocking the vehicle



Press the key.

## Access to the luggage compartment

#### Opening the luggage compartment



Unlock the vehicle and then press the button on the outer side of the luggage compartment.



Press and hold the button on the vehicle key for approximately 1 second.


The doors are unlocked if applicable.

#### Closing the luggage compartment

Close the luggage compartment manually.

# Displays, operating elements

## Around the steering wheel



- 1 Light switch element
- 2 Turn indicator, high-beam headlight
- 3 Instrument cluster
- 4 Windscreen wipers

## Indicator and warning lights

Indicator and warning lights can illuminate in a variety of combinations and colours.

When switching on drive-ready state, the functionality of some lights is checked and they illuminate briefly.

#### Driver's door



- 1 Window lifters
- **2** Central locking system
- **3** Seats, comfort functions
- 4 Exterior mirrors
- **5** Opening/closing the luggage compartment

### Switch cluster



- Selector lever
- 2 Controller
- **3** Parking brake, Automatic Hold
- **4** Driving Experience Control
- **5** Start/Stop button
- **6** Assistance systems

#### \*

#### BMW iDrive

#### Principle

BMW iDrive is the vehicle's display and operating concept and includes a wide range of functions.

#### Buttons on the Controller

Button	Function
HOME	To go to the main menu.
MEDIA	To go to the Media/Radio menu.
TEL	To go to the Telephone menu.
MAP	To go to the navigation map.
NAV	To go to the destination entry menu of the navigation system.
BACK	Go to previous display area.
OPTION	To go to the Options menu.

#### **BMW Intelligent Personal Assistant**

#### Principle

The BMW Intelligent Personal Assistant is a personal assistant that enables natural voice control of various vehicle functions.

#### Activating voice input

- 1. Press the button on the steering wheel.
- 2. Say the command.

#### Cancelling voice input




- Press the button on the steering wheel again.
- ▶ → Cancel
- ▶ Slide the Controller to the right or left.
- ▶ Press the Controller.

# Adjustment and operation


## Seats, mirrors and steering wheel

### Manually adjustable seats



- Longitudinal direction
- 2 Thigh support
- 3 Seat angle
- 4 Backrest width
- **5** Lumbar support
- 6 Height
- 7 Backrest angle


## Electrically adjustable seats



- Backrest width
- 2 Height/longitudinal direction/seat angle
- **3** Head restraint/backrest angle
- 4 Lumbar support

## Adjusting the head restraint


#### Adjusting the height: manual head restraints



- Down: press the button, arrow 1, and slide the head restraint downwards.
- ▶ Up: push the head restraint upwards.

After adjusting the height, make sure that the head restraint engages correctly.

#### Adjusting the height: M sport seat



Press the switch up or down.

#### \*

#### Adjusting the distance



- Back: press the button and push back the head restraint.
- ▶ Forward: pull the head restraint forwards.

After adjusting the distance, make sure that the head restraint engages correctly.

## Adjusting the distance: M sports seat

The distance from the back of the head is adjusted by the seat backrest angle.

## Adjusting the exterior mirrors



#### Icon Meaning



Fold the exterior mirror in and out.




Adjust the exterior mirrors.



Select mirror, automatic parking function.

## Adjusting the steering wheel



- 1. Fold the lever down fully.
- 2. Grip the steering wheel with both hands and adjust it in the longitudinal direction and height of the seat position.
- 3. Fold the lever back up.

## Memory function

#### Principle

The memory function enables the following settings to be stored and retrieved when reauired:

- Seat position.
- Exterior mirror position.
- Depending on the equipment: height of the Head-up display.


#### Overview



The memory buttons are on the front doors.

#### Storing settings

1. Set the desired position.



3. Press the desired button 1 or 2 while the LED is illuminated. A signal sounds.

#### Go to Settings

Press the desired button 1 or 2.

## Entering the rear passenger compartment

#### Manual forward/back adjustment

#### Folding down the backrest

1. Pull the lever as far as it will go.



- 2. Fold the backrest forwards.
- 3. Slide the seat forwards.

#### Folding back the backrest

- 1. Slide the seat back to its initial setting.
- 2. Fold back the backrest to lock the seat.

#### Electric forward/back adjustment

#### Folding down the backrest

1. Pull the lever as far as it will go.



Fold the backrest forwards.

For easier access to the rear compartment, the seat automatically moves all the way forwards.

The process is interrupted if the switch for the forward/back position is pressed or the backrest is folded back.

#### Folding back the backrest

Fold back and lock the backrest.

The seat automatically moves back to its last saved position.

#### Infotainment

## Navigation destination entry

- 1. "NAV"
- 2. "Destination input"
- 3. To enter a new destination or start route quidance, tap on the search field or select an entry from the search history.
- 4. Enter at least two characters.

If necessary, start the search for point of interest categories from the Points of Interest menu.

If necessary, accept the suggested search term.



- 5. A list of results is displayed.
- 6. Select the desired entry.

#### Entertainment

Depending on the national-market version and equipment specification, the following buttons are installed in the instrument panel.

Button	Function
	Turn the knob to set the volume.
	Press the knob to switch off the sound output. Pressing again restores the previous volume.
MEDIA	Changing the entertainment source.
144	Press once: to change the station/music track.
	Press and hold: to fast forward/rewind the music track.

## Using the mobile phone

#### General

Once the mobile phone has been connected in the vehicle, it can be operated using iDrive and the buttons on the steering wheel.

Activate Bluetooth® on the mobile phone.

## Connecting via Bluetooth®

- 1. "MENU"
- 2. "All apps"
- 3. "Mobile devices"
- 4. "Connect new device"

Mobile phones in range are displayed on the control display.

5. Select the required mobile phone.

- Compare the control number displayed on the control display with the control number in the display of the mobile phone and confirm that they match.
- 7. If necessary, select the connection mode: "Use Bluetooth"

The device is connected and displayed in the device list.

#### Accepting a call

Depending on the equipment, incoming calls can be accepted in different ways.

- Via iDrive:
  - ↑ "Accept"



Press the button on the steering wheel.

Use the knurled wheel on the steering wheel to select from the list in the instrument cluster: "Accept"

#### Dialling a number

- 1. "TEL"
- 2. "More"
- 3. "Dial number"
- 4. Enter the numbers.
- Select the icon. The call is made using the mobile phone to which the telephone function is assigned.

## On the move

## Driving

#### Drive-ready state

#### Switching on drive-ready state



- 1. Press the brake.
- 2. Press the Start/Stop button.

#### Switching off drive-ready state

- 1. With the vehicle at a standstill, engage selector lever position P.
- 2. Apply the parking brake.
- Press the Start/Stop button.The engine is switched off.

## Automatic Start/Stop function

The Automatic Start/Stop function switches the engine off automatically when stationary to save fuel. For driving off, the engine starts automatically under the following conditions:

- ▶ By releasing the brake pedal.
- ▶ With Automatic Hold activated: press the accelerator pedal.

#### Steptronic transmission

# Engaging selector lever positions D, N, R, S



- D Drive position.
- N Neutral.
- R reverse gear.
- S Sport programme.

Keep the brake applied until ready to drive off, otherwise the vehicle will move when drive position or reverse gear is selected.

Only engage selector lever position R when the vehicle is stationary.

Sport programme: the shift characteristics are designed for sportier drivability.

#### Engaging selector lever position P

Only engage selector lever position P when the vehicle is stationary.



Press button P.



## Parking brake

### Applying the parking brake



Pull the switch.

The LED on the switch and the indicator light in the instrument cluster are

illuminated.

#### Release the parking brake



With drive-ready state switched on: Press the switch with the brake applied

or the selector lever in position P.

The LED and the indicator light go out. The parking brake is released.


#### **Parking**

Make sure the parking brake is engaged.

## Light and vision

# Turn indicator, high-beam headlight, headlight flasher

#### Turn indicators



- ▶ Flashing: press the lever past the resistance point.
- One-touch signalling: lightly tap the lever up or down.
- To indicate a turn briefly: press the lever as far as the resistance point and hold it there for as long as you wish to indicate a turn.

# High-beam headlight, headlight flasher




Press the lever forwards or pull it back.

- ➤ High-beam headlight on, arrow 1. The high-beam headlight is illuminated when the low-beam headlight is switched on.
- High-beam headlight off/headlight flasher, arrow 2.


## Lights and lighting


#### Buttons in the vehicle

lcon	Function
<b>()</b> ‡	Rear fog light.
OFF	Lights off. Daytime driving lights.
	611 11 1 .










## Wiper system


## Switching on the wiper system



Press the lever upwards to the desired position.

- ▶ Rest position of the windscreen wipers: position 0.
- Rain sensor: position 1.
- ▶ Normal wiper speed: position 2.
- > Fast wiper speed: position 3.

## Switching off the wiper system and flick wiping



Press the lever down.

- ▶ To switch off: press lever downwards until position 0 is reached.
- ▶ To flick wipe: press the lever downwards from position 0.

The lever returns to position 0 when released.

## Activating/deactivating the rain sensor




To activate: press the lever upwards once from position 0, arrow 1.

To deactivate: press the lever back to position 0.



# Adjusting the sensitivity of the rain sensor



Turn the knurled wheel on the wiper lever.

## Cleaning the windscreen



Pull the lever.

## Air conditioning

## Air conditioning functions

## Functions in the air conditioning menu

lcon	Function
AUTO	Automatic programme.
22.0°C	Temperature.
A/C	Air conditioning function.

Icon	Function
MAX A/C	Maximum cooling.
<b>€</b>	Air recirculation function.
₹ <mark>©</mark> Å	Automatic air recirculation control.
	Fresh air.
<b>%</b>	Amount of air.
فر	Air distribution.
SYNC	SYNC programme.
<b>V</b> 447,	Seat heating.

The functions can also be operated via voice, for example, Temperature.

# Buttons, integrated automatic heating/air conditioning system





lcon	Function
MAX \\	Defrost function.
REAR	Rear window heating.

# Buttons, automatic rear airconditioning system



lcon	Function
AUTO	Automatic programme.
▼ ▲	Temperature.
₹,i	Air distribution.
<b>V</b> 222,	Seat heating.
OFF	To switch off.

## Pit stop

## Refuelling

### Fuel filler cap

1. To open the fuel filler flap, press on the rear edge, arrow. The fuel filler flap opens.



2. Turn the fuel filler cap anticlockwise.



3. Place the fuel filler cap in the holder on the fuel filler flap.



#### \*

## Wheels and tyres

## Tyre inflation pressure information



The tyre inflation pressure information can be found on the tyre pressure label on the body pillar of the driver's door.

# After adjusting the tyre inflation pressure

If equipped with a Tyre Pressure Monitor, tyre inflation pressure corrections are applied automatically. Make sure that the tyre settings are correct. For tyres that are not listed in the tyre inflation pressure information on the control display, reset the Tyre Pressure Monitor.

If equipped with a Flat Tyre Monitor, reinitialize the Flat Tyre Monitor.

## Checking the tyre inflation pressure

Check regularly and adjust as necessary:

- At least twice a month.
- Before a long journey.

#### Electronic oil measurement

## Operating requirements

A current reading is available after approximately 30 minutes of normal driving.

## Displaying the engine oil level

- 1. "MENU"
- 2. "Vehicle apps"

- "Vehicle status"
- 4. "Engine oil level"

The engine oil level is displayed.

## Topping up engine oil

#### General

Stop the vehicle safely and switch off driveready state before topping up with engine oil.

## Topping up engine oil

- 1. Open the bonnet.
- 2. Turn the cap anticlockwise to open.



- 3. Add engine oil.
- 4. Tighten cap.

## How to get assistance

## Hazard warning lights





Hazard warning lights button

## **BMW Emergency Service**

In many non-Connected Drive countries, BMW Roadside Assistance can be reached by telephone around the clock. Support can be obtained there in the event of a breakdown.

In ConnectedDrive countries, proceed as follows:

- 1. "MENU"
- 2. "All apps"
- "BMW Assistance"
- 4. Select the desired service.

A voice contact to the selected service is established.

#### ConnectedDrive

#### **BMW** Assistance

Contact BMW Assistance for information and support on all aspects of your vehicle.

- 1. "MENU"
- 2. "All apps"
- 3. "BMW Assistance"
- 4. Select the desired service.

#### Teleservices

Teleservices are services that help to keep the vehicle mobile.

Teleservices may include the following services:

- ▶ BMW Roadside Assistance.
- BMW Accident Assistance.
- ▶ Teleservice Call.
- Your Service Partner.



# Vehicle cockpit

## Vehicle equipment


This chapter describes equipment, systems and functions which are offered or will be of-

fered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

## Around the steering wheel



1

Window lifters 91

2 Exterior mirror operation 108

**3** Seat comfort functions

SET

Memory function 111

**4** Central locking system 87



To unlock



To lock

**5** Lights



Rear fog light 166



Light switch 160



Lights off

Daytime driving lights 163



Side lights 161



Automatic driving lights control

Adaptive lighting functions 163 High-beam Assistant 164



Low-beam headlight 161



Instrument lighting 166





Right parking light 161



Left parking light 161

**6** Steering column lever, left



Turn indicator 135



High-beam headlight, headlight flasher 136



High-beam Assistant 164



Trip data 153 q-Meter 155

- **7** Shift paddles 128
- **8** Buttons on steering wheel, left



Manual Speed Limiter 201



Depending on the equipment:

Cruise Control on/off 203





Depending on the equipment:

Active Cruise Control on/off 206



Cruise Control: to store a speed Speed Limit Assist: to accept the suggested speed 212



Resuming Cruise Control



To interrupt Cruise Control



Active Cruise Control: to increase the distance



Active Cruise Control: to reduce the distance



Cruise Control rocker switch

- 9 Instrument cluster 140
- **10** Buttons on steering wheel, right



Displaying the menu bar in the instrument cluster 140



Volume, see Owner's Handbook for Navigation, Entertainment, Communication 6



Voice control system 57



Selecting the menu contents in the instrument cluster 140

To change the station/music track, see the Owner's Handbook for Navigation, Entertainment, Communication 6







Telephone, see Owner's Handbook for Navigation, Entertainment, Communication 6



Knurled wheel for selecting configuration menus for instrument cluster and head-up display 140 Operating the infotainment selection lists in the instrument cluster 149

11 Steering column lever, right



Windscreen wipers 136



Rain sensor 137



To clean the windscreen 138





Horn, entire area



Steering wheel heating 110

**14** To adjust the steering wheel 110 15


To unlock the bonnet 312



Opening and closing luggage compartment 82

**17** Fold-down compartment 253

## Around the centre console



- 1 Control display 52
- 2 Ventilation 244

3 🛦 🖯

Hazard warning lights 333

Climate control 237



Defrost function 243



Rear window heating 243

Radio/multimedia, see Owner's Handbook for Navigation, Entertainment, Communication 6



Adjusting the volume



Station/track forward



Station/track back

- **4** Button for glove compartment 253
- **5** Controller with buttons 54

**6** Automatic Hold 134



Parking brake 132

7 SPORT Driving Experience Control 131

SPORT drive mode



COMFORT drive mode



ECO PRO drive mode



Switching drive-ready state on/off 123





9 (A)0FF Automatic Start/Stop function 123



Parking assistance systems 215



Panorama View 222



Dynamic Stability Control 194

10 Selector lever 126

## Around the headliner



1 SOS

Emergency call, SOS 335

4



2 \_\_\_

To operate the electric glass sunroof 94

5 📉

Interior lights 166

PASSENGER AIR BAG
ON OFF

Depending on the national-market version:

Front passenger airbag indicator light 171

# Sensors in the vehicle

# Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

### Overview

Depending on the equipment, the following cameras and sensors are installed in the vehicle:

- Front camera.
- ▶ Camera behind the windscreen.
- Exterior mirror cameras.
- Reversing Assist Camera.
- ▶ Front radar sensor.
- ▶ Side radar sensors, rear.
- Ultrasonic sensors in the front/rear bumpers.
- ▶ Side ultrasonic sensors.


## Cameras

#### Front camera



The front camera is located in the radiator arille.

#### Camera behind the windscreen



The camera behind the windscreen is located in the area of the interior mirror.


## 1

#### Exterior mirror cameras



An exterior mirror camera is located under each exterior mirror housing.

## Reversing Assist Camera



The Reversing Assist Camera is located in the handle strip on the rear.

# Functional requirement of the cameras

The areas of the cameras are clean and clear. For further information:

- ▶ Washing the vehicle, see page 342.
- ▶ Vehicle care, see page 343.

## System limits of the cameras

The function of the cameras can be restricted or may indicate something wrong, for example in the following situations:

- ▶ In thick fog, wet conditions or snow.
- ▶ On steep crests or dips or on tight bends.

- When the camera field of view is covered, for example by a fogged up windscreen or stickers.
- ▶ If the camera lens is dirty or damaged.
- ▶ With the exterior mirrors folded in.
- With open doors or open luggage compartment.
- In the case of bright oncoming light or strong reflections, for example if the sun is low in the sky.
- ▶ In the dark.
- The camera has overheated due to excessive temperatures and temporarily turned off.
- During the camera calibration process immediately after vehicle delivery.

A Check Control message may be displayed if the system limits are reached.

## Radar sensors

## Safety information



#### ↑ WARNING


Due to external influences, e.g. interference, the radar sensors of the vehicle and thus also the driving assistance systems can be disturbed. There is a risk of accident. Observe the traffic situation, be ready to take over steering and braking at any time, and actively intervene if the situation warrants it.

#### Front radar sensor



The front radar sensor is located in the front bumper.

## Side radar sensors, rear



The radar sensors are located in the rear bumper.

# Functional requirement of the radar sensors

The areas of the radar sensors are clean and clear.

For further information:

- ▶ Washing the vehicle, see page 342.
- ▶ Vehicle care, see page 343.

### System limits of the radar sensors

The function of the radar sensors can be restricted or not available, for example in the following situations:

- ▶ If the sensors are contaminated.
- ▶ In case of iced up sensors.

- If the sensors are obscured, for example by stickers, foils or a number plate holder.
- ▶ If the sensors are misaligned, for example due to parking damage.
- ▶ If the radiation range of the sensors is covered, for example by protruding loads.
- ▶ When the field of view of the sensors is covered, for example by garage walls, hedges, snow hills, vehicles or trailers.
- ▶ After work performed incorrectly on the vehicle paintwork near to the sensors.
- ▶ At steep crests or hollows of hills.

A Check Control message may be displayed if the system limits are reached.

## Ultrasonic sensors

#### Ultrasonic sensors, front




The ultrasonic sensors of the parking assistance systems are located in the front bumper.






#### Ultrasonic sensors, rear



The ultrasonic sensors of the parking assistance systems are located in the rear bumper.

#### Side ultrasonic sensors



The ultrasonic sensors of the parking assistance systems are located on the side in the front and rear bumpers.

# Functional requirement of the ultrasonic sensors

The areas of the ultrasonic sensors are clean and clear.

For further information:

- ▶ Washing the vehicle, see page 342.
- ▶ Vehicle care, see page 343.

# System limits of the ultrasonic sensors

The physical limits of ultrasound measurement may be reached when detecting objects in situations involving the following, for example:

- If the sensors are dirty or covered, e.g. by stickers.
- ▶ If the sensors are misaligned, for example due to parking damage.
- ▶ After work performed incorrectly on the vehicle pointwork near to the sensors.
- Small children and animals.
- ▶ Persons wearing certain types of clothing, for example a jacket.
- ▶ Obstacles and people at the edge of the driving lane.
- If there is external interference with the ultrasonic sound, for example by passing vehicles, loud machines or other ultrasonic sources.
- Certain weather conditions; for example, high air humidity, wet conditions, snowfall, cold, extreme heat or strong wind.
- For trailer towbars and tow hitches of other vehicles.
- ▶ Thin or wedge-shaped objects.
- Moving objects.
- Higher protruding objects, for example projecting walls.
- ▶ Objects with corners, edges and smooth surfaces.
- ▶ For objects with fine surfaces or structures, e.g. wire mesh fences.
- Objects with porous surfaces.
- Small and low objects such as boxes.
- ▶ Low objects already displayed, for example, kerbs, can be outside of the detection ranges of the sensors.
- Soft obstacles or obstacles covered in foam material.
- Plants or shrubs.
- ▶ In washing bays and car washes.
- On uneven surfaces, for example speed bumps.
- ▶ In the presence of dense exhaust fumes.

LS 👈

- ➤ The ultrasonic sensors do not take into account loads projecting beyond the outline of the vehicle.
- ▶ If the cover of the trailer tow hitch is incorrectly seated.

A Check Control message may be displayed if the system limits are reached.



# Vehicle operating condition

## Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

### General

Depending on the situation, the vehicle is in one of the three states:

- Rest state.
- Standby state.
- Drive-ready state.

### Rest state

### Principle

If the vehicle is in rest state, it is switched off.

#### General

The vehicle is in rest state before you open it from outside and once you have left the vehicle and locked it.

### Safety information



#### ↑ WARNING

An unsecured vehicle can start moving and roll away. There is a risk of accident. Before leaving the vehicle, secure the vehicle against rolling away.

Observe the following to ensure that the vehicle is secured against rolling away:

- > Apply the parking brake.
- > Turn the front wheels towards the kerb on uphill or downhill gradient.
- Additionally secure the vehicle on uphill or downhill gradient, for example with a chock.



#### ↑ WARNING

Unsupervised children or pets in the vehicle can set the vehicle in motion and endanger themselves or other road users, for example by the following actions:

- Pressing the Start/Stop button.
- Releasing the parking brake.
- > Opening and closing doors or windows.
- ▶ Engaging selector lever position N.
- > Operating vehicle equipment.

There is a risk of accident or injury. Do not leave children or pets unsupervised in the vehicle. When leaving the vehicle, take the vehicle key with you and lock the vehicle.

### Establishing the rest state automatically

The rest state is established automatically, for example in the following situations:

- After a few minutes, if no operation is performed on the vehicle.
- ▶ When the vehicle battery state of charge is
- Depending on the iDrive setting: one or both of the front doors is opened when leaving the vehicle after a journey.

In some situations, for example during a telephone call or when the low-beam headlight is switched on, the vehicle will not switch automatically to rest state.

#### Establishing rest state on opening the front doors

After a trip, the rest state can be established by opening the front doors. For this purpose, all passengers must exit the vehicle.

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Doors and windows"
- 4. "Lock/unlock"
- 5. "Turn off after opening door"

## Establishing the rest state manually

To establish rest state in the vehicle at the end of the journey:



Press and hold the button on the radio until the OFF display on the instrument cluster turns off

## Standby state

#### Principle

When standby state is activated, most functions can be operated while the vehicle is still stationary. Any desired settings can be performed.

#### General

The vehicle switches to standby state after the front doors are opened from the outside.

## Manually establishing standby state

#### General

The standby state can be switched on again after the rest state has been automatically established.

#### With button on the radio



Press the button on the radio. The control display and instrument cluster illuminate.

#### With the Start/Stop button



Press the Start/Stop button. The control display and instrument cluster illuminate.

## Display in the instrument cluster



OFF is shown in the instrument cluster. The drivetrain is switched off and standby state switched on.

## Drive-ready state

#### Principle

Switching on drive-ready state corresponds to starting the engine.

## General

Some functions can only be operated when the drive-ready state is switched on.

## Safety information



#### ♠ DANGER

A blocked exhaust pipe or inadequate ventilation can allow harmful exhaust fumes to enter the vehicle. The exhaust fumes contain pollutants which are colourless and odourless. In enclosed spaces, exhaust fumes can also build up outside the vehicle. There is a





danger to life. Keep the exhaust pipe clear and ensure sufficient ventilation.

#### ↑ WARNING

An unsecured vehicle can start moving and roll away. There is a risk of accident. Before leaving the vehicle, secure the vehicle against rolling away.

Observe the following to ensure that the vehicle is secured against rolling away:

- > Apply the parking brake.
- > Turn the front wheels towards the kerb on uphill or downhill gradient.
- > Additionally secure the vehicle on uphill or downhill gradient, for example with a chock.



#### ▲ NOTICE

Repeated attempts to start the engine or starting it several times in quick succession can cause the starter to overheat. Fuel will also be unburned or insufficiently burned. which could cause the catalytic converter to overheat. There is a risk of material damage. Avoid repeated starting in quick succession.

## Switching on drive-ready state

#### General



Drive-ready state is switched on using the Start/Stop button.

#### Switching on drive-ready state

- 1. Press the brake.
- 2. Press the Start/Stop button.

Starting proceeds automatically for a short time and stops as soon as the engine starts. Most of the indicator and warning lights in the instrument cluster illuminate for varying lengths of time.

#### Petrol engine

Depending on the motorisation, full drive power may not be available until approx. 30 seconds after the engine is started. In this case, the vehicle will not accelerate in the usual

For further information:

Power display, see page 150.

#### Diesel engine

With the engine cold and at temperatures below 0 °C, 32 °F the starting operation can be delayed slightly due to automatic preheating.

A Check Control message is shown.

After the engine is started, full drive power may not be available until the engine is at operating temperature. Pay attention to the engine temperature display and power display as applicable. In this case, the vehicle will not accelerate in the usual way.

For further information:

- ▶ Engine temperature display, see page 151.
- ▶ Power display, see page 150.

#### Display in the instrument cluster

The activated drive-ready state is indicated in the instrument cluster, depending on the equipment, by the display of information reauired for driving or the READY display.

### Switching off drive-ready state

- 1. With the vehicle at a standstill, engage selector lever position P.
- 2. Apply the parking brake.
- 3. Press the Start/Stop button. The engine is switched off. The vehicle changes to standby state.

# BMW iDrive

## Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

# Display and operating concept

#### Principle

BMW iDrive is the vehicle's display and operating concept and includes a wide range of functions.

#### General

Depending on the equipment, the functions can be operated as follows:

- ▶ Via the control display.
- Via the Controller.
- ▶ Via the touchpad.
- ▶ Via the BMW Intelligent Personal Assistant.
- ▶ Using the operating elements on the steering wheel.

Instrument cluster, see page 140.

### Safety information



#### ↑ WARNING

Operating integrated information systems and communication devices during a journey may distract you from the traffic situation. You could lose control of the vehicle. There is a risk of accident. Only operate the systems or devices if the traffic situation allows you to


do so. Stop if necessary and operate the systems or devices with the vehicle at a standstill.

#### Main menu

#### General

The main menu is divided into different areas:

#### Overview



- 1 Menu bar
- 2 Widaets
- **3** Status information
- 4 Climate bar, climate 237

#### Menu har

#### Menu

**II** "MENU": Access to apps and vehicle functions. A filter can be selected. The last selected filter is stored. If necessary, change the filter to see the apps you want.

- ▶ "All apps": all apps and functions are displaved.
- "Infotainment apps": only infotainment apps are displayed.
- "Vehicle apps": only functions for vehicle setting are displayed.



#### Media

☐ "MEDIA": Access to functions of the entertainment system, for example radio stations or connection with external devices.

#### Telephone

"TEL": Access to the telephone and message function as well as the connection and management of mobile devices, for example smartphones.

#### Navigation

"NAV": Access to navigation system, destination entry and traffic information. Configurable map views as well as other functions, for example points of interest.

#### Apple CarPlay©

© "Apple CarPlay": Depending on the national-market version with connected feature: access to Apple CarPlay. Apple CarPlay allows certain functions of a compatible Apple iPhone to be used securely via iDrive.

#### Android Auto©

▲ "Android Auto": Depending on the nationalmarket version with connected feature: access to Android Auto. Android Auto enables certain functions of a compatible Android smartphone to be used securely via iDrive.

#### Widgets

Widgets show real-time information and dynamic content, for example the map of the navigation system. The widgets also serve as buttons and allow jumping to the relevant menu.

#### Status information

#### General

The status field is located in the top area of the control display. Status information is displayed in the form of icons. Various symbols are avail-

able depending on vehicle equipment and national-market version.

#### Telephone status information

lcon	Meaning
8	Active call.
%	Data transfer not possible.
.atl	Signal strength.
<b>■</b> !	SIM card missing.

#### Entertainment status information

lcon	Meaning
411	USB audio.
<b>®</b> ⊓	Bluetooth audio.
Ti	Smartphone audio.
H	Connected Music.
<u> </u>	WiFi.
•	Apple CarPlay.
<b>A</b>	Android Auto.

#### Status information notifications

lcon	Meaning
1	Number of messages.
$\triangle$	Check Control message.
Fa .	Traffic information.
1/2	Suppress private information.
Š	Do not disturb.

#### For further information:

Owner's Handbook for Navigation, Entertainment, Communication, see page 6.



lcon	Meaning
$\forall$	Sound output active.
6/	Sound output deactivated.
<b>J</b>	Activation word active.
2	BMW ID or driver profile.
<b>FEE</b>	Route guidance active.
_	Quicklist.
(( <b>f</b> ))	Wireless charging active.
⊲ <sub>Poj</sub>	Park Distance Control: sound activated.
4/4/11	Park Distance Control: sound deactivated.

## Digit input and display

#### Letters and numbers

Letters and numbers can be entered using the controller, the touchpad, control display or voice control depending on the equipment.

lcon	Function
abc ABC	To switch between upper and lower case.
Ш	To enter a space.
EN	To switch between languages.
Ļ	To use voice input.
OK	To confirm your digit input.
<b>4</b> >	Move the entry area to the left or right.

#### Input comparison

When entering data from a database, for example contacts, the selection is gradually narrowed down with each character entered and supplemented if necessary.

#### Activating/deactivating functions

Some menu items are preceded by an icon. Selecting the menu item enables or disables the function.

lcon	Meaning
☑ ◎	Function is activated.
	Function is deactivated.

# Activating/deactivating audio confirmation

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "System settings"
- 4. "Sound"
- 5. Select the desired setting.

#### Quick access

The quicklist provides access to the shortcuts, certain settings and app recommendations.

Digit input	Operation
Show quicklist.	Swipe from top to bottom on the control display.
	Slide the Controller upwards.
Hide quick- list.	Swipe from the bottom up on the control display. Slide the Controller downwards.

#### Activating/deactivating pop-ups

Pop-ups are automatically shown on the control display for some functions. Some of these pop-ups can be activated or deactivated.

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "System settings"
- 4. "Pop-ups"
- 5. Select the desired setting.





#### Shortcuts

#### General

The iDrive functions can be stored on the shortcuts and called up directly, for example, radio stations, navigation destinations, phone numbers and menu entries.

#### Saving a function

- Select the desired function.
- 2. Press and hold the desired function.
- 3. "Add to shortcuts"

Shortcuts can only be created with an active BMW ID or a driver profile.

#### Performing a function

- 1. Swipe from top to bottom on the control display.
- 2. Tap the desired shortcut.

The function is carried out immediately. If you have selected a phone number for example, the connection will also be established.

#### **Deleting shortcuts**

- 1. Swipe from top to bottom on the control display.
- 2. Press and hold the desired shortcut.
- "Delete shortcut"

## **BMW Curved Display**

### Principle

The BMW Curved Display is the one-piece display in the vehicle that is curved towards the driver. The BMW Curved Display comprises the instrument cluster on the driver's side and the control display in the centre console.


#### General

Follow the instructions on cleaning the BMW Curved Display in the Care chapter.

For further information:

Care of special parts, see page 345.

#### Overview



- Instrument cluster 140
- **2** Control display 52

## Control display

#### Principle

The iDrive functions are shown on the control display.

### Safety information



#### ▲ NOTICE

Objects located in front of the control display may slip and damage the control display. There is a risk of material damage. Do not place objects in front of the control display.

### Overview



#### Control display

# Switching the control display on/off automatically

The control display is switched on automatically when the vehicle is unlocked or as soon as the control display is required for operation.

In certain situations, the control display is switched off automatically, for example if no operation is performed on the vehicle for several minutes.

# Switching the control display on/off manually

- 1. Swipe from top to bottom on the control display.
- 2. "Screen off"

Tap the control display to turn it on again.

## Adjusting the brightness

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Displays"
- 4. "Control display"
- 5. "Brightness at night"
- 6. Confirm the desired setting.

Depending on the lighting conditions, the brightness control may not be immediately apparent.

## System limits

If the control display is exposed to very high temperatures, for example because of strong sunlight, the brightness may be reduced and the control display may even switch itself off. Normal functions will be restored when the temperature is reduced, for example by providing shade or using the air conditioning.

## Controller

#### General

The buttons are used to go to menus directly.

#### Overview



Controller

### Buttons on the Controller


Button	Function
HOME	To go to the main menu.
MEDIA	To go to the Media/Radio menu.
TEL	To go to the Telephone menu.
МАР	To go to the navigation map.
NAV	To go to the destination entry menu of the navigation system.
BACK	Go to previous display area.
OPTION	To go to the Options menu.






### Operation


Turn to switch between menu items, for example.



▶ Press to select a menu item, for example.



Slide in four directions to change between display ranges, for example.



# Operation using the Controller

## Going to the main menu



Press the key.

The main menu is displayed.

## Selecting menu items

- 1. Turn the Controller until the desired menu item is highlighted.
- 2. Press the Controller.

### Selecting widgets

- 1. In the main menu, slide the Controller to the right.
- 2. Turn the Controller until the desired widget is selected.
- 3. Press the Controller.

## Changing between display areas

After a menu item has been selected, for example "System settings", a new display area will be displayed.

➤ Slide the Controller to the left. The current display area closes and the previous display area is shown.

BACK

Press the button.

The previous display area re-opens.

## Entering letters and numbers

#### Digit input

- 1. Turn the Controller: to select letters or numbers.
- 2. **OK**: to confirm your digit input. Set system language, see page 59.

#### Delete the input.

#### Icon Function

- Press Controller: to delete a letter or number.
- Press and hold the Controller: to delete all letters or numbers.



For alphabetical lists with more than 30 entries, the letters for which entries exist can be displayed in a letter field.

- 1. Turn the Controller quickly to the left or right.
- Select the first letter of the desired entry.The first entry for the selected letter is displayed in the list.

# Operation by touchpad

#### General

Depending on the equipment, some iDrive functions can be operated with the touchpad of the controller.

### Selecting functions

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "System settings"
- 4. "Touchpad"
- 5. Select the desired setting.

### Entering letters and numbers

- ▶ Enter characters as they are displayed on the control display.
- Always enter associated characters, for example accents or dots, so that the letter can be clearly identified.
- ➤ The input options depend on the set language. You may need to enter special characters using the Controller.
  - Set system language, see page 59.

#### Entering special characters

Function	Operation
Delete a character.	Swipe to the left on the touchpad.
To enter a space.	From the centre of the touchpad, swipe to the right.
To enter a hyphen.	At the top of the touchpad, swipe to the right.
To enter an underscore.	At the bottom of the touchpad, swipe to the right.

## Using the map

The navigation system's map can be moved using the touchpad.

Tap the map on the control display and then continue the operation using the touchpad.

Function	Operation
To move the map.	Swipe in the appropriate direction.
To display the menu.	Tap once.

#### Using alphabetical lists

Alphabetical lists with more than 30 entries permit a direct jump to letters for which an entry exists.

Enter the first letter on the touchpad.

The first entry of the entered letter is displayed in the list.

# Operation via control display

#### General

Depending on the equipment, the control display may be equipped with a touchscreen.





It is possible to tap on menu items and widgets. Touch the control display with your fingers. Do not use any objects.

## Going to the main menu

▲ Tap the icon.

The main menu is displayed.

### Adapting widgets

You can adapt the widgets in the main menu. It is only possible to make adaptations with the vehicle at a standstill.

- 2. Press and hold the widget.
- 3. Make the desired adjustment:
  - → Tap the icon.
    A new widget can be selected.
  - ➤ Tap the icon. The widget is deleted.
  - Press and hold the widget and drag to the left or right.

The widget is moved to the desired position.

### Sorting apps

To sort the app icons again, press and hold the desired icon and move it to the desired location.

#### Go to Context menu

Depending on the menu item, a context menu with additional options can be displayed.

Press and hold the desired menu item.

The menu consists of various areas, such as:

- "General help": call up the Integrated Owner's Handbook.
- "Add to shortcuts": define menu item as shortcut.

### Entering letters and numbers

#### Digit input

- 1. If necessary, tap the 🟋 icon or control display.
- 2. Enter the required letters and numbers.

#### Delete the input.

#### Icon Function

- Tap icon: to delete a letter or number.
- Press and hold the icon: delete all letters or numbers.

#### Using the map

The navigation map can be moved on the control display.

Function	Operation
To move the map.	Swipe in the appropriate direction.
To zoom in/out on the map.	Pinch together or move apart your fingers.
To display the menu.	Tap once.

## Using alphabetical lists

For alphabetical lists with more than 30 entries, the letters for which entries exist can be displayed in a letter field.

- Tap the letter in front of the list.
   A letter box is displayed.
- Tap the first letter of the desired entry.The first entry for the selected letter is displayed in the list.



#### Principle

The BMW Intelligent Personal Assistant is a personal assistant that enables natural voice control of various vehicle functions. The Personal Assistant simplifies the operation of the vehicle with the automation of processes and routines.

#### General

- BMW Intelligent Personal Assistant is available depending on the national-market version.
- The system includes special microphones on the driver's side and the passenger's side.
- Say commands at a normal volume.
   Speaking directly into the microphone does not improve speech recognition.
- Commands and numbers should be spoken fluently, with the usual emphasis and at a normal volume and speed.
- > ....< identifies commands that can be spoken.

## Operating requirements

- A system language that is supported by the Personal Assistant must be set via iDrive.
   Set system language, see page 59.
- ▶ Always say commands in the configured system language.

For the full range of functions, the following functions should be activated, set or booked:

- ▶ Online speech processing, see page 59.
- All settings under
   Data protection, see page 67.
- ▶ Activation word, see page 57.

- ▶ BMW ID or a driver profile.
- ▶ Relevant ConnectedDrive Services via the ConnectedDrive Store.

## Activating voice input

#### General

Voice input can be activated in various ways:



Press the button on the steering wheel briefly.

The microphone on the driver's side is active.

▶ Say the activation word.

The microphones on the driver's or front passenger's side are active with the following voice control, depending on where the activation word was spoken.

Then say the command. The activation word and the command can be spoken without pause in one sentence.

#### Microphone button on steering wheel



Press the button briefly.

2. Say the command.

#### **Activation word**

#### General

Saying the activation word starts the Personal Assistant. The Personal Assistant listens.

#### Preset activation word

The preset activation word >Hello BMW< can be activated and deactivated.

- 1. "MFNU"
- 2. "Vehicle apps"
- 3. "System settings"
- 4. "Voice control"



- 1
- 5. "Personal Assistant (BMW)"
- 6. "Activation word"
- 7. ""Hello BMW""

#### Personal activation word

In addition to the preset activation word, a personal activation word can be set up with an active BMW ID or a driver profile. The personal activation word can also be changed or deleted.

The activation word should consist of multiple syllables to ensure good detection. An addition, such as >Hello< is not necessary.

- "MENU"
- 2. "Vehicle apps"
- 3. "System settings"
- 4. "Voice control"
- 5. "Personal Assistant (BMW)"
- 6. "Activation word"
- 7. "Personal activation word"
- 8. "Set"
- 9. "Start recording"

#### Activation word from third-party providers

Depending on the national-market version, some third-party providers offer digital voice assistants, e.g. Siri or Amazon Alexa.

In order to use Siri, the smartphone must be connected via Apple CarPlay.

Supported voice assistants can be used with a connected smartphone in the vehicle. In addition to the preset or personal activation word, the activation word of voice assistants from connected third-party providers can be used.

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "System settings"
- 4. "Voice control"
- 5. Select the desired voice assistant.
- 6. Select the desired setting.

## Cancelling voice input



Press the button on the steering wheel again.

- ▶ >Cancek
- Slide the Controller to the right or left.
- Press the Controller.

#### Possible commands

#### General

Commands can be used to give instructions or ask questions where the Personal Assistant provides support.

For example, it is possible to call contacts, navigate to an address, make settings or ask questions about the vehicle function.


Most of the contents on the control display, for example menu items and list entries, can be said as commands.

## Help for voice control

- > Voice commands; Sample commands: to have voice command options read aloud.
- > General information on voice controls: have information on the operating principle of the voice control announced.
- > Help«: have tips and example commands for voice control announced.
- Additional example commands for the current context are displayed in the widget of the BMW Intelligent Personal Assistant.

### Sample commands

- > Call John Smith
- > Drive me to Heathrow airport<
- ▶ →Play a classical music station
- > Is my tyre pressure still okay?<
- >Activate climate control
- >Increase the ACC distance



For further information:

Adapting widgets, see page 55.

#### Menu items

Say the commands of the menu items as they are selected via the control display.

- 1. Activate the voice input.
- Media
- Saved stations
   The saved stations are displayed on the control display.

#### Owner's Handbook by voice control

It is possible to ask simple questions about the vehicle functions and about operating the vehicle.

The voice control system and the feedback it provides are not a substitute for the printed or Integrated Owner's Handbook. The function is available depending on the national-market version. The speech recognition function and the quality of the feedback may vary.

>How do you disable the front passenger airbag?<

The Personal Assistant gives a response. Where applicable, the section of the Integrated Owner's Handbook is displayed on the control display if the vehicle is at standstill.

### Settings

### Setting the system language

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "System settings"
- 4. "Language"
- 5. Select the desired setting.

## Setting the response length

You can set the Personal Assistant to use the standard dialogue or a short version. In case of the short version, the announcements by the Personal Assistant are played back in an abbreviated version.

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "System settings"
- 4. "Voice control"
- 5. "Personal Assistant (BMW)"
- 6. "Response length"
- 7. Select the desired setting.

#### Saying during voice output

It is possible to answer during inquiries of the Personal Assistant. The function can be deactivated if the feedback is frequently cancelled inadvertently, for example due to background noise or conversations in the vehicle.

- 1. "MFNU"
- 2. "Vehicle apps"
- 3. "System settings"
- 4. "Voice control"
- 5. "Personal Assistant (BMW)"
- 6. "Speaking during voice output"

## Online speech processing

Online speech processing improves the quality of the speech recognition and search results for points of interest. To use the function, data is sent across an encrypted connection to a service provider where it is delete stored. An active ConnectedDrive contract is required for online speech processing. ConnectedDrive is available depending on the national-market version.

- 1. "MFNU"
- 2. "Vehicle apps"
- 3. "System settings"



- 1
- 4. "Voice control"
- 5. "Personal Assistant (BMW)"
- 6. "Online speech processing"

# Voice control from third-party providers

Depending on the equipment, third-party voice control can be activated by pressing and holding the microphone button on the steering wheel.

- "MENU"
- 2. "Vehicle apps"
- 3. "System settings"
- 4. "Voice control"
- 5. "Long press"
- 6. Select the desired setting.

#### Adjusting the volume

Turn the volume control button during the spoken instructions until the desired volume is obtained.

The volume setting is retained even if you change the volume of other audio sources.

# Using the voice control of the smartphone

Depending on the device, a smartphone connected to the vehicle can be operated via voice input.

The device must be connected via Apple Car-Play or Android Auto.

Press and hold the button on the steering wheel for approx. 3 seconds.
 The voice control of the smartphone is activated.

If activation is successful, a confirmation appears on the control display.

2. Press the button on the steering wheel to cancel the voice control of the smartphone.

### Automating habits

#### General

The Personal Assistant can automate routines, for example, the automatic opening of windows at the same place. This involves creating rules that can be activated and deactivated at any time.

#### Activating/deactivating routines

- 1. "MENU"
- 2. "All apps"
- 3. "Automate habits"
- 4. Select the desired setting.

### System limits

- The Personal Assistant provides information about vehicle functions that may not be installed in the vehicle.
  - This also applies to safety-relevant functions and systems.
- Certain noises may be detected and could cause problems. Keep doors and windows closed.
- Noises from the front passenger or other passengers can impair the system. Avoid background noise in the vehicle while you are speaking.
- Strong dialects may prevent speech recognition from working properly.
- A poor data connection influences the response time of the Personal Assistant and the Search.



#### Principle

The vehicle offers various types of connections for using mobile devices. Which connection type to select depends on the mobile device and the function you wish to use.

#### General

Detailed information on functions and connection types can be found in the following media from the Owner's Handbook under the specified keyword:

- Integrated Owner's Handbook in the vehicle.
- ▶ Printed Owner's Handbook for Navigation, Communication, and Entertainment.
- ▶ Driver's Guide app.
- Driver's Guide Web.

## Safety information

## $\Lambda$

#### MARNING

Operating integrated information systems and communication devices during a journey may distract you from the traffic situation. You could lose control of the vehicle. There is a risk of accident. Only operate the systems or devices if the traffic situation allows you to do so. Stop if necessary and operate the systems or devices with the vehicle at a standstill.

#### Overview

The following list shows possible functions and the appropriate connection types for them. The range of functions depends on the vehicle equipment and the mobile device.

Function	Connection type	lcon on the con- trol display
Making calls using the hands-free system.	Bluetooth. Keyword: Bluetooth connection.	`
Operating telephone functions via iDrive.		
Keyword: calling via Bluetooth.		
Playing music from a USB device.	Bluetooth audio.	IJ ∰
Keyword: audio.	Keyword: Bluetooth connection.	
Calling without a mobile phone.	Personal eSIM.	91
Keyword: calling with Personal eSIM.	Keyword: Personal eSIM.	`
Data exchange between mobile de-	WiFi.	<u>((:</u>
vice and vehicle.	Keyword: vehicle WiFi.	
Use Internet access via the personal	WiFi via personal hotspot.	(î:
hotspot.	Keyword: personal hotspot.	

Function	Connection type	lcon on the con- trol display
Operate Apple CarPlay via iDrive and by voice commands. Keyword: Apple CarPlay preparation.	Bluetooth and WiFi. Keyword: Bluetooth connection and vehicle WiFi.	E
Operate Android Auto via iDrive and by voice control.  Keyword: Android Auto preparation.	Bluetooth and WiFi. Keyword: Bluetooth connection and vehicle WiFi.	<b>A</b>
Playing music from a USB device. Keyword: audio.	USB. Keyword: USB connection. For further information: USB port, see page 250.	ħι

# BMW Remote Software Upgrade

# Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

# **BMW Remote Software** Upgrade

#### Principle

Remote Software Upgrade can be used to update the entire software of the vehicle. This makes new functions, functional enhancements or quality improvements available.

#### General

BMW recommends carrying out the Remote Software Upgrade as soon as it becomes available.

## Safety information

#### MARNING

Unsupervised children or pets in the vehicle can set the vehicle in motion and endanger themselves or other road users, for example by the following actions:

- ▶ Pressing the Start/Stop button.
- > Releasing the parking brake.
- > Opening and closing doors or windows.
- ▶ Engaging selector lever position N.
- > Operating vehicle equipment.

There is a risk of accident or injury. Do not leave children or pets unsupervised in the vehicle. When leaving the vehicle, take the vehicle key with you and lock the vehicle.

#### Operating requirements

- Active ConnectedDrive contract.
- ▶ The integrated SIM card in the vehicle has been activated.
- Mobile reception.
- > A consent for the transmission of the corresponding data was given in the Data Protection menu.

For further information:

Data protection, see page 67.

#### Search for an upgrade

#### Operating requirements

The standby state must be turned on to search for a Remote Software Upgrade.

#### Automatic search

The vehicle regularly searches for updates in the background.

#### Manual search

- 1. "MENU"
- 2. "All apps"
- 3. "System settings"
- 4. "Remote Software Upgrade"
- 5. "Search for upgrades"
- 6. Follow the instructions on the control displav.



## Download of an upgrade

#### Automatic download

If available, the data for a Remote Software Upgrade is automatically downloaded to the vehicle. No consent to download is required.

#### Via BMW app

If an upgrade is available, information about the new software version is displayed in the BMW app.

The data for the upgrade can then be downloaded to a mobile device, for example via an existing Wi-Fi connection.

The data can then be transferred from the mobile device to the vehicle.

This transmission method accelerates the download of the data, for example in areas with limited mobile network availability.

- 1. Download the upgrade in the BMW app to the smartphone.
- 2. Follow the instructions in the BMW app.
- 3. Establish the connection to the vehicle.
  - > iOS: connect Bluetooth audio and WiFi.
  - Android: connect Bluetooth® audio and WiFi.

The data transfer of the upgrade from the mobile device to the vehicle occurs in the background only while driving.

Follow the instructions on the control display.

For further information:

For information on connecting mobile devices with the vehicle, see Owner's Handbook for Navigation, Entertainment, Communication.

#### Release notes

#### General

The release notes describe the updates included in the Remote Software Upgrade. The ver-

sion information can be shown on the control display while downloading and following successful completion of the installation.

This information is also available in the Connected Drive customer portal.

#### Displaying information

Display in the vehicle:

- "MENU"
- 2. "All apps"
- 3. "System settings"
- 4. "Remote Software Upgrade"
- Display currently installed version:
   "Installed version:"
  - Display new available version:"Info on version"
- Follow the instructions on the control display.

Display in the ConnectedDrive customer portal on the Internet:

www.hmw-connecteddrive.com.

## Installing the upgrade

#### General

- Installing the remote software upgrade may cause software modifications not made by the vehicle manufacturer to be deleted, such as increases in performance.
- Modifications to the on-board power supply of the vehicle, for example to control units that have not been made by the manufacturer of the vehicle, can cause the installation to malfunction
- ▶ The installation does not occur until the consent was given.
- ▶ Installation can take around 20 minutes.
- Installation cannot be interrupted.

- The vehicle cannot be used during installation.
- You may leave the vehicle during installation.

#### Prerequisites for the installation

- ▶ The vehicle battery is sufficiently charged.
- $\triangleright$  The outside temperature is above -10 °C, 14 °F.
- ▶ The vehicle is parked on level ground.
- ▶ The hazard warning lights are switched off.
- ▶ The selector lever position P is engaged.
- ➤ The engine is turned off and sufficiently cooled down.

If applicable, follow the notes for further prerequisites on the control display.

If the prerequisites are not met, for example a sufficient vehicle battery charge state, the upgrade will not be offered for installation.

Look out for an offer to install, for example after driving for a long period.

#### Preparing the vehicle

- Park the vehicle safely away from the public road.
- Cellular network reception must be ensured so that a fault message can be sent to the vehicle manufacturer, for example if the installation is terminated.
- Close the windows.
- ▶ Close the glass sunroof.
- Closing the luggage compartment
- ▶ Remove devices that consume energy, for example mobile phone.
- Disconnect the trailer or load carrier.
- ➤ The vehicle key must be located in the vehicle for the consent for installation.
- ▶ Switch off the exterior lights.
- ▶ Remove the devices connected to the socket for on-board diagnosis.

#### Install immediately

The upgrade can be installed immediately when all prerequisites have been met.

- 1. "MENU"
- 2. "All apps"
- 3. "System settings"
- 4. "Remote Software Upgrade"
- 5. "Start upgrade now"
- Follow the instructions on the control display.

#### Installing with timer

At the end of the journey, a timer can be used to install the upgrade automatically at a configured time, for example, during the night. It may make sense to install later to meet functional requirements, such as a sufficiently cooled enaine.

- 1. "MENU"
- 2. "All apps"
- 3. "System settings"
- 4. "Remote Software Upgrade"
- 5. Select the desired settings.

The installation starts automatically when:

- ➤ All prerequisites for the installation have been established correctly.
- All prerequisites continue to be met at the time of installation.

The timer is turned off when the drive-ready state is turned on.

#### **Functional limitations**

During the upgrade, many of the functions are temporarily unavailable, for example:

- Hazard warning lights.
- ▶ Central locking system and, if necessary, Comfort Access.
- Side lights.
- ▶ Horn.





- ▶ Alarm system.
- Emergency call.
- Window lifters.
- ▶ Glass sunroof.
- ▶ Fuel filler flap lock.
- Operating the tailgate or boot lid.

The driver's door can be unlocked and locked from outside with the integrated key.

## After successful upgrade

The vehicle can be used again immediately.

Purchased services, e.g. Real Time Traffic Information or Remote Services, are automatically reactivated during your next drive.

After an extended stationary period, charge the vehicle battery with an extended drive.

#### Malfunction

In the event of a malfunction, follow the instructions on the control display or in the BMW app.

If the malfunction cannot be rectified, contact a Service Partner of the manufacturer, or another qualified Service Partner, or a specialist workshop.

### Validity of Owner's Handbook

### Vehicle production

When the vehicle leaves the factory, the contents of the printed Owner's Handbook are up to date.

### After a software update in the vehicle

After a vehicle software update, for example, via Remote Software Upgrade, the Integrated Owner's Handbook for the vehicle will contain the latest information.

# Personal settings

## Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

# Data protection

#### Data transfer

#### Principle

The vehicle offers various services which require data to be transferred to BMW or a service provider.

#### General

Data transfer can be deactivated for some services. If data transfer has been deactivated for a service, then that service cannot be used.

#### Settings

Data transfer can be configured individually in various stages or for individual services.

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "System settings"
- 4. "Data privacy"
- 5. Select the desired setting.

## Deleting personal data in the vehicle

### Principle

Depending on use, the vehicle stores personal data such as saved radio stations. This per-

sonal data can be permanently deleted using iDrive.

#### General

Depending on the equipment, the following data is deleted:

- ▶ BMW IDs or driver profiles.
- Saved radio stations.
- Stored shortcuts.
- Navigation, for example saved destinations.
- Phone book.
- Online data, for example favourites, cookies.
- Office data, for example voice memos.
- ▶ Login accounts.
- Digital keys.

It may take up to 15 minutes in total to delete data. The vehicle is also removed from the BMW app and the ConnectedDrive customer portal so that remote functions can no longer be used.

#### Operating requirements

- Data can only be deleted with the vehicle at a standstill.
- ▶ The vehicle key must be in the vehicle.

## Deleting data

Personal data in the vehicle is deleted when the vehicle is reset to its factory settings.

For further information:

Reset vehicle data, see page 68.





# Resetting vehicle data

All individual settings can be reset to the factory settings when drive-ready state is switched off. The vehicle key must be in the vehicle.

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "System settings"
- 4. "Reset vehicle data"
- 5. "Reset vehicle data"

If synchronisation of settings has been activated for a BMW ID in the vehicle, the personal settings are retained in the BMW Cloud.

# BMW ID/driver profiles

#### Principle

In ConnectedDrive countries, the BMW ID is the personal login for all relevant offers for the BMW brand. The BMW ID can be used in the vehicle to store and activate personal vehicle settings.

In non-ConnectedDrive countries, the personal vehicle settings can be stored in driver profiles.

#### General

The BMW ID must be registered once. A BMW ID can be registered via the BMW app, in the ConnectedDrive Portal or at the Service Partner.

A driver profile is created in the vehicle.

If a vehicle is used by several people, each person can create their own BMW ID or driver profile in order to save their personal settings.

If a BMW ID or a driver profile is activated, the settings stored therein are applied to the vehicle.

Many of the settings that are stored for a BMW ID in the vehicle can be synchronised with the

BMW Cloud. This makes these settings available in any vehicle where the same BMW ID is used to log in.

The vehicle can store three BMW IDs or three driver profiles.

Activation of a BMW ID or a driver profile can already take place when unlocking. For this purpose, the driver recognition via a vehicle key or a digital key must be assigned to the BMW ID or the driver profile.

If no BMW ID or driver profile is activated when the vehicle is unlocked, the vehicle is in the quest profile.

### Operating requirements


When a BMW ID or driver profile is created, changed, deleted or edited, the vehicle must move no faster than at walking speed.

The login in the vehicle with a BMW ID and synchronisation with the BMW Cloud are only possible when the vehicle has cellular network reception.

#### Welcome window

After unlocking the vehicle, a Welcome window is shown on the control display. The type of the welcome depends on the following prerequisite:

- ▶ The vehicle does not have a stored BMW ID or driver profile:
  - The welcome is neutral. An option to add a BMW ID or create a driver profile is offered.
- The vehicle key or the digital key has not been assigned to a BMW ID or a driver profile:
  - The welcome is neutral. The stored BMW IDs or the stored driver profiles are offered for selection. Additionally, it is possible to add a new BMW ID or create a new driver profile.
- A BMW ID or a driver profile has not been assigned to the vehicle key or the digital key:



As soon as the drive-ready state is turned on or the control display is tapped outside of the welcome window, the welcome will be hidden.

### Registering a BMW ID

The following steps must be carried out in order to use a BMW ID:

- ▶ Register the BMW ID.
- Activate your personal ConnectedDrive account.
- Add or confirm the BMW ID in the vehicle. Registration of the BMW ID via the BMW app can be started in the vehicle.
- 2. "Add BMW ID"
- 3. "Register now"
- 4. Scan the QR code shown in the display.
  The BMW ID is created on the smartphone.

Alternatively, the BMW ID can be registered by the Service Partner and added to the vehicle. The BMW ID must then be confirmed on the control display of the corresponding vehicle.

#### Adding the BMW ID

An existing BMW ID can be added to the vehicle:

- 1. 2 Tap the icon or personal picture in the status bar.
- 2. "Add BMW ID"
- 3. ▶ "Log in with My BMW App"
  - ▶ "Log in with BMW ID"

- Scan the QR code shown in the display.
   The BMW ID is copied from the BMW app.
  - ▶ Enter the login data of the BMW ID.
- 5. Depending on the national-market version, the following settings can be selected:
  - "Settings from BMW Cloud" The settings stored in the BMW Cloud are applied.
  - "Current settings"
    If the vehicle is using the guest profile, the settings of the guest profile will be applied.
  - ▶ "Continue"

The vehicle is added to the user's BMW app.

#### Confirming the BMW ID

If the BMW ID has been created by the Service Partner and added to the vehicle, the BMW ID must then be confirmed in the vehicle:

- 1. Select the BMW ID.
- 2. Select the desired confirmation:
  - ▶ Scan the displayed QR code with the BMW app.
  - ▶ Enter the password of the BMW ID.

#### BMW app

If a BMW ID has been added to a vehicle, the vehicle is automatically added to the BMW app. This means that functions of the BMW app can be used for this vehicle. This requires the BMW app to be used with the same BMW ID.

Alternatively, a vehicle can be added to the BMW app by the Service Partner. In this case, the BMW ID must then be confirmed on the control display of the corresponding vehicle.

In rare cases, the use of BMW app functions for this vehicle may be restricted. A further note is shown on the control display.



## 1

### Creating a driver profile

- 2 Tap the icon or personal picture in the status bar.
- 2. "Add driver profile"
- 3. Enter the name for the driver profile.
- 4. Select the desired setting:

"Current settings"

If the vehicle is using the guest profile, the settings of the guest profile will be applied.

#### Main user

The main user is the person who first enters their BMW ID into the vehicle and the vehicle into the BMW app. Alternatively, the main user can be defined by the Service Partner.

The main user has access to the following settings, for example:

- ▶ Remove BMW IDs stored in the vehicle.
- Transfer the role of the main user to another BMW ID.
- ▶ Make vehicle-wide privacy settings.
- ▶ Creation of the digital master key.

For further information:

BMW Digital Key, see page 84.

## Specify the driver detection

A driver detection and a PIN can be set up for a BMW ID or a driver profile.

The driver detection offers the following advantages:

- ▶ The BMW ID or the driver profile with the saved settings is automatically activated.
- The settings are not accessible to other persons.

The driver detection is specified immediately following the addition of the BMW ID or after creating the driver profile.

Prior to the selection of the driver detection, a PIN must be created.

▶ "Set PIN"

The PIN can be used to activate the BMW ID or the driver profile, even if the assigned vehicle key or the assigned digital key is not available.

▶ "Vehicle key"

The vehicle key that is recognised in the vehicle interior is assigned to the BMW ID or the driver profile.

▶ "Digital Key"

The digital key that is recognised in the vehicle interior is assigned to the BMW ID or the driver profile.


## Automatic driver recognition

If driver recognition has been defined, automatic activation of the BMW ID or driver profile is triggered by the following activities:

- ▶ By unlocking the vehicle using the assigned vehicle key button.
- By unlocking the vehicle using an outside door handle. The assigned vehicle key or the assigned digital key must be carried.
- ▶ By automatic unlocking when approaching the vehicle. The assigned vehicle key or the assigned digital key must be carried. Depending on the national-market version, it may not be possible to recognise the digital key.

If there are several vehicle keys or digital keys in the vicinity of the vehicle, the activation of the BMW ID or the driver profile takes place according to the following priority:

- ➤ The key that unlocks the vehicle triggers the activation of the assigned BMW ID or the assigned driver profile.
  - The guest profile is activated when the vehicle is unlocked using a key that is not assigned to a BMW ID or driver profile.
- If a vehicle key and a digital key are detected at the same time, the digital key trig-



If another key is detected on the driver's door after activating the BMW ID or the driver profile, the BMW ID or the driver profile of the last key detected is activated. If no BMW ID and no driver profile are assigned to this key, the guest profile is activated.

## Synchronisation of settings

If synchronisation is switched on, settings are continuously synchronised from the following areas, for example:

- ▶ BMW ID, e.g. profile picture.
- Navigation, e.g. last destinations, home address or map settings.
- Media, e.g. favourites or stored radio stations.
- ▶ iDrive, e.g. main menu configuration, language or units.
- Personal assistant, e.g. suggestions or activation word.
- Exterior lights, e.g. one-touch signalling and home lights.

Settings from the following areas are only synchronised when you log in for the first time:

- Seating and climate comfort, e.g. driver's seat position or temperature setting.
- Privacy menu.

## Selecting the BMW ID/driver profile

If it was not possible to recognise the BMW ID or driver profile when unlocking the vehicle, the BMW ID or driver profile is selected on the welcome window.

The BMW ID or driver profile can be changed at any time via iDrive:

- 1. 2 Tap the icon or personal picture in the status bar.
- 2. ▶ "Change BMW ID"
  - "Change driver profile"
- 3. Select the BMW ID or driver profile.
- 4. If necessary, enter the PIN.

The BMW ID or the driver profile are activated, the stored settings are loaded.

#### Guest profile

The guest profile can be activated and changed by anyone.

The guest profile is automatically active in the following cases:

- ▶ A BMW ID has not yet been added or a driver profile has not yet been created.
- No BMW ID or driver profile has been assigned to the vehicle key or the digital key that was used to unlock the vehicle.

The following limitations apply to the guest profile:

- Selected functions that process personal data are not available in the guest profile. This includes functions of the navigation and the saving of favourites. More information on data processing is available in the ConnectedDrive data protection notes / service descriptions.
- ▶ The guest profile cannot be renamed.
- ▶ It is not possible to assign a PIN to the guest profile.
- ▶ It is not possible to assign a driver detection to the guest profile.
- ▶ In ConnectedDrive countries, the synchronisation with the BMW Cloud is not possible.





The guest profile is selected in the welcome window or via iDrive:

- 1. 2 Tap the icon or personal picture in the status bar.
- 2. ▶ "Change BMW ID"
  - "Change driver profile"
- 3. "Continue as guest"

### Deleting the BMW ID/driver profile

- 1. 2 Tap the icon or personal picture in the status bar.
- 2. ▷ "Change BMW ID"
  - "Change driver profile"
- 3. Tap the icon of the desired BMW ID or the desired driver profile.

Removing a BMW ID from the vehicle causes the vehicle to be removed from the BMW app. If the BMW ID has been synchronised with the BMW Cloud, the data stored in the BMW Cloud is retained after the BMW ID is deleted. If the currently active BMW ID is removed, the guest profile is activated.

Removing a vehicle from the BMW app removes the corresponding BMW ID from the vehicle. If the BMW ID was synchronised with the BMW Cloud, the BMW ID data stored on the BMW Cloud will be retained.

If the vehicle is removed from the main user's BMW app, it will also be removed from the other users' BMW apps. The corresponding BMW IDs are removed from the vehicle.

If the vehicle is reset to the factory settings, the vehicle is removed from all users' BMW apps and all BMW IDs are removed from the vehicle.

## Transfer of the vehicle key

A vehicle key that is assigned to a BMW ID or a driver profile can be used to view or change the stored personal settings.

Before a vehicle key is transferred to other persons, any assigned driver detection should be cancelled. Changes to the driver detection can

be made in the settings of the BMW ID or the driver profile.

The BMW Digital Key provides the option to transfer a digital key to permit other persons the use of your own vehicle.

For further information:

BMW Digital Key, see page 84.

### Settings

#### General

Settings added when adding a BMW ID or creating a driver profile can be changed.

- 1. 2 Tap the icon or personal picture in the status bar.
- 2. "Settings"

The following settings are available for the RMW ID:

- ▶ The type of driver detection.
- ▶ The profile picture.
- ▶ The synchronisation with the BMW Cloud.
- > The personal salutation.

The following settings are available for the driver profile:

- ▶ The type of driver detection.
- ▶ The profile picture.
- ▶ The profile name.

### Selecting a profile picture

The profile picture can be selected from the predefined profile pictures.

- 1. 2 Tap the icon or personal picture in the status bar.
- 2. "Settings"
- 3. "Manage profile picture"
- 4. "Select profile picture"

For a BMW ID, the personal profile picture can be taken from the profile in the BMW app.
This requires that the synchronisation with the BMW Cloud is activated in the settings. After

the profile picture from the BMW app has been applied, a selection from the predefined pictures is only possible if the profile picture in the BMW app is deleted or synchronisation is deactivated.

# System limits

A clear driver detection via the vehicle key or the digital key may not always be possible, for example in the following cases:

- ▶ If there is a change of driver without the vehicle being locked and unlocked.
- When multiple vehicle keys or multiple digital keys with an assigned BMW ID or driver profile are located in the outer area on the driver's side of the vehicle.
- ▶ When the vehicle was unlocked from the BMW app.

The use of personal settings that are stored for a BMW ID in other vehicles is subject to technical limitations. For example, there may be stored settings for a system that is not available in other vehicles, or only in an incompatible version.



# Opening and closing

# Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

# Vehicle key

#### General

The delivery specification includes two vehicle keys, each containing an integrated key.

Each vehicle key contains a replaceable batterv.

Depending on vehicle equipment and nationalmarket version, various settings are possible for the button functions.

A BMW ID or a driver profile with personal settings can be assigned to a vehicle key.

To provide information on maintenance requirement, the service data is saved in the vehicle key.

To prevent the vehicle key from being locked in, take it with you whenever you leave the vehicle.

## Safety information



#### MARNING

The vehicle key has a button cell battery. Batteries or button cells can be swallowed and lead to serious or fatal injuries within two hours, for example due to internal burns or chemical burns. There is a danger of injury or danger to life. Keep the vehicle key and batteries out of reach of children. Immediately

seek medical help if there is any suspicion that a battery or button cell has been swallowed or is located in any part of the body.

#### Overview



Buttons on the vehicle key.

#### Meaning lcon



Unlock.



Lock.



Unlock the luggage compartment.




Home lights, see page 162.

#### Additional vehicle keys

Additional vehicle keys are available from a Service Partner of the manufacturer or another aualified Service Partner or a specialist workshop.

# Loss of vehicle keys

A lost vehicle key can be disabled and replaced by a Service Partner of the manufac-



If a BMW ID or driver profile has been assigned to the lost vehicle key, the connection to this vehicle key must be deleted. A new vehicle key can then be assigned to the BMW ID or driver profile.

#### Replacing the battery



#### MOTICE

Unsuitable batteries in a battery-operated device can damage the device. There is a risk of material damage. Always replace the discharged battery with a battery with the same voltage, the same size and the same specification.

- 1. Remove the integrated key from the vehicle key.
- 2. Position the integrated key under the battery compartment lid, arrow 1, and pry off the lid by moving the lever of the integrated key, arrow 2.



3. Use a pointed object to press the battery in the direction of the arrow and lift it out.



- 4. Insert a type CR 2032 3V battery with the positive terminal facing up.
- 5. Press the cover back into position and close
- 6. Insert the integrated key into the vehicle key until the integrated key engages.



Dispose of old batteries with a Service Partner of the manufacturer, another aualified Service Partner or a specialist

workshop, or hand them in to an authorised collection point.

## Integrated key

#### General

The integrated key enables the vehicle to be unlocked without the vehicle key.

Depending on the national-market version, the integrated key fits the glove compartment.

Depending on the model and equipment, the key switch for the front passenger airbag can be operated with the integrated key.

## Safety information



#### ↑ WARNING

With some national-market versions, unlocking from the inside requires specific knowledge.





There is a danger of injury or danger to life if persons remain in the vehicle for extended periods and are exposed to extreme temperatures as a result. Do not lock the vehicle from the outside when there is someone inside it.

#### Removing the integrated key

1. Press the button, arrow 1, and pull out the integrated key, arrow 2.




2. Pull off frame from integrated key.



# Unlocking via the door lock

1. Pull the door handle outwards with one hand and hold it.



Unlock the door lock by turning it anti-clockwise using the integrated key.



The other doors must be unlocked from the inside.


#### Locking the vehicle from the interior

#### General

The vehicle can be locked manually from the inside.

To avoid locking the vehicle key in the vehicle, do not place the vehicle key into the vehicle.

#### Overview



Door pin for manual locking of the driver's door.

#### Locking the vehicle

- 1. Close the driver's door.
- 2. Press the door pin in the driver's door down from the inside.
- 3. Lock rear doors from the inside.
- 4. Open the front passenger door and lock it manually.
- 5. Close the front passenger door from the outside.

#### Alarm system

If the vehicle is unlocked with the integrated key via the door lock, the activated alarm system is triggered when the door is opened.

In this case, use the emergency detection of the vehicle key to switch off the alarm.

If the doors are manually locked from the inside, the alarm system is not activated.

# Emergency detection of the vehicle key



Drive-ready state cannot be switched on if the vehicle key is not detected.

If this happens, proceed as follows:

- Hold the rear side of the vehicle key against the mark on the steering column. Pay attention to the display in the instrument cluster.
- If the vehicle key is detected:
   Switch on drive-ready state within 10 seconds.
  - ▶ If the vehicle key is not detected: Slightly change the position of the vehicle key and repeat the procedure.

#### Malfunction

A Check Control message is shown where applicable.

It may be difficult for the vehicle to detect the vehicle key in some circumstances, including the following:

- ▶ The battery of the vehicle key is discharged.
- Disruption of the radio link by transmission masts or other equipment transmitting powerful signals.
- ➤ Shielding of the vehicle key by metallic objects.

Do not transport the vehicle key together with metallic objects.



- Disruption of the radio link by mobile phones or other electronic devices in the immediate vicinity of the vehicle key. Do not transport the vehicle key together
- with electronic devices. ▶ Interference with the radio transmission
- caused by the charging process of mobile devices, for example a mobile phone.
- ▶ The vehicle key is located in the immediate vicinity of the wireless charging tray. Place the vehicle key somewhere else.

If there is a malfunction, the vehicle can be unlocked and locked from the outside with the integrated key. Use the emergency detection of the vehicle key to turn on the drive-ready state.

# Access to vehicle interior

# Safety information



#### ↑ WARNING

Persons remaining in the vehicle or pets left inside can lock the doors from the inside and lock themselves in. In this case, the vehicle cannot be opened from the outside. There is a danger of injury. Carry the vehicle key with you so that you can open the vehicle from the outside.

#### ↑ WARNING

With some national-market versions, unlocking from the inside requires specific knowledge.

There is a danger of injury or danger to life if persons remain in the vehicle for extended periods and are exposed to extreme temperatures as a result. Do not lock the vehicle from the outside when there is someone inside it.

#### ↑ WARNING

Unsupervised children or pets in the vehicle can set the vehicle in motion and endanger themselves or other road users, for example by the following actions:

- Pressing the Start/Stop button.
- Releasing the parking brake.
- > Opening and closing doors or windows.
- ▶ Engaging selector lever position N.
- Operating vehicle equipment.

There is a risk of accident or injury. Do not leave children or pets unsupervised in the vehicle. When leaving the vehicle, take the vehicle kev with you and lock the vehicle.

# Actions during unlocking

Depending on the settings, the following functions are performed when unlocking the vehicle:

- ▶ Only the driver's door and the fuel filler flap will be unlocked or all access to the vehicle will be unlocked.
- ▶ The unlocking of the vehicle can be confirmed with a light signal or a sound signal.
- ▶ The welcome light can be turned on when the vehicle is being unlocked.
- ▶ After opening a vehicle door, the window can be lowered more to make it easier to enter the vehicle.

The following functions are also carried out:

- ▶ If a BMW ID or driver profile was assigned to the vehicle key, this BMW ID or driver profile will be activated.
- ▶ The interior lights are switched on unless they were switched off manually.
- Depending on the equipment, folded exterior mirrors are folded out.

If the exterior mirrors were folded in using the button inside the vehicle, they are not folded out when the vehicle is unlocked.

- ➤ The anti-theft security system is switched off.
- ▶ The alarm system is switched off.

For further information:

- ▶ For settings, see page 88.
- ▶ Welcome light, see page 162.
- ▶ BMW ID/driver profiles, see page 68.

#### Actions during locking

Depending on the settings, the following functions are performed when unlocking the vehicle:

- ➤ The locking of the vehicle can be confirmed with a light signal or a sound signal.
- Depending on the equipment, the exterior mirrors can be folded in automatically during locking. If the hazard warning lights are switched on, the exterior mirrors are not folded in.
- ▶ Home lights can be activated during locking.

The following functions are carried out:

- ➤ All the doors, the tailgate and fuel filler flap are locked.
- The anti-theft security system is switched on. This prevents the doors from being unlocked using the locking buttons or the door handles.
- ▶ The alarm system is switched on.

If drive-ready state is still switched on when locking, the vehicle horn sounds twice. If this happens, switch off drive-ready state using Start/Stop button.

For further information:

For settings, see page 88.

# With the vehicle key

#### Unlocking the vehicle



Press the button on the vehicle key.

If only the driver's door and the fuel filler flap have been unlocked because of the settings, press the button on the vehicle key again to unlock the other vehicle access points.

The vehicle is operational after one of the front doors is opened.

The lighting functions may depend on the ambient brightness.

#### Comfort entry



Press the button on the vehicle key twice in immediate succession to activate comfort entry.

Depending on the settings, the window is lowered further when a door is opened.

# Locking the vehicle

1. Close the driver's door.



Press the button on the vehicle key.

#### On the outside door handle

## Principle

This feature allows you to access the vehicle without having to use the vehicle key.

The vehicle key is automatically detected near the vehicle.

#### General

The function is available with Comfort Access.






#### Operating requirements

- ▶ Carry the vehicle key with you, for example, in your pants pocket.
- To lock the vehicle, the vehicle key must be located outside the vehicle in the vicinity of the doors.
- ▶ After locking, approx. 2 seconds must elapse before unlocking is possible.


#### Unlocking the vehicle



Reach into the handle recess of a door.

# Locking the vehicle

- 1. Close the driver's door.
- 2. Touch the grooved surface on the outside door handle of a closed door with your finger for approximately 1 second without reaching into the handle recess.



#### Malfunction

Wet or snowy conditions may disrupt the locking request detection on the outside door handles.

If a fault occurs, unlock and lock the vehicle with the buttons on the vehicle key or with the integrated key.

# Touchless unlocking/locking of the vehicle

#### Principle

The vehicle is unlocked when the driver approaches the locked vehicle with the vehicle key.

If the driver moves away from the unlocked vehicle with the vehicle key, the vehicle is locked.

#### General

The function is available with Comfort Access.

The vehicle is unlocked when an authorised vehicle key is detected in the unlocking zone.

The unlocking zone is located within a radius of approx. 1.50 m, 5 ft around the side and rear of the vehicle.

The vehicle is locked when the vehicle key leaves the locking zone.

The locking zone is located within a radius of approx. 3 m, 9 ft around the side and rear of the vehicle.

If the vehicle key remains within the unlocking zone without moving for a prolonged period of time, the vehicle is locked automatically.

If a person is detected on the front passenger seat when locking, and if the front passenger's seat belt is in the seat belt buckle when locking:

- ➤ The vehicle is locked, but not protected against theft.
- ▶ The fuel filler flap remains unlocked.

## Actions during unlocking

If the settings specify that only the driver's door and the fuel filler flap will be unlocked, note the following:

The driver's door and fuel filler flap will only be unlocked when the driver approaches the vehicle on the driver's side.

For further information:

For settings, see page 88.

#### Operating requirements

- Carry the vehicle key with you, for example, in your pants pocket.
- Unlocking: When entering the unlocking zone, the doors and luggage compartment must be closed.
- Locking: When leaving the locking zone, the doors and luggage compartment must be closed.
- ➤ Automatic unlocking and locking must be activated in the settings.
- Drive-ready state must be switched off.
- For contactless locking of the vehicle, no second vehicle key may be within a radius of 6 m, approx. 18 ft around the vehicle.
- If the vehicle has been in rest state for several days, contactless unlocking/locking is not possible until the vehicle has been driven.

For further information:

For settings, see page 88.

## With the Key Card

#### Principle

The Key Card is a chip card on which a digital key is installed. It can be used to unlock and lock the vehicle.

For further information:

Key Card, see page 83.

#### General

The Key Card is available with Comfort Access.

## Locking/unlocking the vehicle



Hold the activated Key Card directly and centrally up against the outside door handle on the driver's door.

When locking the vehicle with the Key Card, make sure that all doors and the luggage compartment are closed.

If the Key Card is not detected, slightly change the position of the Key Card and repeat the process.

#### With the BMW Digital Key

#### Principle

Depending on the national-market version and equipment, a digital key can be installed on a compatible smartphone and used to unlock and lock the vehicle.

For further information:

BMW Digital Key, see page 84.

#### Locking/unlocking the vehicle



Hold the NFC antenna on the smartphone directly and centrally up against the outside door





handle on the driver's door. The position of the NFC antenna will depend on the smartphone model.

When locking the vehicle with the smartphone, make sure that all doors and the luggage compartment are closed.

#### Frequently Asked Ouestions

What measures can be taken to enable a vehicle to be opened if the vehicle key has accidentally been locked inside the vehicle?

- ▶ The Remote Services of the BMW app can be used to lock and unlock a vehicle.
  - This requires an active BMW Connected-Drive contract and the BMW app must be installed on a smartphone.
- Unlocking of the vehicle can be requested via the BMW ConnectedDrive call centre.
  - This requires an active BMW Connected-Drive contract.

# Access to the luggage compartment

#### General

The luggage compartment may not open when the vehicle is in Valet Parking mode.

For further information:

Valet parking mode, see page 88.

# Safety information



#### ↑ WARNING

Parts of the body can become trapped when the boot lid is operated. There is a danger of injury. When opening and closing, make sure that the movement range of the boot lid is kept clear.

#### ∧ NOTICE

The boot lid swings rearwards and upwards when opened. There is a risk of material damage. When opening and closing, make sure that the movement range of the boot lid is kept clear.

## With the vehicle key

#### General

To prevent the vehicle key from being locked in, do not place it in the luggage compartment. Depending on the equipment and nationalmarket version, the following settings are possible:

- ▶ Whether the doors are also unlocked when the vehicle key is used to unlock.
- ▶ Whether the vehicle must be unlocked with the vehicle key before unlocking.

# Unlocking the luggage compartment



Press the button on the vehicle key for approximately 1 second.

## On the luggage compartment

#### General


With Comfort Access, the luggage compartment can be accessed without activating the vehicle kev.

The key is automatically detected near the vehicle.

## Functional prerequisite

Carry the vehicle key with you, for example, in your pants pocket.

# Opening the luggage compartment



- ▶ Unlock the vehicle and then press the button on the luggage compartment.
- ▶ With Comfort Access: carry the vehicle key with you and press the button on the luggage compartment.

Locked doors are not unlocked.

#### Closing the luggage compartment



Pull the luggage compartment down using the recessed handles.

#### In the interior

# Unlocking the luggage compartment



Press the button in the driver's door storage compartment.

#### Luggage compartment emergency release

The availability of the luggage compartment emergency release depends on the vehicle equipment.



Pull the handle in the luggage compartment. The luggage compartment is unlocked.

# **Key Card**

#### Principle

The Key Card can be used to lock, unlock and start the vehicle.

#### General

The availability of the Key Card depends on the vehicle equipment and country.

A digital key that has already been paired with the vehicle is installed on the Key Card. The digital key must be activated via iDrive.

When you exit the vehicle, deactivate the Key Card or take the Key Card with you, as it can be used to start the vehicle when activated. Always take the vehicle key with you to a service appointment.

# Safety information



#### ⚠ NOTICE

If the Key Card and a mobile device are in the wireless charging tray at the same time, the Key Card may be damaged. There is a risk of material damage. Do not place the Key Card in the wireless charging tray at the same time as a mobile device.





# Activating/deactivating the Key Card in the vehicle

#### General

To activate the Key Card, it must be in the smartphone tray and there must be a vehicle key in the vehicle.

To deactivate the Key Card, there must be a vehicle key in the vehicle.

If BMW Digital Key is enabled for the vehicle, a digital key can be used instead of the vehicle key.

A deactivated Key Card will remain in the list of registered digital keys.

#### Activating the Key Card



- 1. Open the cover of the smartphone tray.
- 2. Place the Key Card in the middle of the smartphone tray.
- 3. Follow instructions on the control display.

# Deactivating the Key Card

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Doors and windows"
- 4. "Key Card"
- 5. "Deactivate Key Card"

A deactivated Key Card will remain in the list of registered digital keys.

# Unlocking and locking the vehicle

The vehicle can be unlocked and locked with the activated Kev Card.

For further information:

Access to the vehicle interior, see page 78.

# Switching on drive-ready state



- 1. Open the cover of the smartphone tray.
- 2. Place the activated Key Card in the middle of the smartphone tray.
- 3. Press the Start/Stop button.

After turning on the drive-ready state, the Key Card can be taken out of the storage tray.

#### Malfunction

Objects between the sensors and the Key Card, for example a purse/wallet or smart-phone case, may prevent the vehicle from detecting the Key Card.

# **BMW** Digital Key

# Principle

BMW Digital Key allows you to use a compatible smartphone to lock, unlock and start the vehicle.

#### General

Availability and range of functions of the BMW Digital Key depend on the equipment and national-market version.

BMW Digital Key can be used with a compatible smartphone or other compatible end devices.

To unlock and start a vehicle with a compatible smartphone, this function must be offered by the smartphone manufacturer. The BMW app provides a check to determine if the smartphone and the vehicle are compatible and which functions are supported.

A BMW ID or a driver profile with individual settings can be assigned to a digital key.

When using a smartphone as a digital key, always carry a vehicle key or the activated Key Card with you too. This will mean that you can still access the vehicle even if the smartphone is not working. It is also useful to keep the vehicle key or Key Card on your person if the vehicle has to be handed over to another person. The vehicle key or Key Card can then be handed over, instead of the smartphone. Always take the vehicle key with you to a service appointment.

For further information:

- ▶ BMW ID/driver profiles, see page 68.
- www.bmw.com/digitalkey.

# Operating requirements

- ▶ The smartphone is compatible with BMW Digital Key.
- ➤ The vehicle is linked with the Connected-Drive account of the registered keeper.
- The smartphone battery is sufficiently charged. The minimum battery charge required depends on the smartphone in question.

# Enabling the main digital key

The registered keeper's smartphone is enabled as the main digital key in the vehicle. To do so, the registered keeper must provide proof of authorisation for their vehicle.

Proof of authorisation can be started via the BMW app or via the activation code in the cor-

responding smartphone function, for example in the Wallet app. Both vehicle keys must be in the vehicle during activation.

Follow the enabling instructions in the Digital Key menu within the BMW app or on the control display.

## Sharing digital keys

#### General

Digital Key enables digital keys to be shared with other people. This option is provided via the smartphone enabled as the main digital key. This function must be supported by the smartphone.

#### Passing on authorisation

To share the digital key, select the corresponding function on the smartphone, for example in the Wallet app.

As soon as a digital key is shared with a person, this person receives an invitation. If the invitation is accepted, the digital key is activated on the recipient's smartphone.

#### Limiting the range of functions

Certain functions of the digital key can be limited before handing it over. For example, restrictions on driving stability control systems can be suppressed and engine performance can be reduced before the digital key is given to a beginner driver. For more information, refer to the ConnectedDrive portal and the BMW app.

#### Authentication

Depending on the recipient's smartphone model, authentication may be required for security reasons.

An authorised vehicle key, the main digital key or another method can be used to perform the authentication. Corresponding information is displayed for your attention on the smartphone or control display.





# Deleting digital keys

#### General

Deleted digital keys are removed from the list of enabled digital keys.

Deleted digital keys cannot be restored.

#### Deleting the digital master key

The digital master key can be deleted from the smartphone or via iDrive.

The deletion of the digital master key is completed immediately.

#### Deleting a shared key

Shared keys can be deleted via the smartphone associated with the main digital key, via the smartphone associated with a shared key or in iDrive.

A shared key will only be deleted via the smartphone associated with the main digital key if the vehicle is being used with a key other than the one that is to be deleted.

If the smartphone associated with a shared key or iDrive is used to delete a shared key, it will be deleted immediately.

## Deletion in iDrive

To enable a digital key to be deleted in iDrive, there must be an authorised vehicle key in the vehicle or the main key must be in the smartphone tray.

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Doors and windows"
- 4. "Digital Key"
- 5. Select a digital key as necessary.
- 6. Delete the Digital Key.

## Resetting the function

To reset BMW Digital Key function, there must be an authorised vehicle key in the vehicle.

All digital keys, including the main key, are deleted when the BMW Digital Key function is reset. The digital key of the Key Card is not deleted.

Following the reset, it will no longer be possible to lock, unlock or start the vehicle with a digital key.

The main digital key must be enabled again in order to be able to use BMW Digital Key again.

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Doors and windows"
- 4. "Digital Key"
- 5. "Reset function"

# Unlocking and locking the vehicle

The vehicle can be unlocked and locked using the outside door handle.

For further information:

Access to the vehicle interior, see page 78.

# Switching on drive-ready state

#### Using the smartphone tray



- 1. Open the cover of the smartphone tray.
- 2. Place the smartphone in the middle of the smartphone tray.
  - Make sure that the display is pointing upwards.
- 3. Close the cover of the smartphone tray.
- 4. Press the Start/Stop button to turn on the drive-ready state.



Delete all digital keys from the smartphone before selling it. This ensures that the smartphone can no longer be used for the vehicle.

## Selling the vehicle

Before selling a vehicle, reset the digital key function or remove the vehicle from the ConnectedDrive account of the current registered keeper.

If the vehicle is removed from the Connected-Drive account, all digital keys for the vehicle are deleted. The digital key of the Key Card is not deleted.

## System limits

With a digital key, it is not possible to switch off the interior movement sensor and the tilt alarm sensor of the alarm system.

For further information:

Alarm system, see page 90.

#### Malfunction

It may be difficult for the vehicle to detect the digital key in some circumstances, including the following:

- ➤ The smartphone is shielded from the sensors in the vehicle by an unsuitable smartphone cover.
- ➤ There are objects between the smartphone and its cover, for example a card with a chip or the Key Card.
- ► Fault of the connection from transmission towers or other equipment with high transmitting power.
- ➤ Shielding of the smartphone due to buildings or metal objects.

# Central locking buttons

#### General

The vehicle is automatically locked when moving off.

If an accident of appropriate severity occurs, the vehicle is automatically unlocked. The hazard warning lights and interior lights are switched on.

#### Overview



The central locking system buttons are located on the front door.



Lock.



Unlock.

# Locking the vehicle



Press the button with the front doors closed.

Locking does not activate the vehicle's antitheft protection system.

# Unlocking the vehicle



Press the key.



# To open the door

rest.

Press the button to unlock all the doors together.

Pull the door handle above the arm-

Pull the door handle on the door being opened. The other doors remain locked.

# Valet parking mode

## Principle

The control display is disabled in valet parking mode.

This mode can be used, for example, if the vehicle is to be handed over to a parking service.

#### General

Depending on the national-market version, the valet parking mode may not be available.

In valet parking mode, the vehicle settings cannot be changed via iDrive. Settings stored in a BMW ID or a guest profile cannot be changed. Personal data cannot be displayed.

In addition, the following actions are performed:

- ▶ The volume of the audio system is limited.
- The Dynamic Stability Control cannot be turned off.
- ➤ The availability of certain settings of the drive modes is restricted.

For further information:

BMW ID/driver profiles, see page 68.

# Operating requirements

The driver has registered in the vehicle with a BMW ID.

## Activating valet parking mode

- 1. "MENU"
- 2. "Vehicle apps"

- 3. "System settings"
- 4. "Valet parking mode"

The luggage compartment is locked and disconnected from the central locking system.

- 5. If necessary, "PIN"

  If the active BMW ID does not have an assigned PIN, create a PIN. The PIN is needed to deactivate the valet parking mode.
- 6. If necessary, enter the PIN.
- 7. "Activate valet parking mode"

#### Deactivating valet parking mode

- Select the desired BMW ID on the lock screen.
- Enter the assigned PIN for the BMW ID.
   If the PIN was forgotten: enter access data for the BMW ID.
  - If the selected BMW ID does not have an assigned PIN: enter access data for the BMW ID.

# Settings

#### General

Depending on vehicle equipment and nationalmarket version, various settings are possible for openina and closina.

## Unlocking and locking

#### Doors

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Doors and windows"
- 4. "Lock/unlock"
- 5. "Unlock"
- 6. Select the desired setting:
  - "Driver's door only"

Only the driver's door and fuel filler flap are unlocked. Pressing again unlocks the entire vehicle.

- ▶ "All doors"
  - The entire vehicle is unlocked.
- "Lower window"

The entire vehicle is unlocked.

Pressing the button on the vehicle key twice in immediate succession causes the window to be lowered further when the door is subsequently opened.

# Touchless unlocking/locking

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Doors and windows"
- 4. "Comfort access"
- 5. Select the desired setting:
  - "Unlock when approaching"
  - "Lock when walking away"

#### Automatic unlocking

- 1. "MFNU"
- 2. "Vehicle apps"
- 3. "Doors and windows"
- 4. "Lock/unlock"
- 5. Select the desired setting:
  - "Unlock doors at end of trip"
  - "Unlock doors when in P"

After drive-ready state has been switched off by pressing the Start/Stop button or by engaging the selector lever position P, the locked vehicle is automatically unlocked.

# Automatic locking

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Doors and windows"

- 4. "Lock/unlock"
- 5. "Lock after a short time"

The vehicle is automatically locked again after a short while if no doors are opened after unlocking.

## Vehicle acknowledgement signals

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Doors and windows"
- 4. "Lock/unlock"
- To deactivate or activate desired acknowledgement signals:
  - "Flash on lock/unlock"
     Unlocking is acknowledged by two flashes, locking by one flash.
  - ▶ With alarm system:
    - "Sound on lock/unlock"

Unlocking is acknowledged by two acoustic signals, locking by one acoustic signal.

# Automatic folding of the mirrors

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Doors and windows"
- 4. "Lock/unlock"
- 5. "Fold mirrors on lock/unlock"

#### Luggage compartment

# Luggage compartment and doors

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Doors and windows"
- 4. "Tailgate"
- 5. Select the desired setting:
  - "Tailgate"





Depending on vehicle equipment, the luggage compartment will be unlocked or opened.

- "Tailgate and door(s)"
  Depending on the equipment, the luggage compartment will be unlocked or opened and the doors are unlocked.
- "Tailgate will only open if vehicle is already unlocked"

The vehicle must be unlocked before the luggage compartment can be operated with the vehicle key.

 "Lock tailgate button"
 Operation of the luggage compartment with the vehicle key is disabled.

# Alarm system

#### Principle

The alarm system visually and acoustically signals when someone attempts to open the locked vehicle.

#### General

The alarm system responds to the following changes in a locked vehicle:

- Opening a door, the bonnet or the luggage compartment.
- ▶ Movements inside the vehicle interior.
- A change in the vehicle's angle of inclination, for instance if an attempt is made to jack it up and steal the wheels or to raise it prior to towing away.
- ▶ An interruption in the battery voltage.
- ▶ Improper use of the diagnostic socket.
- Locking the vehicle while a device is connected to the on-board diagnostic socket.

The alarm system indicates these changes visually and audibly:

Acoustic alarm:

- Depending on local regulations, the acoustic alarm may be suppressed.
- ▶ Optical alarm:

By flashing of the hazard warning lights and, if applicable, the headlights.

To safeguard operation of the alarm system, do not modify the system.

# Turning the alarm system on/off

The alarm system is turned off/on as soon as the vehicle is unlocked/locked.

# Opening the doors when the alarm system is switched on

The alarm system is triggered when a door is opened if it has been unlocked via the door lock using the integrated key.

# Opening the luggage compartment with the alarm system turned on

The luggage compartment can be opened even when the alarm system is turned on.

After closing the luggage compartment, the luggage compartment will be locked and monitored again. The hazard warning lights flash once during closing.

# Indicator light on the interior mirror



- ▶ Indicator light flashes every 2 seconds: The alarm system is switched on.
- Indicator light flashes for approximately
   10 seconds then switches to flashing every
   2 seconds:

The interior movement detector and tilt alarm sensor are not active because the doors, bonnet or tailgate are not closed correctly. Correctly closed access points are secured.

Once the remaining open access points have been closed, the interior movement detector and tilt alarm sensor are switched on.

- ➤ The indicator light extinguishes after the vehicle has been unlocked:
  - This means that the vehicle is not being tampered with.
- ➤ The indicator light flashes after unlocking until drive-ready state is switched on, but for no longer than approximately 5 minutes: The alarm has been triggered.

#### Tilt alarm sensor

The vehicle's angle of inclination is monitored.

The alarm system responds, for example when there is an attempt to steal a wheel or tow the vehicle away.

#### Interior movement detector

The vehicle interior is monitored.

The alarm system responds when movement is detected in the vehicle interior.

To ensure perfect functioning, the windows must be closed.

# Avoiding false warnings

#### General

The tilt alarm sensor and the interior movement detector may trigger an alarm even though no unauthorised activity is taking place.

Situations where false warnings may occur:

- In washing bays or car washes.
- ▶ In two-level garages.

- ▶ When transporting the vehicle via motorail, car ferry or trailer.
- ▶ When there are pets in the vehicle.
- When the vehicle is locked after starting to refuel.

The tilt alarm sensor and interior movement detector can be switched off for such situations.

# Switching off the tilt alarm sensor and interior movement detector



Within 10 seconds of locking the vehicle, press the button on the vehicle key.

The indicator light illuminates for approximately 2 seconds and then flashes again.

The tilt alarm sensor and the interior movement detector are switched off until the next time the vehicle is locked.

# Ending the alarm

Unlock the vehicle.

If the vehicle is unlocked with the integrated key, drive-ready state must then be turned on via emergency detection of the vehicle key.

# Window

#### General

If a window is often opened in the same location, this task can be carried out by the BMW Intelligent Personal Assistant. For example, if you often use the same multi-storey car park.

For further information:

BMW Intelligent Personal Assistant, see page 57.





# Safety information



#### MARNING

Parts of the body can become trapped when the windows are operated. There is a danger of injury or material damage. When opening and closing, make sure that the movement range of the windows is kept clear.

# With the vehicle key

#### Opening windows



Keep the button on the vehicle key pressed after unlocking.

The windows open for as long as the button on the vehicle key remains pressed.

#### Close windows



Keep the button on the vehicle key pressed after locking.

The windows close for as long as the button on the vehicle key remains pressed.

Depending on the equipment, the exterior mirrors are folded in provided that they were not folded in when the vehicle was locked. If the hazard warning lights are switched on, the exterior mirrors are not folded in.

#### On the outside door handle

## Principle

The windows can be closed via the outside door handle without operating the vehicle key.

The vehicle key is automatically detected near the vehicle


#### General

The function is available with Comfort Access.

#### Functional prerequisite

Carry the vehicle key with you, for example, in your trouser pocket.

#### Close windows



Touch the grooved surface on the outside door handle of a closed door with your finger and hold it there without grasping the handle recess.

In addition to locking, the windows and the glass sunroof with sun protection are closed.

Depending on the equipment, the exterior mirrors are folded in provided that they were not folded in when the vehicle was locked. If the hazard warning lights are switched on, the exterior mirrors are not folded in.

#### In the interior

#### Overview





Window lifters



The windows can be operated under the following conditions.

- ▶ Standby state is switched on.
- ▶ Drive-ready state is switched on.
- ▶ For a short while after rest state has been established.

The vehicle key or a digital key must be inside of the vehicle.

#### Opening windows



Press the switch as far as the resistance point.

The window opens for as long as the switch is held.



Press the switch past the resistance point.

The window is opened automatically. Pressing the switch again stops the movement.

#### Close windows



Pull the switch as far as the resistance point.

The window closes for as long as the switch is held.



Pull the switch past the resistance point.

The window closes automatically. Pulling the switch again stops the movement.

# Anti-trap mechanism

#### **Principle**

The anti-trap mechanism prevents objects or parts of the body from becoming trapped between the door frame and window while a window is being closed.

#### General

If resistance or an obstruction is detected while a window is being closed, the closing process is interrupted.


#### Safety information

#### MARNING

Accessories on the windows, for example aerials, can impair the anti-trap mechanism. There is a danger of injury. Do not attach any accessories within the movement range of the windows.

## Closing with no anti-trap mechanism

If an external hazard or ice prevents normal closure, proceed as follows:



The window is closed but with restricted anti-trap mechanism. If the closing force exceeds a certain level, the closing operation is interrupted.

2. Pull the switch past the resistance point again within approximately 4 seconds and hold it in this position.

The window is closed with no anti-trap mechanism.





# Glass sunroof

#### Safety information



#### ↑ WARNING

Parts of the body may become trapped when the glass sunroof is operated. There is a danger of injury. When opening and closing, make sure that the movement range of the glass sunroof is kept clear.

#### With the vehicle key

#### Opening the glass sunroof



Keep the button on the vehicle key pressed after unlocking.

The electric glass sunroof with sun protection is opened for as long as the button on the vehicle key is pressed.

#### Closing the glass sunroof



Keep the button on the vehicle key pressed after locking.

The electric glass sunroof with sun protection is closed for as long as the button on the vehicle kev is pressed.

Depending on the equipment, the exterior mirrors are folded in provided that they were not folded in when the vehicle was locked. If the hazard warning lights are switched on, the exterior mirrors are not folded in.

#### On the outside door handle

## Principle

The glass sunroof can be closed with the outside door handle without operating the vehicle

The vehicle key is automatically detected near the vehicle.


#### General

The function is available with Comfort Access.

#### Functional prerequisite

Carry the vehicle key with you, for example, in vour trouser pocket.

#### Closing the glass sunroof



Touch the grooved surface on the outside door handle of a closed door with your finger and hold it there without grasping the handle recess.

In addition to locking, the windows and the glass sunroof with sun protection are closed.

Depending on the equipment, the exterior mirrors are folded in provided that they were not folded in when the vehicle was locked. If the hazard warning lights are switched on, the exterior mirrors are not folded in.

#### In the interior

#### General

The glass sunroof and the sun protection are operated using the same switch.

#### Overview

#### Button in the vehicle





To open/close the glass sunroof/sun protection.

#### Operating requirements

The glass sunroof and the sun protection can be operated under the following conditions:

- > Standby state is switched on.
- Drive-ready state is switched on.
- > For a short while after rest state has been established.

The vehicle key must be in the vehicle interior.

# Raising/closing the glass sunroof



Press the switch briefly up.

- The closed glass sunroof is raised and the sun protection opens slightly.
- The opened glass sunroof closes to the raised position. The sun protection does not move.
- ▶ The raised glass sunroof is closed.

# Opening/closing the glass sunroof and sun protection separately



Slide the switch backwards as far as the resistance point and hold.

> The sun protection opens for as long as the switch is pressed. If the sun protection is already fully open, the glass sunroof is opened.

Slide the switch forwards as far as the resistance point and hold.

The glass sunroof closes for as long as the switch is held. If the glass sunroof is already closed or is in the raised position, the sun protection is closed.

 Slide the switch backwards beyond the resistance point.

The sun protection is opened automatically. If the sun protection is already fully open, the glass sunroof is opened automatically. Pressing the switch again stops the move-

ment.

Slide the switch forwards beyond the re-

The glass sunroof is closed automatically. If the glass sunroof is already closed or is in the raised position, the sun protection is closed automatically.

Pressing the switch again stops the movement.

# Opening/closing the glass sunroof and sun protection together



sistance point.

➤ Slide the switch back beyond the resistance point twice in quick succession.

The glass sunroof and the sun protection open together.





- Pressing the switch again stops the movement.
- Slide the switch forwards beyond the resistance point twice in quick succession.
   The glass sunroof and the sun protection

The glass sunroof and the sun protection close together.

Pressing the switch again stops the movement.

## Comfort position

In some models, wind noise levels inside the vehicle are lowest when the glass sunroof is not fully open. On these models, the automatic function initially only opens the glass sunroof as far as this comfort position.

Pressing the switch again in the interior opens the electric glass sunroof fully.

# Closing the glass sunroof automatically

#### Principle

After locking, the open glass sunroof is automatically moved to the raised position in the event of rain or after six hours.

# Operating requirements

- Rain must be able to reach the sensor field in the area of the interior mirror. The sensor field may be obscured by a car port or bridge, for example.
- Vehicle must be in rest state.
- ▶ The function must be activated in the settings.

For settings, see page 88.

#### Malfunctions

The open glass sunroof is not moved to the raised position under the following circumstances:

- ▶ The glass sunroof is blocked.
- The anti-trap mechanism cannot be guaranteed.
- ➤ There is a system error, for example due to a temporary open circuit. In this case, initialising the glass sunroof can help.

An error message is shown on the control display. No further closure is attempted.

If rain detection is not possible due to the system, the open glass sunroof is immediately moved to the raised position. An error message is shown on the control display.

#### Anti-trap mechanism

## Principle

The anti-trap mechanism prevents objects or parts of the body from becoming trapped between the roof frame and glass sunroof while the glass sunroof is being closed.

#### General


If resistance or an obstruction is detected while the glass sunroof is being closed, the closing operation is interrupted once the roof reaches the half-open position or when closing from the raised position.

# Closing with no anti-trap mechanism from an open position

If an external hazard or ice prevents normal closure, proceed as follows:



- Close all doors.
- Slide the switch forwards beyond the resistance point and hold it in this position.
   The glass sunroof is closed with restricted anti-trap mechanism. If the closing force



Slide the switch forwards once again beyond the resistance point and hold until
the glass sunroof closes with no anti-trap
mechanism. Ensure that the closing range
is clear.

# Closing with no anti-trap mechanism from a raised position

If an external hazard or ice prevents normal closure, proceed as follows:



- 1. Close all doors.
- 2. Slide the switch forwards beyond the resistance point and hold it in this position.

## Initialising after an open circuit

#### General

If a open circuit occurs while the glass sunroof is opening or closing, it may only have restricted functionality afterwards. In this case, initialising the system can help.

The system can be initialised if the following conditions are met:

- ▶ The vehicle is parked on level ground.
- ➤ The vehicle does not move until initialisation is complete.
- ▶ Drive-ready state is activated.
- ► The outside temperature is above 5 °C/41 °F.

During initialisation, the glass sunroof closes with no anti-trap mechanism.

Ensure that the closing range is clear.

#### Initialising the system



Press the switch up and hold until initialisation is complete:

Initialisation begins within 15 seconds.

- ▶ If the glass sunroof is closed, it opens, then closes again.
- ▶ If the glass sunroof is open, it first closes, then opens and closes again.

Initialisation is complete once the glass sunroof and sun visor have opened, then closed again.





# Seats, mirrors and steering wheel

# Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

# Safe seating position

A seat position that suitably meets the needs of the occupants is essential for relaxed driving with minimum fatigue.

In an accident, the correct seat position plays an important role. Pay attention to the notes in the following chapters.

For further information:

- ▶ Seats, see page 98.
- ▶ Seat belts, see page 103.
- Head restraints, see page 105.
- ▶ Airbags, see page 169.

# Seats

#### Safety information



#### ↑ WARNING

Setting the seat during a journey could cause the seat to move unexpectedly. You could lose control of the vehicle. There is a risk of accident. Only adjust the seat on the driver's side when at a standstill.

#### ↑ WARNING

If the backrest is angled too far back, the protective effect of the seat belt will no longer be guaranteed. There is a risk of sliding under the seat belt in the event of an accident. There is a danger of injury or danger to life. Adjust the seat before starting the journey. Adjust the backrest to the most upright position possible, and do not change it during the journey.



#### ↑ WARNING

There is a risk of entrapment when the seats are moved. There is a danger of injury or material damage. Before making any adjustment, make sure that the movement range of the seat is clear.

## Manually adjustable seats

#### Overview



The levers for the seat settings are located at the front seats.

# Adjusting the forward/back position



#### MARNING MARNING

If the seat is not locked, it could move unexpectedly during a journey. You could lose control of the vehicle. There is a risk of accident. After making an adjustment, move the seat forwards and backwards slightly to ensure that it is properly engaged.




Pull the lever and slide the seat in the desired direction.

#### Adjusting the seat angle



Pull the lever up or press the lever down repeatedly until the seat reaches the desired angle.

#### Adjusting the height



Pull the lever up or press the lever down repeatedly until the seat reaches the desired height.

# Adjusting the backrest angle



Pull the lever and add or remove pressure on the backrest as required.

# Electrically adjustable seats

#### General

The current seat position can be saved using the memory function.


# 1

#### Overview




The switches for the seat settings are located at the front seats.

## Adjusting the forward/back position




Press the switch forwards or backwards.

# Adjusting the height




Press the switch up or down.

#### Adjusting the seat angle



Tilt the switch up or down.

# Adjusting the backrest angle



Tilt the switch forwards or backwards.

# Adjusting the seat position automatically

#### General


The seat setting for the driver's seat is stored in the active BMW ID or in the active driver profile. If the BMW ID or the driver profile is reactivated at a later time, the stored position is loaded automatically.

#### Activating/deactivating the function

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Seat comfort"
- 4. Select driver's seat.
- 5. Select the desired setting.

# Thigh support

## Sport seat



Pull the lever on the front of the seat and adjust the thigh support forwards or backwards.

#### Lumbar support

#### **Principle**

The curvature of the backrest can be changed to provide support for the lumbar region, or lordosis. The upper edge of the pelvis and the spinal column are supported to encourage an upright sitting posture.

# Adjusting the lumbar support



- Press the button at the front/rear: The curvature is increased/decreased.
- Press the button at the top/bottom: The curvature is shifted upwards/downwards.

#### **Backrest width**

## **Principle**

The backrest width can be adjusted to improve lateral support when cornering.

#### General

The backrest width is changed by adjusting the side sections of the backrest.

#### Adjusting the backrest width



- Press the button at the front: Backrest width is reduced.
- Press the button at the rear: Backrest width is increased.

# Entering the rear passenger compartment

#### Safety information

#### ↑ WARNING

There is a risk of entrapment when the seats are moved. There is a danger of injury or material damage. Before making any adjustment, make sure that the movement range of the seat is clear.

#### MARNING

If the backrest is not locked, it could move unexpectedly while you are driving. You could lose control of the vehicle. There is a danger of injury. Fold back and lock the backrest before every journey. Move the backrest forwards and backwards slightly to ensure that it is properly engaged.






#### Manual forward/back adjustment

#### Folding down the backrest

1. Pull the lever as far as it will go.



- 2. Fold the backrest forwards.
- 3. Slide the seat forwards.

#### Folding back the backrest

- 1. Slide the seat back to its initial setting.
- 2. Fold back the backrest to lock the seat.

#### Electric forward/back adjustment

#### Folding down the backrest

Pull the lever as far as it will go.



Fold the backrest forwards.

For easier access to the rear compartment, the seat automatically moves all the way forwards.

The process is interrupted if the switch for the forward/back position is pressed or the backrest is folded back.

#### Folding back the backrest

Fold back and lock the backrest.

The seat automatically moves back to its last saved position.

# Calibrating the front seats

#### General

As soon as the electric seat adjustment no longer functions precisely, a Check Control message is displayed on the control display.

To restore the accuracy of the electric seat setting, the front seats must be calibrated.

# Safety information

#### ↑ WARNING

There is a risk of entrapment when the seats are moved. There is a danger of injury or material damage. Before making any adjustment, make sure that the movement range of the seat is clear.

# Calibrating the front seat

- 1. Push the switch forward again in a longitudinal direction until the seat stops.
- 2. Push the switch forward again until the seat stops.
- 3. Reset the desired seat position.

As soon as the message on the control display disappears, the calibration is complete. If the message remains active, repeat the calibration.

If the message is not hidden after repeated calibration, have the system checked by a qualified Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.



#### General

For the safety of the vehicle occupants, the vehicle is equipped with four seat belts. However, they can only provide a protective effect when applied correctly.

Before each journey, always make sure that all occupants have fastened their seat belts. The airbags supplement the seat belts as an additional safety device. The airbags are not a substitute for the seat belts.

All belt anchorages are designed to achieve the best possible protective effect of the seat belts with proper use of the seat belts and correct seat setting.

For further information:

Notes on sitting safely, see page 98.

#### Safety information

#### MARNING

If a seat belt is used by more than one person at the same time, the protective effect of the seat belt is no longer guaranteed. There is a danger of injury or danger to life. Only one person should use each seat belt at any one time. Do not allow infants and children to travel on the lap of another occupant. Instead, secure the infant or child in child restraint systems intended for this purpose.

#### MARNING

The protective effect of the seat belts may be restricted or may even fail completely if the seat belts are worn incorrectly. If a seat belt is not worn correctly, additional injuries can be caused, for example in the event of an accident, braking or avoidance manoeuvre. There is a danger of injury or danger to life. Make

sure that all vehicle occupants have fastened their seat belts correctly.

#### ↑ WARNING

Seat belts are designed to bear upon the bony structure of the body and should be worn low across the front of the pelvis, or the pelvis, chest and shoulders, as applicable. Wearing the lap section of the belt across the abdominal area must be avoided.

Seat belts should be adjusted as firmly as possible, consistent with comfort, to provide the protection for which they have been designed. A slack seat belt will greatly reduce the protection afforded to the wearer.

Care should be taken to avoid contamination of the seat belt strap by polishes, oils and chemicals and particularly battery acid. Cleaning may safely be carried out using a mild soap and water solution. The seat belt should be replaced if the seat belt strap becomes frayed, contaminated or damaged. Seat belts should not be worn with straps twisted. Each seat belt assembly must only be used by one occupant; it is forbidden to put a belt around a child being carried on the occupant's lap.

It is essential to replace the entire seat belt assembly after it has been worn in a severe impact even if damage to the assembly is not obvious.

#### ↑ WARNING

No modifications or additions should be made by the user that will either prevent the seat belt adjusting devices from operating to remove slack, or prevent the seat belt assembly from being adjusted to remove slack.





#### ⚠ WARNING

If the rear seat backrest is not locked, the protective effect of the middle seat belt is not ensured. There is a danger of injury or danger to life. Lock the wider rear seat backrest when using the middle seat belt.

#### ▲ WARNING

The protective effect of the seat belts may be restricted or may even fail completely in the following situations:

- ▶ If the seat belts or seat belt buckles are damaged, dirty or have been modified in another way.
- ➤ The seat belt tensioners or belt retractors have been modified.

Seat belts can be damaged in an accident without the damage necessarily being apparent. There is a danger of injury or danger to life. Do not modify seat belts, seat belt buckles, seat belt tensioners, belt retractors and belt anchor points and ensure that they are kept clean. After an accident, have the seat belts inspected at a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

#### Correct seat belt use

- Place the seat belt tightly over the pelvis and shoulder, close to the body and without twisting.
- ▶ Make sure that the seat belt is positioned low at the hips in the area of the pelvis. The seat belt must not press on the abdomen.
- The seat belt must not be allowed to rub against sharp edges, be routed over solid or breakable objects or be trapped.
- Avoid wearing bulky clothing.
- Keep the seat belt taut by occasionally pulling upwards on the upper body area.

# Setting for automatic retracting seat belts

- Draw the seat belt tongue attached to the seat belt across the body and press it into the seat belt buckle until a 'click' is heard.
- ➤ Adjustment of the belt length is very important. To adjust the lap belt and check whether the seat belt buckle has locked correctly, pull upwards on the shoulder strap until the lap belt fits tightly.
- The length of the diagonal shoulder strap adjusts itself automatically to allow freedom of movement.
- ➤ To release the seat belt, press the button on the seat belt buckle.

## Fastening the seat belt

- 1. When fastening the seat belt, guide it slowly over the shoulder and pelvis.
- Insert the seat belt tongue in the seat belt buckle. The seat belt buckle must be heard to engage.



# Unfastening the seat belt

- 1. Hold the seat belt firmly.
- Press the red button on the seat belt buckle.
- Guide the seat belt back up to the automatic reel.



#### General

Check whether the seat belts are fastened correctly.

The seat belt warning becomes active in the following situations:

- ▶ When the seat belt on the driver's side or on the passenger's side is not fastened.
- ▶ When the seat belt is unfastened while driving.
- ▶ When objects are lying on a seat.

#### Display in the instrument cluster

The indicator light in the instrument cluster illuminates after turning on the drive-ready state and the seat belt warning is active.

A Check Control message is shown where applicable. Check whether the seat belt has been fastened correctly.

The displays may vary depending on the equipment and national-market version.

lcon	Meaning
Å	Seat belt is not buckled.
	Seat belt is only buckled on the corresponding seat.
	Seat belt on the corresponding

seat is not buckled.

# Front head restraints

#### Safety information

#### MARNING

If the head restraints are removed or incorrectly adjusted, they cannot provide protective effect as intended and head and neck injuries may result. There is a danger of injury.

- ▶ Before a journey, re-install any removed head restraints on all occupied seats.
- > Adjust the head restraint so that its centre supports the back of the head at eye level where possible.
- > Adjust the distance so that the head restraint is as close as possible to the back of the head. If necessary, adjust the distance by adjusting the backrest angle.



#### ↑ WARNING

Parts of the body can become trapped when the head restraint is moved. There is a danger of injury. When moving the head restraint, make sure that the movement range is kept clear.


#### MARNING

Objects on the head restraint impair the protective effect of the head restraint in the head and neck area. There is a danger of injury.

- ▶ Do not fit any covers on the seats or head restraints.
- ▶ Do not hang objects such as coat hangers directly on the head restraint.
- > Only use accessories that have been classified as safe for attaching to the head restraint.
- > Do not use any accessories, for example cushions, during the journey.




## Adjusting the height



- Down: press the button, arrow 1, and slide the head restraint downwards.
- ▶ Up: push the head restraint upwards.

After adjusting the height, make sure that the head restraint engages correctly.

## Adjusting the height: M Sport seat



Press the switch up or down.

# Adjusting the distance



- Back: press the button and push back the head restraint.
- > Forward: pull the head restraint forwards.

After adjusting the distance, make sure that the head restraint engages correctly.


# Adjusting the distance: M sport seat

The distance from the back of the head is adjusted by the seat backrest angle.

Adjust the distance so that the head restraint is as close as possible to the back of the head.

## Removing the head restraints

Only remove the head restraint if no-one is intending to sit in the seat in question.



- Push the head restraint up until resistance is felt.
- 2. Press the button, arrow 1, and pull the head restraint fully out.

# Removing the head restraints: M sport seat

The head restraints cannot be removed.

#### Installing head restraints

Proceed in the reverse order to install the head restraint.

# Rear head restraints

## Safety information

#### ↑ WARNING

If the head restraints are removed or incorrectly adjusted, they cannot provide protective effect as intended and head and neck injuries may result. There is a danger of injury.

- ▶ Before a journey, re-install any removed head restraints on all occupied seats.
- > Adjust the head restraint so that its centre supports the back of the head at eye level where possible.
- > Adjust the distance so that the head restraint is as close as possible to the back of the head. If necessary, adjust the distance by adjusting the backrest angle.

#### MARNING

Parts of the body can become trapped when the head restraint is moved. There is a danger of injury. When moving the head restraint, make sure that the movement range is kept clear.

#### MARNING

Objects on the head restraint impair the protective effect of the head restraint in the head and neck area. There is a danger of injury.


- Do not fit any covers on the seats or head restraints.
- > Do not hang objects such as coat hangers directly on the head restraint.
- > Only use accessories that have been classified as safe for attaching to the head restraint.
- ▶ Do not use any accessories, for example cushions, during the journey.

# Folding down the head restraints

#### General

Head restraints can be folded back to improve rear visibility. Only fold back the head restraint if no one is sitting on the seat in question.

#### Folding down the head restraints



- ▶ Backwards: press the button, arrow 1, and fold back the head restraint.
- > Forwards: fold the head restraint forwards as far as it will go. Ensure that the head restraint engages correctly.

# Adjusting the height



The height of the head restraints can be adjusted.

- Down: press the button, arrow 1, and slide the head restraint downwards.
- Up: push the head restraint upwards.

After adjusting the height, make sure that the head restraint engages correctly.





# Removing the head restraint

Only remove the head restraint if no-one is intending to sit in the seat in question.

- 1. Fold down the respective rear seat back-
  - To enlarge the luggage compartment, see page 258.
- 2. Push the head restraint up until resistance
- 3. Insert the integrated key. Integrated key, see page 74.



4. Press and hold the integrated key and the button simultaneously, arrows 1, and pull the head restraint fully out.



# Installing head restraints

To install, insert the head restraint into the mount and push down until resistance is felt.

After installation, make sure that the head restraint engages correctly.

# Exterior mirrors

#### General

The exterior mirror adjustment is stored in the active BMW ID or in the active driver profile. If the BMW ID or the driver profile is reactivated at a later time, the stored position is loaded automatically.

The current exterior mirror adjustment can be stored using the memory function.

# Safety information

#### ↑ WARNING

Objects reflected in the mirror are closer than they appear. The distance from road users behind the vehicle could be incorrectly estimated, for example when changing driving lane. There is a risk of accident, Look over your shoulder to estimate the distance from following traffic.

## Overview



#### lcon

#### Meaning



Fold the exterior mirror in and out.



Adjust the exterior mirrors.



Select mirror, automatic parking function.

# Adjusting the exterior mirrors



Press the kev.

The selected exterior mirror moves along with the button movement.

# Selecting the exterior mirror



To switch to the other mirror: Push the switch.

### Malfunction

In case of an electrical failure, adjust the exterior mirror by pressing on the edges of the mirror glass.

## Folding in/folding out the exterior mirror



#### ▲ NOTICE

Because of its width, the vehicle could sustain damage in car washes. There is a risk of material damage. Before washing, fold the mirrors in manually or with the button.



Press the kev.

The mirrors can be folded in at vehicle speeds up to approx. 20 km/h/15 mph.

Folding the exterior mirrors in and out is helpful in the following situations:

- In car washes.
- In narrow streets.

Mirrors which are folded in automatically fold out when the vehicle reaches a speed of approximately 40 km/h/25 mph.

# Automatic heating

When required, both exterior mirrors are automatically heated when drive-ready state is switched on.

# Automatic dimmina

The exterior mirror on the driver's side is dimmed automatically. Photocells in the interior mirror are used to control this function.

# Automatic parking function

# **Principle**

When reverse gear is engaged, the mirror glass on the passenger's side is tilted downwards. When parking, for example, this gives the driver a better view of the kerb or other objects near the around.

### Activating the automatic parking function



- 1. Push the switch to the driver's mirror position.
- 2. Engage selector lever position R.

The automatic parking function is deactivated when the trailer socket is occupied.

#### Deactivating the automatic parking function

Push the switch to the front passenger's side exterior mirror position.





# Interior mirror, manual dim



Reduce dazzling effect from the interior mirror by tilting the lever forward.

# Rear-view mirror with automatic anti-dazzle function

#### General

The interior mirror is dimmed automatically.

The function is controlled by photocells:

- ▶ In the mirror glass.
- On the back of the mirror.

#### Overview





# Operating requirements

- Keep the photocells clean.
- Do not obstruct the zone between the interior mirror and the windscreen.


# Steering wheel

# Safety information

#### ↑ WARNING

Adjusting the steering wheel while driving may cause the steering wheel to move unexpectedly. You could lose control of the vehicle. There is a risk of accident. Only adjust the steering wheel when the vehicle is at a standstill.

# Manual steering wheel adjustment



- 1. Fold the lever down fully.
- 2. Grip the steering wheel with both hands and adjust it in the longitudinal direction and height of the seat position.
- 3. Fold the lever back up.


# Steering wheel heating

#### Overview



Button for steering wheel heating

### Turning the steering wheel heating on/off



A Check Control message is shown.

If a journey is resumed within about 15 minutes after a temporary stop, steering wheel heating switches on automatically provided that the function had been active at the end of the previous iourney.

# Memory function

# Principle

The memory function enables the following settings to be stored and retrieved when reauired:

- Seat position.
- ▶ Exterior mirror adjustment.
- Depending on the equipment: height of the Head-up display.

#### General

For each driver profile, two memory slots can be assigned with different settings.

The following settings are not saved:

- Backrest width.
- ▶ Lumbar support.

# Safety information



#### ↑ WARNING

Using the memory function while driving may cause the seat or steering wheel to move unexpectedly. You could lose control of the vehicle. There is a risk of accident. Only use the memory function when the vehicle is at standstill.

#### ↑ WARNING

There is a risk of entrapment when the seats are moved. There is a danger of injury or material damage. Before making any adjustment, make sure that the movement range of the seat is clear.

#### Overview



The memory buttons are on the front doors.

# Storing settings

1. Set the desired position.



Press the button. The LED is illumi-

3. Press the desired button 1 or 2 while the LED is illuminated. A signal sounds.

# Go to Settings

Press the desired button 1 or 2.

The saved position is retrieved.

The operation is halted when a seat setting switch or one of the memory buttons is pressed again.

The adjustment of the seat position on the driver's side is interrupted after a short time while driving.



# Seat climate control

Various air conditioning functions are available for the seats.

For further information:

Air conditioning control, see page 237.

# Carrying children safely

# Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

# Important considerations

# Safety information

#### ↑ WARNING

Unsupervised children or pets in the vehicle can set the vehicle in motion and endanger themselves or other road users, for example by the following actions:

- ▶ Pressing the Start/Stop button.
- ▶ Releasing the parking brake.
- ▶ Opening and closing doors or windows.
- ▶ Engaging selector lever position N.
- > Operating vehicle equipment.

There is a risk of accident or injury. Do not leave children or pets unsupervised in the vehicle. When leaving the vehicle, take the vehicle key with you and lock the vehicle.

#### 

Hot vehicle can have fatal consequences, in particular for children or pets. There is a danger of injury or danger to life. Do not leave anyone unsupervised in the vehicle, especially children or pets.

#### ↑ WARNING

Child restraint systems and their parts can get very hot when exposed to direct sunlight. Contact with hot parts can cause burns. There is a danger of injury. Do not expose the child restraint system to direct sunlight; cover the child restraint system if necessary. If required, allow the child restraint system to cool down before transporting a child. Do not leave children unsupervised in the vehicle.

#### Children on the rear seat

#### General

Accident research has shown that the safest place for children is on the rear seat.

Wherever possible, children younger than 12 years old or shorter than 150 cm, 5 ft should be transported only on the rear seats in child restraint systems appropriate for their age, weight and stature. Children aged 12 years and older must be secured with a seat belt once a suitable child restraint system is no longer an option due to their age, weight or stature.

# Safety information



#### ↑ WARNING

Children shorter than 150 cm, 5 ft cannot wear the seat belt correctly without using additional child restraint systems. The protective effect of the seat belts may be restricted or may even fail completely if the seat belts are worn incorrectly. If a seat belt is not worn correctly, additional injuries can be caused, for example in the event of an accident, braking or avoidance manoeuvre. There is a danger of injury or danger to life. Children shorter





than 150 cm, 5 ft must be secured in suitable child restraint systems.

# Not for Australia: Children on the front passenaer seat

#### General

When using a rearward-facing child restraint system on the front passenger seat, make sure that the front passenger airbag is deactivated.

If it is not possible to deactivate the front passenger airbag, do not carry children in suitable rearward-facing child restraint systems on the front passenger seat.

For further information:

Key switch for front passenger airbag, see page 171.

### Safety information



#### ♠ DANGER

If triggered, an active front passenger airbag can fatally injure a child in a child restraint system which is mounted facing backwards. There is a danger to life. Make sure that the front passenger airbag is deactivated and the PASSENGER AIRBAG OFF indicator light is illuminated.

# Fitting child restraint systems

#### General

Please comply with the operating and safety instructions provided by the child restraint system manufacturer when selecting, attaching and using child restraint systems.

# Safety information



#### ↑ WARNING

If child restraint systems and their attachment systems have been damaged or subjected to stresses in an accident, their protective effect may be restricted or may fail completely. A child might not be adequately restrained, for example in the event of an accident, braking or avoidance manoeuvre. There is a danger of injury or danger to life.

Do not continue to use child restraint systems which are damaged or have been subjected to stresses in an accident.

If attachment systems have been damaged or subjected to stresses in an accident, have them checked and replaced by a Service Partner of the manufacturer, another qualified Service Partner or a specialist workshop.



#### ⚠ WARNING

If the seat is not set properly or the child seat has been installed incorrectly, the child restraint system may have restricted or no stability at all. There is a danger of injury or danger to life. Make sure that the child restraint system rests firmly against the seat backrest. Wherever possible, adapt the backrest angle of all relevant seat backrests and adjust the seats correctly. Make sure that the seats and their backrests are correctly engaged or locked. If possible and if necessary, adjust the height of the head restraints or remove them.

# For Australia: installation of child restraint systems

Please note the following warning because your vehicle has been equipped with a front airbag for the front passenger seat that cannot he deactivated:



It is not recommended to use rearward-facing child restraint systems on the front passenger seat.



### Extreme hazard

Do not use rearward-facing child restraint systems on a seat protected by an airbag in front of it.

# Not for Australia: On the front passenger seat

#### Deactivating the airbag



#### ♠ DANGER

If triggered, an active front passenger airbag can fatally injure a child in a child restraint system which is mounted facing backwards. There is a danger to life. Make sure that the front passenger airbag is deactivated and the PASSENGER AIRBAG OFF indicator light is illuminated.

Before installing a rearward-facing child restraint system on the front passenger seat, make sure that the front passenger airbag is deactivated. If the airbag cannot be deactivated, do not install a rearward-facing child restraint system.

For further information:

Key switch for front passenger airbag, see page 171.

# Rearward-facing child restraint systems



#### ♠ DANGER

If triggered, an active front passenger airbag can fatally injure a child in a child restraint system which is mounted facing backwards. There is a danger to life. Make sure that the

front passenger airbag is deactivated and the PASSENGER AIRBAG OFF indicator light is illuminated.



Follow the note on the sun visor on the passenger's side.

Never use rearward facing child restraint systems on a seat with an activated front airbaa. Use may result in death or serious injury to children.

## Seat position and height

After installing a universal child restraint system, move the front passenger seat as far back as it will go and adjust it to the highest position. This seat position and height provides the best possible belt routing and protection in the event of an accident.

After installing a universal child restraint system, adjust the inclination of the seat backrest to achieve the best possible belt routing.

If the upper attachment point of the seat belt is in front of the child seat's seat belt guide, carefully move the front passenger seat forwards until the best possible seat belt quide is achieved.

#### **Backrest width**

With adjustable backrest width: before installing a child restraint system on the front passenger seat, fully open the backrest width. Do not change the backrest width from this point on and do not retrieve a seat position from the memory.





# ISOFIX or i-Size child safety seat fasteners

#### General

Please comply with the operating and safety instructions provided by the, child restraint system manufacturer when selecting, attaching and using ISOFIX or i-Size child restraint systems.

# i-Size child restraint systems

#### General

i-Size is a legal regulation for child restraint systems which is used for the approval of child restraint systems.

The system represents a further development of the ISOFIX child safety seat fasteners.

ISOFIX child restraint systems can also be attached to anchors with i-Size markings.

#### Icon

#### Meaning



If this icon is seen in the vehicle, the vehicle has also been approved in accordance with i-Size. The icon shows the mounts for the system's lower anchors. The lower anchors meet the European i-Size reauirements.



The corresponding icon shows the top tether eyelet.

# Suitable ISOFIX or i-Size child restraint systems

Only certain ISOFIX or i-Size child restraint systems are permitted for use on the designated seats. The associated size class and size

category are denoted by a letter or ISO reference on a plate on the child seat.

For further information:

Suitable seats for child restraint systems, see page 118.

#### Fixtures for lower anchors

#### General

Note the following when fitting child restraint systems with integrated strap to the mounts for the lower anchors:

The total weight of the child and child restraint system must not exceed 33 kg, 73 lbs.

### Safety information



#### MARNING

If the child restraint system lower anchors are not engaged correctly, the protective effect of the child restraint system will be restricted. There is a danger of injury or danger to life. Make sure the lower anchor points have enagged correctly and the child restraint system. rests firmly against the backrest.



#### ↑ WARNING

The mounts for the lower anchors and the attachment points for child restraint systems are intended for attaching child restraint systems only. If other objects are attached, the mounts or attachment points can be damaged. There is a danger of injury or material damage. Only attach child restraint systems to the corresponding mounts for the lower anchors or the attachment points.



# **Icon**

#### Meaning



The corresponding icon shows the fixtures for the lower ISO-FIX anchors or i-Size mounting.



The fixtures for the lower anchors are located behind the marked covers. To expose the anchorage points, open the flaps upwards.

# Before fitting child restraint systems

Pull the seat belt away from the area of the child seat mountings.

# Fitting child restraint systems

- 1. Install child restraint system, see the manufacturer's instructions.
- 2. Make sure that the child restraint system attachment correctly engages in the lower anchor on both sides.

# Child restraint systems with upper restraint strap

# Safety information

#### MARNING

If the upper retaining strap is used incorrectly on the child restraint system, the protective effect will be reduced. There is a danger of injury. Make sure that the upper retaining strap is not twisted and is not routed to the upper attachment point over sharp edges.

#### MARNING

If the rear seat backrest is not locked, the protective effect of the child restraint system will be restricted or lost. The rear seat backrest may fold forward in certain situations, for example in the event of braking manoeuvre or an accident. There is a danger of injury or danger to life. Make sure that the rear seat backrests are locked.



## ↑ WARNING

The mounts for the lower anchors and the attachment points for child restraint systems are intended for attaching child restraint systems only. If other objects are attached, the mounts or attachment points can be damaged. There is a danger of injury or material damage. Only attach child restraint systems to the corresponding mounts for the lower anchors or the attachment points.





# Attachment points for upper retaining strap

#### lcon

#### Meaning




The corresponding icon shows the top tether eyelet.



There are two attachment points for the upper retaining strap of ISOFIX child restraint systems.

# Routing the retaining strap



- 1 Direction of travel
- 2 Head restraint
- **3** Hook of the upper retaining strap
- 4 Attachment point
- 5 Parcel shelf
- 6 Seat backrest
- **7** Upper retaining strap

# Attaching the upper retaining strap to the attachment point

- 1. Open the cover of the attachment point.
- 2. If necessary, raise the head restraint.
- 3. Guide the upper retaining strap between the head restraint mounts.
- Attach the hook of the retaining strap to the attachment point.
- 5. Tighten the retaining strap by pulling it firmly down.

# Suitable seats for child restraint systems

#### General

The legal provisions determining which child seat is permitted for which age and body size may vary from country to country. Please comply with the relevant national legal provisions.

Additional information is available from a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.


For detailed information about using child restraint systems:

Seats for child restraint systems, see page 354.

# Seats and child restraint systems

The following section provides information on which child restraint system is suitable for which seat in the vehicle.

Left-hand drive vehicles, seats:




Seat	Airbag, front passenger	Mounting			
1		X			
3 a)	ON only for- ward-facing child restraint system	U	L		
	OFF only rearward fac- ing child re- straint sys- tem	U	L		
4, 6 – b)		U	L	<b>©</b> j	<u></u>
5		X			

- a) Move the front passenger seat as far back as it will go and adjust it to the highest position. Then adjust the angle of the backrest to achieve the best possible belt routing.
- b) When using child restraint systems on the rear seats, adjust the longitudinal direction of the front seat if necessary and, if possible and necessary, adjust or remove the head restraint of the rear seat.
- c) Depending on the equipment or national-market version.

Right-hand drive vehicle, seats:





Seat	Airbag, front passenger	Mounting			
1 a)	ON only for- ward-facing child restraint system	U	L		
	OFF only rearward fac- ing child re- straint sys- tem	U	L		
3		X			
4, 6 – b)		U	L	<b>(</b> )	<u> </u>
5		×			

- a) Move the front passenger seat as far back as it will go and adjust it to the highest position. Then adjust the angle of the backrest to achieve the best possible belt routing.
- b) When using child restraint systems on the rear seats, adjust the longitudinal direction of the front seat if necessary and, if possible and necessary, adjust or remove the head restraint of the rear seat.
- c) Depending on the equipment or national-market version.



### Meaning

**Icon** 

#### Meaning



Not suitable for child restraint systems.



Suitable for ISOFIX child restraint systems.



Suitable for Universal-category child restraint systems approved for use in this weight group.



Suitable for ISOFIX and i-Size child restraint systems.



Suitable for child restraint systems in the semiuniversal category if the vehicle and seat are given in the list of vehicle types from the manufacturer of the child restraint system.



Suitable for child restraint systems with an upper retaining strap.

# Recommended child seats

Please comply with the operating and safety instructions provided by the child restraint system manufacturer when selecting, attaching and using child restraint systems.

The manufacturer of the vehicle recommends the following child restraint systems:

- Maxi-Cosi CabrioFix.
- Maxi-Cosi EasvFix Base.
- ▶ Römer TRIFIX 2.
- Römer KIDFIX series.
- Cybex Solution Z i-Fix.

Each seat position is fitted with a head restraint.

# Safety information



#### MARNING

Anchorages for child restraint systems are designed to withstand only those loads imposed by correctly fitted child restraint systems. Under no circumstances are they to be used for adult seat belts, harnesses or for attaching other items or equipment to the vehicle. After using and removing child restraint systems, fold away the anchor brackets if necessary.

# systems

#### General

In accordance with ADR 34/03, provisions have been made to allow installation of a child restraint system at each rear seat position.

For Australia: Child restraint

The anchoring hooks which belong to the upper restraining strap of the child restraint system - AS 1754, can be applied immediately to the relevant mount.

Please refer strictly to the installation instructions supplied with the child restraint system.

#### ↑ WARNING

If the rear seat backrest is not locked, the protective effect of the child restraint system will be restricted or lost. The rear seat backrest may fold forward in certain situations, for example in the event of braking manoeuvre or an accident. There is a danger of injury or danger to life. Make sure that the rear seat backrests are locked.



#### ↑ WARNING

If the upper retaining strap is used incorrectly on the child restraint system, the protective effect will be reduced. There is a danger of injury. Make sure that the upper retaining strap is not twisted and is not routed to the upper attachment point over sharp edges.

# Attachment points

#### **Icon**

#### Meaning




The corresponding icon shows the top tether eyelet.



There are two attachment points for the upper retaining strap of ISOFIX child restraint systems.

# Routing the retaining strap



- Direction of travel
- 2 Head restraint
- **3** Hook of the upper retaining strap
- **4** Attachment point
- 5 Parcel shelf
- 6 Seat backrest
- **7** Upper retaining strap

# Attaching the upper retaining strap to the attachment point

- 1. Open the cover of the attachment point.
- 2. If necessary, raise the head restraint.
- 3. Guide the upper retaining strap between the head restraint mounts.
- 4. Attach the hook of the retaining strap to the attachment point.
- 5. Tighten the retaining strap by pulling it firmly down.



# Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

# Start/Stop button

# Principle

Drive-ready state is switched on and off by pressing the Start/Stop button.

#### General

Drive-ready state is switched on by pressing the Start/Stop button with the brake applied.

Pressing the Start/Stop button again switches drive-ready state off again and standby state is switched on.

For further information:

- ▶ Drive-ready state, see page 47.
- Standby state, see page 47.

# Driving off

- 1. Switch on drive-ready state.
- 2. Select the drive position.
- 3. Release the parking brake.
- 4. Drive off.

# Automatic Start/Stop function

# Principle

The Automatic Start/Stop function helps you to save fuel. It does this by switching off the engine when the vehicle stops, for example in congestion or at traffic lights. Drive-ready state remains switched on. For driving off, the engine starts automatically.

#### General

Each time the engine is started via the Start/ Stop button, the Automatic Start/Stop function is switched to standby.

Without mild hybrid technology: the function is activated from a speed of around 5 km/h, approx. 3 mph.

With mild hybrid technology: the function is activated from a speed of around 15 km/h, approx. 10 mph.

Depending on the selected drive mode, the system is activated or deactivated automatically.

# Engine shutdown

# Operating requirements

The engine is automatically shut down when stationary when the following conditions are met:

- Selector lever in selector lever position D.
- Without mild hybrid technology: Brake pedal remains pressed while the vehicle is at a standstill or the vehicle is kept stationary by Automatic Hold.
- Driver's seat belt fastened or driver's door closed.





# Manual engine shutdown

If the engine was not switched off automatically when the vehicle came to a stop, it can be switched off manually:

- Rapidly press the brake pedal from the current position.
- ▶ Engage selector lever in position P.

If all the operating requirements have been met, the engine is stopped.

# Air conditioning when the vehicle is parked

The amount of air of the air conditioning is reduced when the engine is not running.

# Display in the instrument cluster



The display in the instrument cluster indicates that the Automatic Start/Stop function is ready for automatic engine start.

#### **Functional limitations**

The engine is not shut down automatically in the following situations:

- > On a steep downhill gradient.
- The brake pedal has not been pressed hard enough.
- When the outside temperature is high and the automatic air conditioning is switched on.
- ▶ Interior is not heated or cooled to the desired temperature.
- Where there is a risk of condensation when the automatic air conditioning is switched on.
- ▶ Engine or other parts are not at operating temperature.
- ▶ Engine cooling is required.
- Sharp steering wheel angle or steering operation.

- ▶ Vehicle battery charge state very low.
- ▶ At high altitudes.
- ▶ The bonnet is unlocked.
- Park Assist is activated.
- ▶ For stop-and-go traffic.
- ▶ Selector lever position in N, S or R.
- After reversing.
- ▶ When using fuel with high ethanol content.

# Engine start

### Operating requirements

For driving off, the engine starts automatically under the following conditions:

- By releasing the brake pedal.
- ▶ With Automatic Hold activated: press the accelerator pedal.

#### Driving off

Accelerate as usual after starting the engine.

# Safety function

After an automatic shut down, the engine will not restart automatically if one of the following conditions is met:

- Driver's seat belt unfastened and driver's door open.
- ▶ Bonnet has been unlocked.

Several indicator lights illuminate for various lengths of time.

The engine can only be started using the Start/ Stop button.

### System limits

Even if you do not want to drive off, the engine restarts automatically in the following situations:

- In case of excessive warming of the interior when the air conditioning function is turned on.
- ▶ In case of excessive cooling of the interior when the heating is turned on.
- Where there is a risk of condensation when the automatic air conditioning is switched on.
- ▶ Without mild hybrid technology: In case of a steering operation.
- ▶ When changing the selector lever position from D or P.
- ▶ In case of seriously discharged vehicle battery.
- ▶ When starting an oil level measurement.

# Manually deactivating the system

# Principle

The engine is not switched off automatically. During an automatic engine shutdown, the engine is started.

# Without mild hybrid technology: via button





Press the key.

- ▶ LED illuminates: Automatic Start/ Stop function is deactivated.
- ▶ The LED is off: Automatic Start/Stop function is activated.

# Without mild hybrid technology: via iDrive

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Drivetrain and chassis"
- 5. "Auto Start/Stop"
- 6. Select the desired setting.

# Via selector lever position

The Automatic Start/Stop function is also deactivated in selector lever position S.

# Via Driving Experience Control

The Automatic Start/Stop function is also deactivated in the SPORT drive mode of Driving Experience Control.

# Parking the vehicle during automatic engine shutdown

During an automatic engine shutdown, the vehicle can be parked safely, for example in order to exit it.

- 1. Press the Start/Stop button.
  - ▶ Drive-ready state is switched off.
  - > Standby state is switched on.
  - ▶ Selector lever position P is automatically engaged.
- 2. Apply the parking brake.

# Automatic deactivation

In certain situations the Automatic Start/Stop function is deactivated automatically for safety reasons, for example if the absence of the driver is detected.

#### Malfunction

The Automatic Start/Stop function no longer shuts down the engine automatically. A Check Control message is shown. It is possible to continue driving. Have the system checked by





a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

# Steptronic transmission

# Principle

The Steptronic transmission is the vehicle's automatic transmission. With the shift paddle, there is the option of changing gear manually if required.

# Safety information



#### ↑ WARNING

An unsecured vehicle can start moving and roll away. There is a risk of accident. Before leaving the vehicle, secure the vehicle against rolling away by, for example, applying the parking brake.

# Selector lever positions

# D Drive position

Selector lever position for all normal driving. All gears for driving forwards are selected automatically.

# R reverse gear

Only engage selector lever position R when the vehicle is stationary.

#### N neutral

In selector lever position N, the vehicle can be pushed or can roll without drivetrain, for example in car washes.

#### P Pork

#### General

Selector lever position once the vehicle is parked, for example. In selector lever position P, the transmission blocks the drivetrain.

Only engage selector lever position P when the vehicle is stationary.

#### P is engaged automatically

Selector lever position P is automatically engaged in situations such as the following:

- After switching off the drive-ready state when selector lever position R. D. or S is engaged.
- ▶ After switching off the standby state when selector lever position N is engaged.
- ▶ While the vehicle is at a standstill and selector lever position D, S, or R is engaged, the driver's seat belt is unfastened, the driver's door is opened and the brake is not depressed.

Before exiting the vehicle, make sure that selector lever position P is engaged and the parking brake is engaged. The vehicle could otherwise start to move.

For further information:

Parking brake, see page 132.

# Engaging selector lever positions

#### General

Apply the brake until ready to drive off, otherwise the vehicle will move when drive position or reverse gear is selected.

# Operating requirements

The selector lever will only move from position P to another selector lever position if driveready state is switched on and the brake is pressed.

It may not be possible to move out of selector lever position P until all technical conditions are met.

# Engaging selector lever position D, N,

- 1. Fasten the driver's seat belt.
- 2. Tilt or pull the selector lever into the desired direction, past a resistance point, if needed. The selector lever returns to the centre position when released.



# Engaging selector lever position P



Press button P.

The transmission lock is engaged.

# Rolling or pushing the vehicle

#### General

In some situations, the vehicle may need to roll a short distance without drivetrain, for example in a conveyor car wash, or when being pushed.

# Engaging selector lever position N

#### ⚠ NOTICE

The selector lever position P is automatically engaged when standby state is switched off. The wheels are locked. There is a risk of material damage. Do not switch off standby state if the vehicle is to roll, e.g. in conveyor car washes.

- 1. Switch on drive-ready state while pressing the brake.
- 2. If necessary, release the parking brake and switch off Automatic Hold.
- 3. Press the brake.
- 4. Engage selector lever position N.
- 5. Switch off drive-ready state.

Standby state then remains switched on and a Check Control message is shown.

The vehicle can now roll.

Selector lever position P is automatically engaged after approximately 35 minutes.

If there is a fault, it may not be possible to change the selector lever position.

Unlock the parking lock electronically if necessarv.

For further information:

Unlocking the parking lock electronically, see page 128.

## Kickdown

Kickdown is used to achieve maximum performance.

Press the accelerator pedal down beyond the regular full-throttle position; some resistance will be felt.





# Sport programme S

#### Principle

In the Sport programme, the gear shift points and gear shift times are configured for more sporty driving. For example, the transmission shifts up later and the gearshift times are shorter.

# Activating the Sport programme



Pull the selector lever out of selector lever position D to D/S.

The gear selected is displayed in the instrument cluster, for example S1.

The Sport programme of the transmission is activated.

# **Ending Sport programme**

Pull the selector lever to D/S.

D is shown in the instrument cluster.

# Displays in the instrument cluster



The selector lever position is displayed, for example P.

# Unlocking the parking lock electronically

#### General

Unlock the transmission lock electronically, e.g. to manoeuvre the vehicle out of a danger area in the event of a fault.

Before unlocking the parking lock, secure the vehicle to prevent it from rolling away, for example with a chock.

# Engaging selector lever position N

- Press the Start/Stop button three times quickly; do not press the brake when doing so.
- 2. Press the brake.
- Press the selector lever to position N.
   A corresponding Check Control message is shown.
  - Position N is displayed on the selector lever
- 4. Manoeuvre the vehicle out of danger and then secure it against rolling away.

# Shift paddles

# Principle

The shift paddles on the steering wheel enable the gears to be changed manually.

# General

### Gearshift

Gear shifting is only carried out at the appropriate rotational speed and vehicle speed.

Even in manual mode, the transmission switches automatically in certain situations, e.g. when speed limits are reached.

# Temporary manual mode

In selector lever position D, pulling a shift paddle causes the system to switch to manual mode temporarily.

The gear selected is also displayed in the instrument cluster, for example D1.

The transmission reverts to automatic mode from manual mode after a certain period of time of moderate driving without acceleration or gear shifts using the shift paddles.

It is possible to change to automatic mode:

- ▶ Pull and hold the right shift paddle until D is shown in the instrument cluster.
- ▶ While pulling and holding the right shift paddle, pull the left shift paddle.

#### Permanent manual mode

In Sport programme S, pulling a shift paddle causes the system to switch permanently to manual mode M.

The gear selected is displayed in the instrument cluster, for example M1.

It is possible to change to automatic mode:

- ▶ Pull and hold the right shift paddle until S is shown in the instrument cluster.
- ▶ While pulling and holding the right shift paddle, pull the left shift paddle.
- ▶ Pull the selector lever to D/S.

If M2 is set manually while the vehicle is stationary, the transmission will no longer shift back to M1. These shift characteristics are retained until M1 is engaged manually or manual mode M is exited.

# Shifting gears



- ▶ To shift up: pull the right shift paddle.
- ▶ To shift down: pull the left shift paddle.

The gear selected appears briefly in the instrument cluster, followed by the gear currently in use.

### Advanced mode

#### General

Depending on the equipment, the Steptronic sport transmission offers an advanced mode with adapted shift characteristics.

- Automatic downshift to the lowest possible gear.
  - If the left shift paddle is pulled and held, the Steptronic transmission automatically shifts down to the lowest possible gear.
- Avoid automatic upshifting in manual mode.
  - The Steptronic transmission does not shift up automatically in manual mode when speed limits are reached.
- ▶ There is no downshift for kickdown.

# Activating advanced mode

Advanced mode is active in manual mode.

"SPORT": Depending on the equipment, the drive mode must be selected and configured accordingly.





# Launch Control

# Principle

When the ambient conditions are dry, Launch Control permits optimised acceleration on a road surface that offers plenty of grip.

#### General

Using Launch Control causes premature component wear, as this feature subjects the vehicle to very high stresses and loads.

When driving off with Launch Control, do not turn the steering wheel.

Do not use Launch Control when running in. For further information:

Running in, see page 262.

# Operating requirements

Launch Control is available when the engine is at operating temperature. The engine is at operating temperature after an uninterrupted journey of at least 10 km, 6 miles.

# Start up with Launch Control

1. Switch on drive-ready state.



Press the button.

- 3. Activate TRACTION on the control display.
- 4. Engage selector lever position S.
- 5. Press the brake firmly with the left foot.
- 6. Press the accelerator pedal down beyond the resistance at the full-throttle position and hold, kickdown.

A destination flag is shown in the instrument cluster.

7. The engine speed for pulling away is adjusted. Wait briefly until the engine speed is

- constant. Keep the accelerator pedal in this position.
- 8. Release the brake within 3 seconds of the destination flag illuminating.

The vehicle accelerates.

Upshifts are automatic as long as the destination flag is displayed and the accelerator pedal is not released.

# Using again during a journey

Once Launch Control has been used, the transmission requires a short time to cool down before Launch Control can be used again. Launch Control adapts to the ambient conditions when used again.

# After using Launch Control

To support driving stability, re-activate Dynamic Stability Control as soon as possible.

# System limits

An experienced driver may be able to achieve better acceleration values in DSC OFF mode without Launch Control.

# Steptronic sport transmission: sprint function

# Principle

Depending on the equipment, the sprint function can be used when the driver is about to accelerate. The sprint function prepares the drivetrain for the acceleration.

### General

Activating the sprint function makes the vehicle's response characteristics more dynamic.

# Activating

 Pull and hold the left shift paddle until SPRINT is shown in the instrument cluster.

- The transmission changes down to the lowest possible gear and switches to manual mode M.
- ▶ A dynamic setting is activated for the drivetrain.
- 2. Change gears manually.

# Deactivating automatically

The sprint function ends automatically if the vehicle is driven moderately for a certain amount of time.

# Deactivating manually

- Pull and hold the right shift paddle until SPRINT is no longer shown in the instrument cluster.
- ▶ While pulling and holding the right shift paddle, pull the left shift paddle.
- Press the selector lever from position S to position D.

# **Driving Experience Control**

# Principle

The Driving Experience Control influences, among other things, the characteristics of the driving dynamics of the vehicle.

Various drive modes allow the vehicle to be adapted to suit the situation.

# General

The following systems are influenced, for example:

- Drivetrain.
- Suspension.
- Steering.
- Display in the instrument cluster.
- Cruise Control.

#### Overview

#### Buttons in the vehicle



Button	Drive mode
SPORT	SPORT SPORT PLUS SPORT INDIVIDUAL
COMFORT	COMFORT
ECO PRO	ECO PRO ECO PRO INDIVIDUAL

# Displays in the instrument cluster



The selected drive mode is shown in the instrument cluster.

# Activating/deactivating the drive mode

Press the button of the desired drive mode repeatedly until the desired drive mode is displayed in the instrument cluster.

When the drive mode is changed, the current drive mode is deactivated.





#### Drive modes in detail

#### COMFORT

The COMFORT drive mode is a balanced setting between sporty and consumption-optimised driving.

#### **SPORT**

The SPORT drive mode is a dynamic setting for greater agility with an optimised suspension.

#### SPORT PLUS

The SPORT PLUS drive mode is a dynamic setting for maximum agility with an adapted drivetrain.

#### **ECO PRO**

The ECO PRO drive mode provides a consumption-optimised setting.

# INDIVIDUAL configuration

#### General

For some drive modes there is another individually adjustable mode.

The most recent custom configuration is activated when the drive mode is called up again.

# Configuring and resetting

For example, ECO PRO INDIVIDUAL drive mode:

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Drivetrain and chassis"
- 5. "ECO PRO INDIVIDUAL"
- 6. Select the desired setting.

To reset ECO PRO INDIVIDUAL to the default setting:

"Reset to ECO PRO STANDARD"

#### Activating INDIVIDUAL

Press the button of the desired drive mode several times.

# Parking brake

# Principle

The parking brake is used to prevent the vehicle from rolling away when it is parked.

# Safety information

#### ↑ WARNING

An unsecured vehicle can start moving and roll away. There is a risk of accident. Before leaving the vehicle, secure the vehicle against rolling away.

Observe the following to ensure that the vehicle is secured against rolling away:

- > Apply the parking brake.
- > Turn the front wheels towards the kerb on uphill or downhill gradient.
- ▶ Additionally secure the vehicle on uphill or downhill gradient, for example with a chock.



#### ↑ WARNING

Unsupervised children or pets in the vehicle can set the vehicle in motion and endanger themselves or other road users, for example by the following actions:

- Pressing the Start/Stop button.
- Releasing the parking brake.
- Opening and closing doors or windows.
- ▶ Engaging selector lever position N.
- > Operating vehicle equipment.

There is a risk of accident or injury. Do not leave children or pets unsupervised in the vehicle. When leaving the vehicle, take the vehicle key with you and lock the vehicle.

#### Overview

#### Button in the vehicle





Parking brake

# Applying the parking brake

# When the vehicle is stationary



Pull the switch.

The LED is illuminated.



The indicator light in the instrument cluster is illuminated red.

The parking brake is engaged.

# While driving

The parking brake can be used as an emergency braking function while driving:



Pull and hold the switch. The vehicle brakes hard for as long as the switch is pulled.



The indicator light in the instrument cluster is illuminated red, a signal sounds and the brake lights illuminate.


A Check Control message is shown.

Apply the parking brake when the vehicle is stationary.

# Release the parking brake

# Releasing the parking brake manually

1. Switch on drive-ready state.



# Releasing the parking brake automatically

The parking brake is automatically released on when you drive off.

The LED and the indicator light go out.

#### Malfunction

If a parking brake has failed or malfunctioned, secure the vehicle to prevent it from rolling away before leaving the vehicle.


A Check Control message is shown.

After getting out, secure the vehicle to prevent it from rolling away, for example with a chock.

# After an open circuit

To restore the operability of the parking brake after a power failure, an initialisation may be required.

1. Switch on standby state.



The procedure can take a few seconds. Any sounds that occur are normal.







The indicator light extinguishes as soon as the parking brake is operational again.

# Automatic Hold

# Principle

Automatic Hold provides assistance by automatically applying and releasing the brake, for example in stop-and-go traffic.

The vehicle is held automatically when at a standstill.

On upward gradients, it prevents the vehicle from rolling back when driving off.

#### General

The parking brake is released automatically when the following conditions are met:

- Drive-ready state is switched off.
- ▶ When the driver's door is opened while the vehicle is stationary.
- ▶ If the moving vehicle is brought to a standstill with the parking brake.

# Safety information



#### MARNING

An unsecured vehicle can start moving and roll away. There is a risk of accident. Before leaving the vehicle, secure the vehicle against rolling away.

Observe the following to ensure that the vehicle is secured against rolling away:

- > Apply the parking brake.
- > Turn the front wheels towards the kerb on uphill or downhill gradient.
- > Additionally secure the vehicle on uphill or downhill gradient, for example with a chock.

#### ↑ WARNING

Unsupervised children or pets in the vehicle can set the vehicle in motion and endanger themselves or other road users, for example by the following actions:

- Pressing the Start/Stop button.
- Releasing the parking brake.
- > Opening and closing doors or windows.
- ▶ Engaging selector lever position N.
- > Operating vehicle equipment.

There is a risk of accident or injury. Do not leave children or pets unsupervised in the vehicle. When leaving the vehicle, take the vehicle kev with you and lock the vehicle.



#### ∧ NOTICE

Automatic Hold applies the parking brake when the vehicle is stationary and will prevent the vehicle from rolling in car washes. There is a risk of material damage. Deactivate Automatic Hold before driving into the car wash.

# Overview

### Button in the vehicle





Automatic Hold

#### Activate Automatic Hold

1. Switch on drive-ready state.



Press the button.

The LED is illuminated.



The indicator light illuminates green.

Automatic Hold is activated.

When the vehicle is restarted, the last selected setting is retained.

#### Automatic Hold holds the vehicle

Automatic Hold is activated and the driver's door is closed.



Once the vehicle has stopped, it is automatically secured from rolling away once the indicator light lights up green.

# Driving off

To drive off, press the accelerator pedal.

The brake is released automatically and the parking brake indicator light is extinguished.

# Automatic parking brake application

The parking brake is applied automatically if drive-ready state is switched off or the vehicle is exited while Automatic Hold is holding the vehicle.



The indicator light changes from green to red.

The parking brake is not applied automatically if drive-ready state was switched off while the vehicle was rolling to a stop. Automatic Hold is temporarily deactivated in this case.

# Deactivate Automatic Hold



Press the key.

The LED is extinguished.



The indicator light extinguishes.

Automatic Hold is deactivated.


If the vehicle is being held by Automatic Hold, also depress the brake when deactivating.

# Turn indicators

### Turn indicator in exterior mirror

To ensure that the indicator lamps in the exterior mirrors can be seen, do not fold in the exterior mirrors while driving and while the turn indicators or hazard warning lights are operating.

# Indicating



Press the lever beyond the resistance point.

# One-touch signalling

Briefly tap the lever up or down.

The duration of the one-touch signalling can be set.

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Exterior lighting"
- 4. If necessary, "Additional settings"
- 5. "One-touch indicator"
- 6. Select the desired setting.





# Indicating a turn briefly

Press the lever as far as the resistance point and hold it there for as long as you wish to indicate a turn.

# High-beam headlight, headlight flasher

Press the lever forwards or pull it back.



- ▶ High-beam headlight on, arrow 1. The high-beam headlight is illuminated when the low-beam headlight is switched
- ▶ High-beam headlight off/headlight flasher, arrow 2.



The indicator light in the instrument cluster is illuminated when the highbeam headlight is switched on.

# Wiper system

# Safety information



#### ↑ WARNING

If the windscreen wipers start moving when they are folded away from the windscreen. parts of the body may become trapped or the vehicle may be damaged. There is a danger of injury or material damage. Make sure that the vehicle is switched off when the wipers

are folded away from the windscreen, and that the windscreen wipers are in contact with the windscreen when switching on.




#### ⚠ NOTICE

The wiper blades can wear out or become damaged prematurely when wiping on dry glass for longer periods of time. The wiper motor may overheat. There is a risk of material damage. Do not use the wipers when the glass is dry.

#### ∧ NOTICE

If the wipers are frozen to the windscreen, switching them on may cause the wiper blades to tear off and the wiper motor to overheat. There is a risk of material damage. Defrost the windscreen before switching on the windscreen wipers.

# Switching on the wiper system




Press the lever upwards to the desired position.

- ▶ Rest position of the windscreen wipers, position 0.
- Rain sensor, position 1.
- Normal wiper speed, position 2. When the vehicle is at a standstill, the wipers switch to intermittent operation.
- ▶ Fast wiper speed, position 3.

When the vehicle is at a standstill, the wipers switch to normal speed.

If a journey is interrupted with the wiper system switched on: when the journey is resumed, the windscreen wipers continue operating at the previous level.

# Switching off the wiper system and flick wiping



Press the lever down.

- ▶ To switch off: press lever downwards until position 0 is reached.
- ▶ To flick wipe: press the lever downwards from position 0.

The lever returns to position 0 when released.

#### Rain sensor

# Principle

The rain sensor automatically controls the wiper operation depending on the rain intensitv.

### General

The sensor is mounted on the windscreen, directly in front of the interior mirror.

# Safety information

#### ∧ NOTICE

In car washes, the wipers may inadvertently start moving if the rain sensor is activated. There is a risk of material damage. Deactivate the rain sensor in car washes.

# Activating the rain sensor



Press the lever upwards once from position 0, arrow 1.


Wiping is started.

The LED in the wiper lever is illuminated. If there is frost, wiping may not start.

# Deactivating the rain sensor

Press the lever back to position 0.

# Adjusting the sensitivity of the rain sensor



Turn the knurled wheel to adjust the sensitivity of the rain sensor.

Upwards: high sensitivity of the rain sensor.





Downwards: low sensitivity of the rain sensor.

# Window washer system

# Safety information

#### ↑ WARNING

At low temperatures, the washer fluid can freeze onto the windscreen and restrict visihility. There is a risk of accident. Only use the washer systems if there is no possibility of the washer fluid freezing. Use antifreeze additive if required.

#### ▲ NOTICE

If the washer fluid reservoir is empty, the washer pump cannot operate as intended. There is a risk of material damage. Do not use the washer system with the washer fluid reservoir empty.

# Cleaning the windscreen



Pull the lever.

The washer fluid is sprayed onto the windscreen and the windscreen wipers are turned on briefly.

# Windscreen wipers fold-out position

### Principle

The wipers can be folded out from the windscreen in the fold-out position. This is necessary for example when replacing the wiper blades or to keep them away from the windscreen when there is frost.

# Safety information



#### ↑ WARNING

If the windscreen wipers start moving when they are folded away from the windscreen, parts of the body may become trapped or the vehicle may be damaged. There is a danger of injury or material damage. Make sure that the vehicle is switched off when the wipers are folded away from the windscreen, and that the windscreen wipers are in contact with the windscreen when switching on.




#### ▲ NOTICE

If the wipers are frozen to the windscreen, switching them on may cause the wiper blades to tear off and the wiper motor to overheat. There is a risk of material damage. Defrost the windscreen before switching on the windscreen wipers.



- 1. Switch on standby state.
- 2. Press the wiper lever down and hold until the windscreen wipers stop in an approximately vertical position.



3. Lift the windscreen wipers completely away from the windscreen.



# Folding down the windscreen wipers

- 1. Fold the windscreen wipers fully down onto the windscreen.
- 2. Switch on standby state and press and hold the wiper lever down again.

The windscreen wipers move back to the rest position and are operational once again.



# Displays

# Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

# Instrument cluster

# Principle

The instrument cluster comprises various digital displays, such as speedometer, time, range, temperature displays or indicator and warning lights.

# General

The layout of the instrument cluster adapts to the respective drive mode. The positions of some displays may vary, e.g. the selector lever indication.

The displays in the instrument cluster can sometimes differ from the illustrations in the Owner's Handbook.

# Safety information



#### MARNING


If the displays in the instrument cluster fail, the vehicle must not be used. There is a risk of accident or material damage. Immediately park the vehicle safely. If drive-ready state is switched off and on again, the malfunction may rectified and it is possible to continue driving. If the malfunction cannot be rectified, have the system checked by a Service Partner of the manufacturer, or another qualified Service Partner, or a specialist workshop.

#### Overview



Instrument cluster

# Indication ranges in the instrument cluster



- Speedometer
- 2 Driver assistance systems 198
- 3 Driver Attention Camera 192
- 4 Check Control 148 Selector lever indication 126 Optimum shift indicator 150 Selection lists 149 Using ECO PRO efficiently 279
- **5** Power display 150 Revolution counter 151
- **6** Engine temperature 151

- **7** Outside temperature 152
- 8 Central display area 152
- 9 Drive mode 131
- **10** Speed Limit Info 198 Speed Limit Assist 212
- **11** Time 155
- **12** Fuel level indicator 155 Range 156

For further information:

Indicator and warning lights, see page 143

# Operating elements on the steering wheel

Operating element	Function				
≔	Display the menu bar in the instrument cluster.				
$\triangleleft \triangleright$	Press the corresponding arrow button to move the selection.				
	Turn the knurled wheel: scroll the selection up or down.				
	Press the knurled wheel: confirm the selection.				

# Configuring the layout

In COMFORT drive mode, the layout can be individually configured and displayed in the instrument cluster.

1. Press the button on the steering wheel.

A menu bar is displayed in the instrument cluster.

2. "LAYOUT"

Select the menu using the arrow buttons on the steering wheel as necessary.

3. Select the required setting using the knurled wheel on the steering wheel.

# Settings

Individual displays can be set individually, e.g. a second actual speed.

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Displays"
- 4. "Instrument cluster"
- 5. Select the desired setting.

# Live Vehicle

### Principle

Live Vehicle is a virtual representation of your own vehicle with different information, e.g. vehicle status or energy flow indicators.

#### General

Depending on the driving situation, suitable information is shown on the control display. Fault statuses are not taken into account.

# Adaptive content

The following is displayed in alternating order and, if applicable, depending on the selected drive mode:

- ▶ Vehicle status, see page 156.
- ▶ Current driving condition, see page 157.
- ▶ Sport displays, see page 157.
- ▶ Driving style analysis, see page 281.
- ▶ Trip data, see page 153.

#### Static content

The following content can be displayed continuously on the control display regardless of the driving situation and set drive mode.





- Vehicle status.
- ▶ Trip data.

# Configuring the display

In the Live Vehicle menu, it is possible to choose between an adaptive display with changing content and static content.

- "MENU"
- 2. "Vehicle apps"
- 3. "Live Vehicle"
- 4. "Content"
- 5. Select the desired setting:
  - ▶ "Adaptive content": different contents are displayed in varying order.
  - "Journey data": trip data is permanently displayed.
  - "Vehicle status": vehicle status is permanently displayed.

# BMW Head-up display

# Principle


The Head-up display projects important information in the driver's field of view, for example the speed.

### General

Depending on the equipment: the height of the Head-up display can be saved with the memory function.

Follow the instructions on cleaning the headup display in the Care chapter.

# Overview



The protective glass of the head-up display is located between the steering wheel and the windscreen.

# Configuring a view

The views for the Head-up display can be set independently of the display in the instrument cluster, for e.g. a reduced view.



A menu bar is displayed in the instrument cluster.

- 2. "HEAD-UP"
  - Select the menu using the arrow buttons on the steering wheel as necessary.
- Select the required setting using the knurled wheel on the steering wheel.

# Display

# Turning the Head-up display on/off

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Displays"
- 4. "Head-up display"
- 5. "Head-up display"

#### Overview

The following information is displayed in the Head-up display:

- ▶ Speed.
- Navigation instructions.
- ▶ Check Control messages.
- Sport displays.
- ▶ Lists and messages.
- Driver assistance systems.

Some of this information is only shown briefly when needed.

## Visibility of the display

The visibility of the information shown on the Head-up display can be affected by the following:

- Seat position.
- Objects on the protective glass of the headup display.
- Dust or dirt on the protective glass of the head-up display.
- ▶ Dirt on the inside or outside of the windscreen.
- Sunglasses with certain polarisation filters.
- Wet roads.
- Adverse lighting conditions.

If the image is distorted, have the default settings checked by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

# Settings

Individual settings can be entered for the Head-up display, for example for the height, brightness or illustration. In addition, individual displays in the Head-up display can be set up separately, for instance information on driver assistance.

- 1. "MFNU"
- 2. "Vehicle apps"

- 3. "Displays"
- 4. "Head-up display"
- 5. Select the desired setting.

# Special windscreen

The windscreen is an integral part of the system.

The shape and coating of the special windscreen enable the system to function.

In the event of damage, have the special windscreen replaced by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

# Indicator and warning lights

### Principle

Indicator and warning lights in the instrument cluster display the status of some functions in the vehicle. Indicator and warning lights indicate faults in monitored systems.

#### General

Indicator and warning lights can illuminate in a variety of combinations and colours.

When switching on drive-ready state, the functionality of some lights is checked and they illuminate briefly.

# Red lights

# Seat belt warning



Seat belt is not buckled.

For further information:

Seat belt warning, see page 105.

# Airbag system



The indicator light illuminates briefly: this indicates that the entire airbag sys-





tem and seat belt tensioners are operational when the vehicle is switched on.

The indicator light illuminates continuously: there is a malfunction. Have the vehicle checked immediately by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

For further information:

Airbags, see page 169.

# Parking brake



The parking brake is engaged.

For further information:

Parking brake, see page 132.

### Brake system



Fault in the brake system, braking power assistance may be faulty. Continue driving at moderate speed. Avoid

abrupt braking, take longer stopping distance into account.

Have the vehicle checked immediately by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

### Risk of collision



Check that indicator light is illuminated or flashes in conjunction with an acoustic signal if a collision is imminent.

For further information:

Front-collision warning, see page 174.

# Pedestrian warning



Indicator light is illuminated: risk of collision with a person has been detected. Increased awareness is required.

Indicator light flashes and a signal sounds: collision with a person is imminent. Intervene immediately yourself according to the situation.

For further information:

Pedestrian Warning with city braking function, see page 178.

### **Collision Warning**



Indicator light lights up: risk of collision, e.g. with a vehicle. Increased awareness is required.

Indicator light flashes and a signal sounds: collision with a vehicle is imminent. Intervene immediately yourself according to the situation.

For further information:

Collision Warning with braking function, see page 177.

# Active Cruise Control with distance control



Indicator light flashes and an acoustic signal sounds: brake and take avoidance manoeuvre, if necessary.

For further information:

Active Cruise Control with distance control, see page 206.

# Yellow lights

# Anti-lock Braking System



System failure. Ease of steering is restricted during full braking.

Avoid sudden braking. Bear in mind that stopping distances will be longer.

Have the vehicle checked immediately by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

# Front-collision warning restricted or failed



Depending on the equipment and national-market version: functional limitation detected, e.g. due to low sun or

system failure. It is possible to continue driving. Where applicable, observe the information from Check Control messages.

For further information:

Front-collision warning, see page 174.

### Front-collision warning switched off



Depending on vehicle equipment and national-market version: the system is switched off.

For further information:

Front-collision warning, see page 174.

# Dynamic Stability Control regulating, restricted or failed



Indicator light flashes: Dynamic Stability Control controls the drive and brake forces. The vehicle is being stabilised.

Decrease speed and adjust driving style to the road conditions.

Indicator light is illuminated: Dynamic Stability Control failure or initialising. No driving stabilisation.

Have the system checked immediately by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

For further information:

Dynamic Stability Control, see page 194.

# Dynamic Stability Control deactivated or Dynamic Traction Control activated



Dynamic Stability Control is deactivated or Dynamic Traction Control is activated.

For further information:

- Dynamic Stability Control, see page 194.
- ▶ Dynamic Traction Control, see page 196.

### Flat tyre monitor



The Flat Tyre Monitor reports a tyre pressure loss in a tyre.

Reduce your speed and carefully stop the vehicle. Avoid heavy braking and sudden steering manoeuvres.

For further information:

Flat Tyre Monitor, see page 304.

### Tyre Pressure Monitor



Indicator light illuminates: the Tyre
Pressure Monitor is reporting a low tyre
inflation pressure or a flat tyre. Note

the information in the Check Control message.

Indicator light flashes and then illuminates continuously: the system is unable to detect flat tyres or tyre pressure losses.

- Fault due to systems or devices with the same radio frequency: the system is automatically reactivated upon leaving the field of interference.
- For tyres with special approval: the Tyre
   Pressure Monitor was unable to complete
   the reset. Reset the system again.
- A wheel without wheel electronics is mounted: if necessary have it checked by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.
- Malfunction: have the system checked by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

For further information:

Tyre Pressure Monitor, see page 297.





### Steering system

**⊕i** ⊢

The steering system may be faulty.

Have the system checked by a Service Partner of the manufacturer or another

qualified Service Partner or a specialist workshop.

## Engine warning light



Engine malfunction.

Have the vehicle checked by a Service Partner of the manufacturer or another

qualified Service Partner or a specialist workshop.

For further information:

Socket for on-board diagnosis, see page 326.

### Lane Departure Warning

Depending on equipment and nationalmarket version:

Indicator light lights up: functional limitation detected, e.g. due to low sun or system failure. It is possible to continue driving. Where applicable, observe the information from Check Control messages.

Indicator light flashes: a warning is issued actively. The system does not carry out any steering interventions.

For further information:

Lane Departure Warning, see page 180.

## Rear fog light



Rear fog light is switched on.

For further information:

Rear fog light, see page 166.

## Green lights

#### Turn indicators



The turn indicator is switched on.

If the indicator light flashes more rapidly than usual, a turn indicator bulb

has failed.

For further information:

Turn indicators, see page 135.

### Side lights



The side lights are switched on.

For further information:

Side light, low-beam headlight, see page 161.

### Low-beam headlight



The low-beam headlight is switched on.

For further information:

Side light, low-beam headlight, see page 161.

### High-beam Assistant



Low-beam headlight is switched on and the High-beam Assistant is activated.

The high-beam headlight is switched on and off automatically according to traffic situation.

For further information:


High-beam Assistant, see page 164.

## Lane Departure Warning



Depending on equipment and national-market version:

Indicator light illuminates: the system is switched on. A lane boundary has been detected on at least one side of the vehicle and the system is ready to intervene. Warnings are issued.



For further information:

Lane Departure Warning, see page 180.

### Automatic Hold: vehicle is held automatically



Automatic Hold is ready to operate. AUTO H The vehicle is held automatically when at a standstill.

For further information:

Automatic Hold, see page 134.

## Automatic Hold: vehicle secured against rolling away



The vehicle is automatically secured against rolling away after stopping.

For further information:

Automatic Hold, see page 134.

### Manual Speed Limiter



Indicator light illuminates: the system is NIM switched on.

Indicator light flashes: set speed limit is exceeded.

For further information:

Manual Speed Limiter, see page 201.

### Cruise Control



The system is active.

For further information:

Cruise Control, see page 203.

### Active Cruise Control with distance control



Indicator light illuminates: system has detected a vehicle ahead. The vehicle symbol goes out if no vehicle in front is

detected.

Indicator light flashing: vehicle in front has

For further information:

Active Cruise Control with distance control, see page 206.

### **Speed Limit Assist**



Depending on the equipment, the indicator light illuminates green, together with the icon for a Cruise Control Svs-

tem. Speed Limit Assist is active and detected speed limits can be adopted manually for the displayed system.

For further information:

Speed Limit Assist, see page 212.

### Speed Limit Assist



The detected speed limit can be applied with the SET button. As soon as the speed limit has been adopted, a

green tick is displayed.

For further information:

Speed Limit Assist, see page 212.

## Blue lights

## High-beam headlight



The high-beam headlight has been switched on.

For further information:

- ▶ High-beam headlight, see page 136.
- ▶ High-beam Assistant, see page 164.



## Grey lights

### Manual Speed Limiter



Indicator light illuminates: the system is LIM interrupted.

For further information:

Manual Speed Limiter, see page 201.

### Cruise Control



The system is interrupted.

For further information:

Cruise Control, see page 203.

### Active Cruise Control with distance control

Indicator light illuminates: the system is interrupted.

Indicator light flashes: the requirements for operation of the system are no longer being met. The system has been deactivated but will continue to brake until you actively take over by depressing the brake or accelerator pedal.

For further information:

Active Cruise Control with distance control, see page 206.

### Lane Departure Warning

Depending on equipment and nationalmarket version:

Indicator light lights up: the system is switched off or automatically deactivated, e.g. because DSC OFF is activated.

Indicator light flashes: a warning is issued actively. The system does not carry out any steering interventions.

For further information:

Lane Departure Warning, see page 180.

### White lights

### Cruise Control with distance control



No display of distance control as the accelerator pedal is being pressed.

For further information:

Active Cruise Control with distance control, see page 206.

### Check Control

### Principle

Check Control monitors vehicle functions and alerts you to any faults in the monitored systems.

### General

A Check Control message is displayed as a combination of indicator or warning lights and text messages in the instrument cluster and, if applicable, in the Head-up display.

An acoustic signal may also be output and a text message shown on the control display.

### Hiding Check Control messages

◀ An arrow symbol next to the Check Control message indicates whether the Check Control message can be hidden.



To hide Check Control messages, press the left arrow button on the steering wheel.

## Continuous display

Some Check Control messages are displayed permanently and remain until the fault has been repaired. If a number of malfunctions have occurred at the same time, the messages are displayed in succession.

Permanently displayed Check Control messages may be temporarily hidden. After approx. 8 seconds, these messages are automatically displayed again.

### Temporary display

Some Check Control messages are automatically hidden after approximately 20 seconds. The Check Control messages remain stored and can be displayed again.

# Displaying saved Check Control messages

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Vehicle status"
- 5. Select the required text message.

### Display

### **Check Control**



At least one Check Control message is displayed or saved.

### Text messages

Text messages and an icon in the instrument cluster explain what a Check Control message means and what the indicator and warning lights signify.

### Supplementary text messages

Additional information, for example the cause of the fault and any action required, can be called up via Check Control.

With urgent text messages, the added text will be automatically displayed on the control display.

It is possible to select additional assistance depending on the Check Control message.

- 1. "MENU"
- 2. "Vehicle apps"

- 3. "Vehicle status"
- 5. Select the required text message.
- 6. Select the desired setting.

# Messages displayed at the end of the journey

Certain messages displayed when driving are displayed again when drive-ready state is switched off.

### Selection lists

### Principle

The instrument cluster or the Head-up display can show lists for certain functions and can be used for operation where applicable.

- ▶ Entertainment source.
- Current audio source.
- Recent calls list.

If applicable, the relevant menu is opened on the control display.

### Displaying and using the list


The selection lists can be displayed and operated using the operating elements on the steering wheel.

Operating elements	Function
	Turn the knurled wheel: display the entertainment list or scroll up or down in the list.
	Press the knurled wheel: confirm the selection.
$\triangleleft$ $\triangleright$	Press the corresponding arrow button to change the entertainment source.
•	To display the last calls list.





### Display



### An example:

To change the track or entertainment source after calling up the entertainment list, use the arrow keys on the steering wheel. Press the knurled wheel to confirm the selection.

Turn the knurled wheel up or down to select the desired entry in the list. Press the knurled wheel to confirm the selection.

Depending on the equipment, the list in the instrument cluster may differ from the figure.

# Optimum shift indicator

### Principle

The optimum shift indicator recommends the gear that best suits the current driving situation. The use of the optimal gear supports an efficient driving style.

### General

Depending on the equipment and the nationalmarket version, the optimum shift indicator is active in manual mode M.

### **Displays**

Information on upshifting, downshifting or the engaged gear is displayed in the instrument cluster.

For vehicles without optimum shift indicator, the gear engaged is shown.

Example	Description
M3	In permanent manual mode M: Optimal gear is engaged.
D3	With shift paddles: temporary manual mode.
S3	With shift paddles: Sport programme.
2•3	Switching instruction.

For further information:

## Shift paddles, see page 128

# Power display

### Principle

The power display indicates the currently drawn drive power as a percentage.


# Activating/deactivating power display

Depending on the selected drive mode or the individually configured layout, the power display or revolution counter is displayed.

## Display



Needle in the arrow 1 area: display of the energy recuperation achieved, for example during deceleration. CHARGE.



### Reduced drive power

The available drive power may be reduced due to certain factors. The power display is automatically adjusted as necessary.

In addition, icons on the power display and in the revolution counter indicate if the drive power has been reduced.

lcon	Description
<b>₹</b>	Blue icon: cold drive system.
	White icon: increased drive system temperature, for example due to long-lasting or high power requirements when driving uphill.
Î	Depending on equipment and national-market version:
	Restriction of drive power set by BMW Digital Key.
!	System-related functional limitation.
	A Check Control message will be shown as necessary.

## Revolution counter

### General

It is vital to avoid rotational speeds in the red warning zone. In this zone, the fuel supply is interrupted to protect the engine.

# Activating/deactivating the revolution counter

The revolution counter is displayed depending on the selected drive mode or the individually configured layout.

### Reduced speed range

The available speed range may be reduced due certain factors, example a cold drivetrain. The revolution counter display is automatically adjusted depending on the available speed range.

In addition, symbols in the revolution counter indicate a reduced engine speed range.

# Standby state and driveready state



OFF in the instrument cluster indicates that drive-ready state is switched off and standby state is switched on.



The letters READY in the instrument cluster indicate that the Automatic Start/Stop function is ready for automatic engine start.

For further information:

- ▶ Vehicle operating condition, see page 46.
- Automatic Start/Stop function, see page 123.

## Engine temperature

### Display



Cold engine: the needle is in the blue temperature range, close to the limit position of the temperature display and the WARM-UP text is displayed.





Drive at moderate rotational speed and vehicle speed.

- Normal operating temperature: the needle is located in the centre or left half of the temperature display.
- Hot engine: the needle is in the red temperature range. A Check Control message is also displayed.

For further information:

Coolant level, see page 322.

# Outside temperature

### General

If the display drops to +3 °C, 37 °F or lower, a signal sounds.

A Check Control message is shown.

There is an increased risk of black ice.

## Safety information



#### ↑ WARNING

Even at temperatures above +3 °C, 37 °F there may be an increased risk of black ice, for example on bridges or on shaded sections of road. There is a risk of accident. At low temperatures, adjust driving style to the weather conditions.

# Shift Lights

### Principle

Shift Lights are temporarily displayed in the instrument cluster and indicate the appropriate time for upshifting, with which rapid acceleration values are achieved.

### General

The Shift Lights are active in manual mode M and can be displayed in the instrument cluster or in the Head-up display in combination with the revolution counter.

### Operating requirements

- "SPORT": depending on the equipment, the drive mode must be selected.
- ➤ To display the shift lights in the Head-up display, the sport view must be selected.
- Manual mode M must be activated.
- ▶ Advanced mode must be enabled.

For further information:

Advanced mode, see page 129.

## Display



Yellow fields illuminate successively to indicate when a gearshift is due.

- ➤ Shift gear at the latest when all fields light up red.
- ▶ When the maximum engine speed is reached, the entire display flashes red and the fuel supply is limited to protect the engine.

## Central display area

### General

The following settings can be selected:

- Reduced view.
- ▶ Trip data, see page 153.
- ▶ With navigation system: route preview.
- ▶ With navigation system: map view.
- ▶ G meter, see page 155.
- Entertainment.


Some contents for the central display area can also be configured as a view in the Head-up display.

For further information:

Head-up display, see page 142.

## Configuring the central display area

The contents for the central indication range in the instrument cluster can be individually configured, for example, the display of trip data.



A menu bar is displayed in the instrument cluster.

2. "CONTENT"

Select the menu using the arrow buttons on the steering wheel as necessary.

3. Select the required setting using the knurled wheel on the steering wheel.

## Trip data

## Principle

The display of trip data provides various information about the trip, e.g. the average consumption or the trip distance.

### General

The trip data can be shown on the control display and in the instrument cluster.

Depending on the setting in the Live Vehicle menu, the trip data is shown dynamically or continuously on the control display.

The values can be displayed and reset depending on different intervals.

### Display on the control display

#### General

The following trip data is shown on the control display:

- ▶ Set interval for displaying the trip data.
- Ø Average fuel consumption as a function of the set interval.
- Oriving time depending on the set interval.
- → Distance covered, depending on the set interval.
- The distance covered in the coasting drive state.

## Displaying trip data continuously

- 1. "MFNU"
- 2. "Vehicle apps"
- 3. "Live Vehicle"
- 4. "Content"
- 5. "Journey data"

### Display in the instrument cluster

Information on consumption and distance covered can be displayed on the instrument cluster.







- ▶ Current consumption, arrow 1.
- ▶ Average consumption, arrow 2.
- ▶ Distance covered depending on the configured interval, arrow 3.
  - This icon is displayed when the vehicle is in coasting driving condition.
- ▶ Total kilometres, arrow 4.

### Current consumption

The display of the current consumption allows you to check the current fuel consumption, e.g. for driving economically and in an environmentally friendly manner.

### Average consumption

The average consumption is displayed depending on the setting of the intervals for displaying the trip data.


## Configuring the trip data display

The intervals for displaying the trip data in the instrument cluster and on the control display can be configured.

Use the key on the left steering column lever:

Press the key.

The trip data is displayed.



Press the key repeatedly until the desired setting is displayed.

Via iDrive:

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "System settings"
- 4. "Time period for journey data"
- 5. "Values"
- 6. Select the desired setting:
  - "Since start of journey ()": the values are reset automatically if the vehicle is at a standstill for approximately four hours.
  - "Since last refuel ()": the values are reset automatically after refuelling with a significant amount of fuel.
  - ▶ "Since factory": the values since leaving the factory are displayed.
  - "Since Individual ()": the values since the last manual reset are displayed. The values can be reset at any time.


### Resetting average values manually


The following interval can be reset manually at any time:

"Since Individual ()"

Use the key on the left steering column lever:

1. Press the key.





Press and hold the button until the values are reset.

### Via iDrive:

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "System settings"
- 4. "Time period for journey data"
- 5. "Reset Individual"

The average values and counters are reset. Once the average values and counters have been reset, the following interval is automatically activated:

"Since Individual ()"

### G meter

### General

The G meter shows the longitudinal and lateral forces acting on the vehicle occupants during a journey.

The display can be configured in the central indication range of the instrument cluster.


The values are automatically reset after each start of the journey.

For further information:

Central display area, see page 152.

## Manually resetting g-Meter values

- 1. Display g-Meter in the instrument cluster.
- Press and hold the button on the steering column lever on the left until the values are reset.



## Date and time

Various settings can be configured for the display of date and time, for example the date format.

Depending on the equipment and nationalmarket version, the time zone can be set and the automatic time setting can be activated. The automatic time setting automatically updates the time, date and, if necessary, the time zone.

- 1. "MENU"
- 2. "Vehicle apps"
- "System settings"
- 4. "Date and time"
- 5. Select the desired settings.

### **Fuel level indicator**

### Principle

The current filling level of the fuel tank is displayed.





### General

The vehicle inclination may cause the display to fluctuate.

For further information:

Refuelling, see page 284.

### Display



An arrow next to the fuel pump symbol indicates on which side of the vehicle the fuel filler flap is located.

The current range is displayed

as a numerical value.

## Range

### Principle

The range shows what distance can be covered with the amount of fuel currently in the tonk.

### General

The estimated range available with the remaining fuel is displayed in the instrument cluster.

A Check Control message is displayed briefly if the remaining range is low. A small remaining range means that the engine functions are not always ensured if a sporty driving style is employed, e.g. when cornering fast.

If the range drops below approximately 50 km, 30 miles the Check Control message is displayed continuously.

## Safety information



#### ∧ NOTICE

If the range drops below 50 km, approx. 30 miles, the engine may no longer be supplied with sufficient fuel. The engine functions are no longer ensured. There is a risk of material damage. Refuel in good time.

## Display



The current range is displayed as a numerical value on the fuel level indicator.

## Selecting the units of measurement

Depending on the national-market version, it is possible to select the units of measurement for various values, for example, consumption, distances and temperature.


- "MENU"
- "Vehicle apps"
- 3. "System settings"
- 4. "Units"
- 5. Select the desired setting.

## Vehicle status

### General

The status can be displayed and actions performed for several systems, such as for Check Control.

Depending on the setting, the vehicle status is displayed dynamically or permanently on the control display.



- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Vehicle status"

### Overview

lcon	Description
(!)	"Flat Tyre Monitor": Status of the Flat Tyre Monitor, see page 304.
(!)	"Tyre Pressure Monitor": status of the Tyre Pressure Monitor, see page 297.
₹ <u>~</u> .	"Engine oil level": Electronic oil measurement, see page 320.
÷	"AdBlue": BMW Diesel with BluePerformance, see page 316.
$\triangle$	"Check Control": to display saved Check Control mes- sages, see page 148.
	"Service requirements": to display service requirements, see page 158.

# Current driving condition

### General

The current driving condition is displayed dynamically while driving in the Live Vehicle menu on the control display.

The following states can be displayed:

- Driving.
- ▶ Coasting driving condition: "EFFICIENT COASTING".
- ▶ "CHARGING BATTERY"

With mild hybrid technology:

- Adaptive recuperation.
- Efficient coasting with the engine switched off


For further information:

- ▶ Adaptive recuperation, see page 281.
- ▶ Coasting, see page 282.

### Operating requirements

- ▶ COMFORT or ECO PRO drive mode must be selected.
- The following settings must be selected for Live Vehicle:
  - "Adaptive content"

## Display



#### An example:

The adaptive recuperation is active, arrow 1.

The vehicle battery is charged when the vehicle is decelerating, arrow 2.

# Sport displays

### Principle

The sport displays primarily assist a sporty driving style.

### Operating requirements

- Drive mode SPORT must be selected.
- ▶ The following settings must be selected for Live Vehicle:





"Adaptive content"

### Display

The sport displays are displayed in the Live Vehicle menu on the control display.

The following information is displayed:

- ▶ Torque.
- Power.
- ▶ Charging pressure.
- ▶ Engine oil temperature.

# Service requirements

### Principle

The function shows the current service requirements and related maintenance jobs.

### General

After switching on drive-ready state, the next service appointment or the distance remaining until your next servicing is displayed briefly on the instrument cluster.

The current service requirements can be read out from the vehicle key by a service advisor.

### Display

More detailed information on the maintenance work required can be displayed on the control display.

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Vehicle status"
- 4. Service requirements"

Maintenance routines and any statutory inspections required are displayed.

Select the desired entry to display more detailed information.

### Entering deadlines

Dates for mandatory vehicle inspections can be entered.

Ensure that the date and time are set correctly in the vehicle.

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Vehicle status"
- 4. Service requirements"
- 5. "Vehicle inspection"
- 6. "Date:"
- 7. Select the desired setting.

## Service history

### Principle

Completed maintenance work can be displayed on the control display.

### General

Have maintenance work performed by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop. The maintenance work carried out is entered in the vehicle data. The function is available as soon as a maintenance visit has been logged in the vehicle data.

### **Displays**

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Vehicle status"
- 4. Service requirements"

Essential maintenance routines and any statutory inspections required are displayed.

- 5. 

  ✓ 

  "Service history"
- Select an entry to display more detailed information.



### Icons

Icon	Description
OK	Maintenance has been carried out on time.
OK	Maintenance has been carried out later than scheduled.
	Maintenance has not been carried out.



# Lights

## Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

# Lights and lighting

### Overview

### Buttons in the vehicle



lcon	Function
<b>()</b> ‡	Rear fog light.
OFF	Lights off. Daytime driving lights.
∋D O≑	Side lights.
AUTO	Automatic driving lights control. Adaptive lighting functions.

lcon	Function
<b></b> ■D	Low-beam headlight.
( <del>,</del>	Instrument lighting.
P÷	Parking light, right.
⋛P	Parking light, left.

### Buttons on the vehicle key

lcon	Function
	Interior lighting. Parts of the exterior lights.
<b>&lt;&gt;</b>	Home lights.

# Automatic driving lights control

### Principle

Depending on ambient brightness, the system switches the low-beam headlight on or off automatically, for example in a tunnel, at twilight and in rain or snow.

### General

The headlights may also be switched on when the sun is low against a blue sky.

If the low-beam headlight is switched on manually, the automatic driving lights control is deactivated.

## Activating the automatic driving lights control



Press the button on the light switch element.

The LED in the button illuminates.



The indicator light in the instrument cluster is illuminated when the lowbeam headlight is switched on.

### System limits

The automatic driving lights control is no substitute for using your own judgement to assess the light conditions.

The sensors are unable to recognise fog or hazy weather, for example. In such situations, switch on the lights manually.

# Side lights, low-beam headlights, and parking lights

### General

If the driver's door is opened when drive-ready state is switched off, the exterior lights are switched off automatically after a given time.

### Side lights

### General

The side lights can only be switched on in the low speed range.

## Switching on the side lights



Press the button on the light switch el-**EDUS** ement.




The indicator light in the instrument cluster is illuminated.

The vehicle is illuminated all round.

Do not leave the side lights on for extended periods of time, as this could drain the vehicle battery and it may no longer be possible to switch on drive-ready state.

### Switching off the side lights

The side lights can be switched off as follows:



Switch on drive-ready state.

After switching on drive-ready state, the automatic driving lights control is activated.

### Low-beam headlight

### Switching on the low-beam headlight



Press the button on the light switch element.

The low-beam headlight illuminates if driveready state is switched on.



The indicator light in the instrument cluster is illuminated.

To switch on the low-beam headlight as soon as the standby state is switched on, press the button again.

### Switching off the low-beam headlight

Depending on the national-market version, the low-beam headlight may be switched off in the low speed range:

Press the button on the light switch element.

### Parking light

When parking the vehicle, it is possible to switch on a parking light on one side.





Button	Function
P <del></del>	Parking light, right on.



Parking light, left on.

To switch off parking light:



Press the button on the light switch element or switch on drive-ready state.

## Welcome light

### Principle

With the welcome light, the exterior lights are automatically turned on for a limited time when approaching or unlocking the vehicle.

### General

Depending on the equipment, the exterior lights of the vehicle can be individually adjusted.

# Activating/deactivating welcome light

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Exterior lighting"
- 4. If necessary, "Additional settings"
- 5. Depending on the equipment, select the desired setting:
  - "Welcome and goodbye"When unlocking the vehicle, individual lighting functions are turned on.

## Turning on the welcome light

- > Automatically on approach.
- ▶ During unlocking.

With the vehicle locked, press the button on the vehicle key.

Depending on the settings, the interior lighting and parts of the exterior lighting will be turned on.

The function is not available for the first 10 seconds after locking.

# Home lights

### Principle

With the home lights, the exterior lights are automatically turned on for a limited time after leaving the vehicle in order to illuminate the area around the vehicle.

### Switching on the home lights

▶ After switching off drive-ready state, press the turn indicator lever forwards briefly.



Activate the home lights function for the button of the vehicle key:

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Doors and windows"
- 4. "Vehicle kev"
- 5. Select the desired setting.

### Setting the duration

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Exterior lighting"



- 5. "Home lights"
- 6. Select the desired setting.

# Daytime driving lights

### General

The daytime driving lights illuminate when drive-ready state is switched on.



The indicator light in the instrument cluster is illuminated when the rear daytime driving lights are switched on.

## Activating/deactivating daytime driving lights

In some countries, daytime driving lights are compulsory, in which case the daytime driving lights cannot be deactivated at the front.

- 1. "MFNU"
- 2. "Vehicle apps"
- 3. "Exterior lighting"
- 4. If necessary, "Additional settings"
- 5. Depending on equipment or national-market version:
  - "Daytime driving lights"
  - "Rear daytime driving lights"

# Dynamic ECO light function

### General

In the low speed range, the brightness of the low-beam headlights is reduced.

### Activating the dynamic ECO light function

**AUTO** If necessary, press the button on the light switch element to activate automatic lights.

The LED in the button illuminates.

2. Activate ECO PRO drive mode. ECO PRO, see page 132.

# Adaptive lighting functions

### Principle

Adaptive lighting functions makes it possible to illuminate the road responsively.

### General

The adaptive lighting functions consist of one system or multiple systems, depending on the equipment:

- Variable light distribution.
- Cornering light.
- ▶ Roundabout light.

### Activating the adaptive light functions



Press the button on the light switch el-AUTO ement.

The LED in the button illuminates.

The adaptive lighting functions are active when drive-ready state is switched on.

# Variable light distribution

### Principle

The variable light distribution enables better illumination of the road.





### General

The light distribution is adjusted automatically depending on speed and navigation data, if necessary.

### **Urban lights**

The light beam from the low-beam headlight is extended at the sides.

### Motorway beam pattern

The range of the low-beam headlight is increased.

# Cornering light

### Principle

When turning off or on tight bends, for example hairpin bends, up to a certain speed, a cornering light is added to illuminate the inside area of the bend.

### General

The cornering light is switched on automatically depending on the steering wheel angle or, where applicable, activation of the turn indicators.

When reversing, the cornering light is activated automatically as appropriate, irrespective of the steering wheel angle.

### Hairpin lights

The cornering light is also switched on before entering hairpin bends.

# Roundabout light

Shortly before driving onto a roundabout, the cornering light is activated on both sides. The edge of the road is illuminated more effectively. Shortly before leaving a roundabout, the

cornering light is switched off again on both sides.

# Adaptive headlight range control

Adaptive headlight range control compensates for acceleration and braking manoeuvres and vehicle load conditions to prevent oncoming vehicles from being dazzled.

# High-beam Assistant

### Principle

High-beam Assistant detects other road users in good time and activates or deactivates the high-beam according to traffic situation.

### General

High-beam Assistant ensures that the highbeam headlight is switched on when the traffic situation allows. The system does not switch on the high-beam headlight at low speed range.


The system responds to the lights of oncoming traffic and traffic driving ahead of you, and to ambient lighting, for example in built-up areas.

The high-beam headlight can be switched on and off manually at any time.

If equipped with Selective Beam, the highbeam headlight is not switched off for oncoming vehicles or vehicles driving ahead of you. Instead, the system masks only those areas of the beam which would otherwise dazzle oncoming traffic or traffic driving ahead. In this case, the blue indicator light continues to illuminate.

Depending on the equipment: if the headlights have been converted, High-beam Assistant may only function to a restricted extent.


For further information:



### Operating requirements

- ▶ Automatic driving lights control is activated.
- ▶ The low-beam headlight is switched on.

## Activating High-beam Assistant



Press the button on the turn indicator lever.



The indicator light in the instrument cluster is illuminated when the low-beam headlight is switched on.

The system will switch automatically between low-beam headlight and high-beam headlight.



The blue indicator light in the instrument cluster illuminates if the highbeam headlight is switched on by the


system.

If a journey is interrupted with High-beam Assistant activated: when the journey is resumed, High-beam Assistant remains activated.

The High-beam Assistant is deactivated by switching the high-beams on and off manually.

To reactivate High-beam Assistant, press the button on the turn indicator lever.

## Deactivating High-beam Assistant



Press the button on the turn indicator lever.

## System limits

High-beam Assistant cannot replace the driver's own judgement as to when to use the high-beam headlight. Therefore activate the dipped headlights manually if the situation requires it.

In the following situations, the system will not operate or its operation will be restricted and your intervention may be required:

- ▶ In extremely adverse weather conditions such as fog or heavy precipitation.
- When detecting poorly lit road users such as pedestrians, cyclists, horse riders or carriages and when trains or ships are close to the road, or when animals are crossing the road.
- ▶ On tight bends, on steep brows or hollows of hills, when there is crossing traffic or if the view of oncoming vehicles on a motorway is partly obstructed.
- ▶ In poorly lit towns or where there are highly reflective signs.
- ▶ If the area of windscreen in front of the interior mirror is covered with condensation, dirt, stickers, labels, etc.





# Fog light

### Rear fog light

### Operating requirements

The low-beam headlight must be switched on before the rear fog light can be activated.

### Switching the rear fog light on/off



Press the key.



The yellow indicator light in the instrument cluster illuminates when the rear fog light is switched on.

If automatic driving lights control has been activated, the low-beam headlight switches on automatically when the rear fog light is switched on.

### Bad weather light

### Principle

The bad weather light provides optimised illumination of the road when visibility conditions are poor, for example in fog or rain. The light distribution from the low-beam headlight is adapted to the visibility conditions.

# Activating/deactivating the bad weather light

The bad weather light is activated when the automatic driving light system or the rear fog light is switched on.

# Left-hand/right-hand traffic

### General

When driving in countries where vehicles drive on the opposite side of the road to your vehi-

cle's country of registration, you will need to prevent the dazzling effect of your headlights.

## Converting the headlights

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Exterior lighting"
- 4. If necessary, "Additional settings"
- 5. "Right/left-hand traffic"
- Select the desired setting.
   Depending on the national-market version, the parking brake must be applied.

### System limits

The availability of the High-beam Assistant might be restricted.

The availability of the adaptive lighting functions might be restricted.

# Instrument lighting

## Operating requirements

The brightness can only be adjusted when the side lights or low-beam headlight are switched on.

### Adjusting the brightness




The brightness can be adjusted using the knurled wheel.

## Interior lighting

### General

Depending on the equipment, the interior lights, the footwell lights, door entry lighting,



### Overview

### Buttons in the vehicle





Reading lights



Interior lights

### Switching interior lights on/off



Press the key.

To switch off permanently: press and hold the button for approximately 3 seconds.

The interior lights in the rear can be switched on and off independently. The button is located on the headliner in the rear.

## Switching reading lights on/off



Press the key.

Depending on the equipment, there are reading lights located at the front and in the rear beside the interior lights.

# Ambient lighting

### General

Depending on the equipment, the lighting for some of the interior lights can be adjusted.

# Activating/deactivating ambient light

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Interior lighting"
- 4. If necessary, "Ambience"
- 5. "Ambient lighting"

## Turning ambient lighting on/off

The ambient lighting is switched on when the vehicle is unlocked and switched off when the vehicle is locked.

If the ambient lighting was deactivated using iDrive, it is not switched on when the vehicle is unlocked

### Selecting the colour

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Interior lighting"
- 4. If necessary, "Ambience"
- 5. "Colour"
- 6. Select the desired setting.

### Adjusting the brightness

- 1. "MENU"
- "Vehicle apps"
- 3. "Interior lighting"
- 4. If necessary, "Ambience"
- 5. "Brightness"
- 6. Select the desired setting.





### Dynamic light

Individual actions, for example incoming calls or open doors, are indicated by light effects. If the ambient light is deactivated, the light effects are still displayed.

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Interior lighting"
- 4. If necessary, "Ambience"
- 5. "Dynamic light"
- 6. Select the desired setting.

### Reduced for journey at night

Some lights of the interior lighting are reduced when the vehicle is driven in the dark.

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Interior lighting"
- 4. If necessary, "Ambience"
- 5. "Reduced for night driving"



# Vehicle equipment


This chapter describes equipment, systems and functions which are offered or will be of-

fered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

# Airbags



- 1 Front airbag, driver
- **2** Front airbag, front passenger

## Front airbags

Front airbags protect the driver and front passenger in the event of a head-on collision where the protection of the seat belts alone would no longer be sufficient.

### Side airbag

In a side-on crash, the side airbag protects the side of the body in the chest and pelvic area.

- 3 Head airbag
- 4 Side airbag

## Head airbag

The head airbag protects the head in the event of a side-on crash.

### Protective effect

#### General

Airbags are not activated in every collision situation, for example, in minor accidents.



### Information for optimum airbag protective effect

#### MARNING

If the seat position is incorrect or the deployment area of the airbag is restricted, the airbag system cannot provide the intended level of protection or may cause additional injuries when it deploys. There is a danger of injury or danger to life. Observe the following for optimum protective effect of the airbag system.

- ▶ Keep a distance from the airbags.
- > Always grip the steering wheel at the steering wheel rim. Place your hands in the 3 o'clock and 9 o'clock positions to minimise the risk of injury to hands or arms when the airbag deploys.
- > Adjust the seat and steering wheel so the driver can reach over the steering wheel diagonally. Select the settings so that, when reaching over, the shoulders stay in contact with the backrest and the upper body stays as far away from the steering wheel as possible.
- ▶ Make sure that the front passenger is sitting correctly, i.e. with their feet and legs in the footwell, not resting on the dashboard.
- Make sure that vehicle occupants keep their head away from the side airbag.
- Do not place any other persons, pets or objects between the airbags and occupants.
- Keep the dashboard and windscreen area on the passenger's side clear, for example do not attach adhesive foil or covers and do not fit brackets for navigation devices or mobile phones, for example.
- Do not glue the airbag covers and do not cover or modify them in any way.
- Do not use the front airbag cover on the passenger's side as a tray.
- Do not attach slip covers, seat cushions or other objects to the front seats that are not

- specifically suited for seats with integrated airbag versions.
- Do not hang items of clothing, for example coats or jackets, over the backrests.
- Do not modify individual components of the system or its wiring. This also applies to the covers of the steering wheel, the dashboard and seats.
- Do not dismantle the airbag system.

Even if all this information is observed, injuries resulting from contact with the airbag cannot be entirely ruled out in every situation.

The noise caused by the deployment of an airbag may lead to temporary hearing loss in vehicle occupants sensitive to noise.

## Operational readiness of the airbag system

### Safety information



#### MARNING

Individual components of the airbag system may be hot after airbag deployment. There is a danger of injury. Do not touch individual components.



### MARNING

Work carried out incorrectly can cause the airbag system to fail, malfunction or deploy accidentally. If there is a malfunction, the airbag system might not deploy as intended in an accident, even if the impact is of the appropriate severity. There is a danger of injury or danger to life. Have the airbag system tested, repaired or removed and disposed of by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

## Display in the instrument cluster



When drive-ready state is switched on, the warning light in the instrument cluster illuminates briefly to indicate

that the entire airbag system and the seat belt tensioners are operational.

### Malfunction



- The warning light does not illuminate after drive-ready state is switched on.
- The warning light is permanently illuminated.

Have the system checked.

## Adjusting the front seat position

To maintain the accuracy of the seat position, calibrate the electric front seats as soon as a corresponding message is displayed on the control display.

For further information:

Seats, see page 98.

# Key switch for front passenger airbag

### Principle

When using a rear-facing child restraint system on the front passenger seat, the front passenger airbag can be deactivated using the key switch for the front passenger airbag.

### General

The availability of the function depends on the vehicle equipment and country.

The front passenger airbag can be deactivated and reactivated with the integrated key from the vehicle key.

### Overview



The key switch for front passenger airbag is located on the outside of the dashboard.

# Deactivating the front passenger airbag



- 1. Insert the key and press inwards where necessary.
- 2. With the key pressed inwards, turn the switch to the OFF position as far as it will go. Once the stop position has been reached, remove the key.
- 3. Make sure that the key switch is in the end position so that the airbag is deactivated.

The front passenger airbag is deactivated. The driver airbag remains active.

If a rearward-facing child restraint system is removed from the front passenger seat, reactivate the front passenger airbag so that it can deploy as intended in the event of an accident.

The airbag status is shown by the indicator light on the headliner.





## Activating the front passenger airbaa



- 1. Insert the key and press inwards where necessary.
- 2. With the key pressed inwards, turn the switch to the ON position as far as it will go. Once the stop position has been reached. remove the key.
- 3. Make sure that the key switch is in the end position so that the airbag is activated.

The front passenger airbag is reactivated and deploys in appropriate situations.

## Front passenger airbag indicator light

The indicator light for the front passenger airbag in the headliner shows the operating status of the front passenger airbag.

After switching on standby state, the light illuminates briefly and then shows whether the airbag is activated or deactivated.

### **Display Function** When the front passenger airbag is activated, the indicator light illuminates for approx. 1 minute and then goes out. When the front passenger airbag is deactivated, the indica-PASSENGER X tor light remains illuminated.

Check the status of the indicator light before and also while driving when the front passenger seat is occupied.

# Active pedestrian protection

### Principle

The active pedestrian protection raises the bonnet if the front of the vehicle collides with a pedestrian.

### General

When triggered, the pedestrian protection creates deformation space underneath the bonnet in readiness for the subsequent head impact. Sensors underneath the bumper are used for detection.

The system's gas pressure springs are only approved for a certain period of time. Check the gas pressure springs during maintenance and replace them as necessary.

## Safety information



#### ↑ WARNING

The system may trigger inadvertently if contact is made with individual components of the hinges and bonnet locks. There is a danger of injury or material damage. Do not touch individual components of the hinges and bonnet locks.



#### ⚠ WARNING

Modifications to the pedestrian protection can lead to a failure, a malfunction or accidental triggering of the pedestrian protection system. There is a danger of injury or danger to life. Do not modify the pedestrian protection, its individual components or its wiring. Do not dismantle the system.



### MARNING

Work carried out incorrectly can lead to a failure, malfunction or accidental triggering of the system. If there is a malfunction, the system might not trigger as intended in an accident, even if the impact is of the appropriate severity. There is a danger of injury or danger to life. Have the system tested, repaired or removed and disposed of by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

### ↑ WARNING

If the system has been triggered or is damaged, its functionality will be restricted or it may no longer work at all. There is a danger of injury or danger to life.

If the system has been triggered or is damaged, have it checked and replaced at a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

### ∧ NOTICE

Opening the bonnet when the pedestrian protection has triggered may damage the bonnet or the pedestrian protection. There is a risk of material damage. Do not open the bonnet after the Check Control message is displayed. Have checks performed by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

## System limits

The active pedestrian protection is only triggered at speeds between approximately 30 km/h, 18 mph and 55 km/h, 34 mph.

For safety reasons, the system may also trigger in rare instances where impact with a pedestrian cannot be excluded beyond all doubt, for example in the following situations:

- Collision with objects such as a skip or a boundary post.
- Collision with animals.
- Stone impact.
- Driving into a snow drift.

### Malfunction



 $\blacksquare$  A Check Control message is shown. The system has been triggered or is faulty.

Immediately drive at moderate speed to a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop to have the system checked and repaired.

# Collision warning systems

### General

Depending on the equipment, the vehicle has different systems that can help prevent an imminent collision.

- ▶ Front-collision warning, see page 174.
- ▶ Lane Departure Warning, see page 180.
- ▶ Lane Change Warning, see page 183.
- ▶ Rear Collision Prevention, see page 185.

## Safety information



### ↑ WARNING

The system does not relieve you of your personal responsibility to assess the traffic situation correctly. Due to system limits, it cannot respond independently and appropriately in all traffic situations. There is a risk of accident. Adapt your driving style to the traffic conditions. Observe the traffic situation, be ready to take over steering and braking at



any time, and actively intervene if the situation warrants it.



### ↑ WARNING

Displays and warnings do not relieve you of your personal responsibility. System limits can mean that warnings or system responses are not issued or are issued too late, incorrectly or for no reason. There is a risk of accident. Adapt your driving style to the traffic conditions. Observe the traffic situation and intervene actively if the situation warrants it.

### Turning on/turning off collision warning systems

Depending on the national-market version, some of the systems are automatically active after every driving off.

The following functions are adjustable.

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Driver assistance"
- 5. "Safety and warnings"
- 6. Select the desired settings.

### Resetting settings

The settings of the collision warning systems can be reset to the default settings for vehicle delivery.

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Driver assistance"
- 5. "Safety and warnings"
- 6. "Reset to recommended settings"

## System limits

### Safety information



#### ↑ WARNING

Due to system limitations, the system may not respond at all, or may respond too late, incorrectly or for no reason. There is a risk of accident or material damage. Observe the information on the system limits and intervene actively if necessary.

### **Detection capability**

The detection capability of the system is limited.

Only objects within the detection range of the installed sensors and that are detected by the system are taken into account.

Depending on the equipment, the area is monitored by cameras or radar sensors.

For this reason, the system may fail to respond or only respond after a delay.

### System limits of the sensors

For further information:

Sensors in the vehicle, see page 41.

## Front-collision warning

### Principle

The front-collision warning can help prevent accidents. If an accident cannot be avoided. the system may help reduce the severity of the accident.

The system can issue a warning of a possible risk of collision and may activate the brakes independently.



Depending on the equipment version, the front-collision warning system includes the following functions:

- Collision Warning with braking function, see page 177.
- ▶ Pedestrian Warning with city braking function, see page 178.

### Safety information

## 

The system does not relieve you of your personal responsibility to assess the traffic situation correctly. Due to system limits, it cannot respond independently and appropriately in all traffic situations. There is a risk of accident. Adapt your driving style to the traffic conditions. Observe the traffic situation, be ready to take over steering and braking at any time, and actively intervene if the situation warrants it.

### **⚠** WARNING

Displays and warnings do not relieve you of your personal responsibility. System limits can mean that warnings or system responses are not issued or are issued too late, incorrectly or for no reason. There is a risk of accident. Adapt your driving style to the traffic conditions. Observe the traffic situation and intervene actively if the situation warrants it.

### **△** WARNING

Individual functions may malfunction when tow-starting or towing away with activated front-collision warning or Cruise Control switched on. There is a risk of accident. Turn off the front-collision warning and Cruise Control before tow-starting or towing away.

### Sensors

Depending on the equipment, the system is controlled by the following sensors:

- Camera behind the windscreen.
- Front radar sensor.

### Speed range

The system issues a warning of a possible risk of collision at speeds above approx. 5 km/h/3 mph.

The system is temporarily disabled at speeds over approx. 250 km/h, 155 mph.

Some functions are deactivated earlier.

As soon as the speed drops below these values again, the system is activated.

# Turning the front-collision warning on/off

### Switching on the system automatically

Depending on the national-market version, the system is automatically active after every driving off.

### Switching the system on manually

The system is activated when the warning time is set.

For further information:

Setting the warning time, see page 176.

## Switching the system off manually

Depending on the national-market version, the setting can only be made at a vehicle standstill or in the very low speed range.

If necessary, the switch-off must be confirmed successively on the control display.

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Driver assistance"



- 1
- 5. "Safety and warnings"
- 6. "Front collision warning"
- 7. "Off"

## Setting the warning time

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Driver assistance"
- 5. "Safety and warnings"
- 6. "Front collision warning"
- 7. Select the desired setting.
  - ▶ "Early"
  - ▶ "Medium"
  - "Late": only acute warnings are displayed.

The higher the sensitivity of the warning time settings the more warnings are displayed. As a result, there may also be an increased number of premature or unjustified warnings and responses.

## Switching the warning signal on/off

Depending on the equipment and nationalmarket version, system warning signals can be turned off.

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Driver assistance"
- 5. "Safety and warnings"
- 6. "Front collision warning"
- 7. "Warning tone"

## Display in the instrument cluster

The following icons are shown in the instrument cluster and, depending on the equipment, in the Head-up display:

### Icon Meaning



Depending on equipment and national-market version:

The icon lights up yellow: functional limitation detected, e.g. due to low sun or system failure. It is possible to continue driving. Where applicable, observe the information from Check Control messages.



Depending on equipment and national-market version:

The icon lights up yellow: the system is turned off.



Risk of collision, for example, with a pedestrian.



Risk of collision, for example, with a vehicle driving in front.



General risk of collision.

The image of the respective icon may vary, because the system may detect multiple objects.

## Warning function

The front-collision warning warns on different warning levels, depending on the respective hazardous situation.

In the event of a system warning, the driver must intervene immediately and in accordance with the situation.

- ▶ A red icon illuminates:
  - A hazardous situation has been detected. Increased awareness is required.
- A red icon flashes:
  - There is a risk of collision. Intervene yourself immediately.
- A warning signal sounds:



Automatic brake intervention:

Depending on the equipment and situation in case of an imminent danger of collision, the system can also intervene with an automatic brake intervention and automatically decelerate the vehicle, if necessary, to a complete standstill.

When the brake pedal is pressed quickly and hard, the maximum brake force of the vehicle is used.

### Automatic brake intervention

In case of a risk of collision, the system can assist with an automatic brake intervention, if necessary.

At low speeds, the vehicle can be braked to a standstill.

A brake intervention can be cancelled by sufficiently stepping on the accelerator pedal, releasing the brake pedal or with an active steering wheel movement.

City braking function: brake intervention takes place at up to approx. 80 km/h, 50 mph.

With radar sensor: brake intervention takes place at up to approx. 250 km/h, 155 mph.

At speeds above approx, 210 km/h/130 mph. only a brief brake intervention will occur.

### System limits

### Safety information



#### ↑ WARNING

Due to system limitations, the system may not respond at all, or may respond too late, incorrectly or for no reason. There is a risk of accident or material damage. Observe the information on the system limits and intervene actively if necessary.

### Detection capability

The detection capability of the system is limited.

Only objects within the detection range of the installed sensors and that are detected by the system are taken into account.

Depending on the equipment, the area is monitored by cameras or radar sensors.

For this reason, the system may fail to respond or only respond after a delay.

### System limits of the sensors

For further information:

Sensors in the vehicle, see page 41.

### **Functional limitations**

The system may have restricted functionality in situations such as the following:

- ▶ In tight bends.
- ▶ With restriction of the driving stability control systems.
- ▶ Up to 10 seconds after switching on driveready state using the Start/Stop button.

# Collision Warning with braking function

### Principle


The Collision Warning with braking function warns of a possible risk of collision and may brake independently.

If an accident cannot be avoided, the system helps to reduce the collision speed.



## 1

### General



Sensors detect the traffic situation in their detection range.

The system issues a warning of a possible risk of collision with vehicles at speeds above approx. 5 km/h/3 mph. The timing of these warnings may vary depending on the current driving situation.

The driver's own driving behaviour is taken into account in the responses of the system. If an active driving style is detected, warnings and brake interventions are output less frequently.

### Safety information

Follow the Safety Information in Chapter "Front-collision warning".

## Display in the instrument cluster

A warning symbol is displayed when a collision with a detected vehicle is imminent.

### Icon Meaning



Collision Warning with a detected vehicle.



General risk of collision.

## Warning function

The warning prompts the driver to intervene personally.

For further information:

Front-collision warning, see page 174.

## System limits

### General

Follow the limits of the system in the chapter "Front-collision warning".

### **Detection range**

The following situations may not be detected, or only detected with a delay, for instance:

- ▶ Slow driving vehicle in front being approached at high speed.
- ▶ Vehicles suddenly cutting in or decelerating heavily.
- ▶ Vehicles with unusual rear design.
- ➤ Two-wheeled vehicles ahead.

### Upper speed limit

The system is temporarily disabled at speeds over approx. 250 km/h, 155 mph. Once the speed drops back below this threshold, the system becomes responsive again according to its settings.


# Pedestrian Warning with city braking function

## Principle

The pedestrian warning with city braking function warns of the possible risk of collision with pedestrians and cyclists at speeds that are common in towns and cities and brakes automatically if necessary.

If an accident cannot be avoided, the system helps to reduce the collision speed.

### General



Sensors detect the traffic situation in their detection range.

The system issues a warning of a possible risk of collision with pedestrians at speeds above approx. 5 km/h/3 mph.

## Safety information

Follow the Safety Information in Chapter "Front-collision warning".

## Display in the instrument cluster

A warning symbol is displayed when a collision with a detected pedestrian is imminent.

### Icon Meaning



Risk of collision with a pedestrian.



General risk of collision.

## Warning function

The warning prompts the driver to intervene personally.

For further information:


Front-collision warning, see page 174.

## System limits

### General

Follow the limits of the system in the chapter "Front-collision warning".

### **Detection range**



The detection range in front of the vehicle consists of two parts:

- Central zone, arrow 1, directly in front of the vehicle.
- Extended zone, arrows 2, to the right and left of the central area.

There is a risk of collision if persons are in the central zone. A warning is only given of persons in the extended zone if they are moving towards the central zone.

For example the following might not be detected:

- Partially covered pedestrians or bikes.
- Pedestrians that are not detected as such because of their contour or posture.
- Pedestrians with insufficient height.

### Upper speed limit

Depending on the equipment, the system reacts to pedestrians when your own speed is up to 80 km/h. approx. 50 mph.






# Lane Departure Warning

### Principle

The Lane Departure Warning issues a warning if the vehicle leaves the road or its driving lane.

### General



Sensors detect the traffic situation in their detection range.

The system issues a warning starting at a minimum speed. The minimum speed is countryspecific and displayed on the control display.

Warnings are displayed in the instrument cluster. In addition, the steering wheel is vibrating.

The system does not issue a warning if the driver indicates in the corresponding direction before leaving the driving lane.

### Safety information



### MARNING

The system does not relieve you of your personal responsibility to assess the layout of the road and the traffic situation. There is a risk of accident. Adapt your driving style to the traffic conditions. Observe the traffic situation and intervene actively if the situation warrants it. In the event of a warning, do not move the steering wheel unnecessarily abruptly.

### MARNING MARNING

Displays and warnings do not relieve you of your personal responsibility. System limits can mean that warnings or system responses are not issued or are issued too late, incorrectly or for no reason. There is a risk of accident. Adapt your driving style to the traffic conditions. Observe the traffic situation and intervene actively if the situation warrants it.

### Operating requirements

The lane marking must be detected by the camera in order for the Lane Departure Warning to be active.

### Sensors

The system is controlled by the camera behind the windscreen.

## Turning the Lane Departure Warning on/off

## Switching on the system automatically

Depending on the national-market version, the system is automatically active after every driving off.

### Switching the system on manually

The system is activated when the warning time is set.

For further information:

Setting the warning time, see page 181.

## Switching the system off manually

Depending on the equipment and nationalmarket version, the switch-off must be confirmed successively on the control display.

- 1. "MFNU"
- 2. "Vehicle apps"
- 3. "Driving settings"



- 5. "Safety and warnings"
- 6. "Lane departure warning"
- 7. "Off"

## Setting the Lane Departure Warning

#### Setting the warning time

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Driver assistance"
- 5. "Safety and warnings"
- 6. "Lane departure warning"
- 7. Select the desired setting.
  - ▶ "Early"
  - "Medium"
  - "Reduced"

Some warnings are suppressed depending on the situation, for instance, when purposely driving over driving lane lines in bends or with dynamic overtaking without turn indicator.

## Adjusting the strength of the steering wheel vibration

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Driver assistance"
- 5. "Feedback via steering wheel"
- 6. "Vibration intensity"
- 7. Select the desired setting.

The setting is applied to all collision warning systems.

# Depending on the national-market version: switch steering intervention on/off

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Driver assistance"
- 5. "Safety and warnings"
- 6. "Lane departure warning"
- "Steering intervention"

Depending on the national-market version, steering intervention is automatically active whenever you drive off.

## Display in the instrument cluster

Depending on the equipment and nationalmarket version, different system statuses are displayed in the instrument cluster.

#### Icon Meaning



The icon lights up green: the system is turned on. A lane boundary has been detected on at least one side of the vehicle and the system is ready to intervene. Warnings are issued.

The icon flashes green: a warning is actively issued. If necessary, the system performs a steering intervention.



The icon lights up yellow: functional limitation detected, e.g. due to low sun or system failure. It is possible to continue driving. Where applicable, observe the information from Check Control messages.

The icon flashes yellow: a warning is actively issued. The system does not carry out any steering interventions.





#### Icon Meaning



The icon lights up grey: the system is switched off or automatically deactivated, e.g. because DSC OFF is activated.

The icon flashes grey: a warning is actively issued. The system does not carry out any steering interventions.

#### Warning function

#### When leaving the driving lane

If the vehicle leaves the driving lane and a lane boundary is detected, the steering wheel vibrates depending on the steering wheel vibration setting.

If the turn indicator is switched on in the corresponding direction before changing lanes, no warning is issued.

#### Steering intervention

Depending on the national-market version and equipment: if a lane boundary is crossed in the speed range up to 210 km/h, approx. 130 mph, the system may respond with an active steering intervention in addition to the steering wheel vibration. The system thereby helps to keep the vehicle in driving lane. Steering intervention can be felt at the steering wheel, and can be overridden manually at any time. With active steering intervention, the display flashes in the instrument cluster.

For example, steering intervention is suppressed in the following situations:

- ▶ If the vehicle is accelerating rapidly or braking heavily.
- ▶ On indicating.
- ▶ If the hazard warning lights are switched on.
- In driving situations with high driving dynamics.

- When Dynamic Stability Control is regulating.
- Directly after a steering intervention by the vehicle systems.
- ▶ When actively weaving back to your own lane after overtaking.

#### Warning signal

Depending on the national-market version: in the event of multiple active steering interventions by the system within 3 minutes without the driver's intervention at the steering wheel during the steering intervention itself, an acoustic warning will sound. A short warning signal will sound at the second steering intervention. A longer warning signal sounds from the third steering intervention onwards.

A Check Control message is also displayed.

The warning signal and Check Control message advise to pay closer attention to the lane.

#### In trailer operation

If the trailer socket is occupied or the trailer operation is activated, for example during operation with trailer, no steering intervention takes place.

For further information:

Operation with a trailer or rear luggage rack, see page 272.

#### Cancellation of the warning

For example, the warning or an active steering intervention is cancelled in the following situations:

- Automatically after a few seconds.
- ▶ On returning to the correct lane.
- If the vehicle is accelerating rapidly or braking heavily.
- If the hazard warning lights are switched on.
- ▶ On indicating.



- Directly after a steering intervention by the vehicle systems.
- ▶ With manual steering intervention.
- Possibly when another driver assistance system is activated.
- ▶ Lane boundaries are not detected.
- ▶ When the system limits are reached.

## System limits

#### General

Follow the limits of the system in the chapter "Collision warning systems".

#### **Functional limitations**

The system may have restricted functionality in situations such as the following:

- When there are missing, worn, poorly visible, merging/separating or ambiguous lane boundaries, for example, in areas where there are roadworks.
- ▶ With lane boundaries that are covered in snow, ice, dirt or water.
- ▶ In tight corners or on narrow roads.
- ▶ With lane boundaries that are not white.
- ▶ With lane boundaries that are covered by objects.
- ▶ If the vehicle is too close to the vehicle ahead.
- ▶ Up to 10 seconds after switching on driveready state using the Start/Stop button.
- ▶ While Dynamic Stability Control is disabled.

A Check Control message may be displayed if functionality is restricted. Depending on the national-market version, a yellow icon is also illuminated.


## Lane Change Warning

#### Principle

Lane Change Warning detects vehicles in the blind spot, or if vehicles are approaching from behind in the adjacent lane.

The light in the exterior mirror warns in different increments.

#### General



The system is operational after a minimum speed has been reached and uses radar sensors to monitor the area behind and adjacent to the vehicle.

The minimum speed is country-specific and displayed in the Lane Change Warning menu.

The system indicates when vehicles are in the blind spot, arrow 1, or are approaching from the rear in an adjacent lane, arrow 2. The light in the exterior mirror illuminates at a dimmed level.

In the above situations, the system issues a warning before a lane change with the turn indicator activated. The light in the exterior mirror flashes and the steering wheel vibrates.

When turning at a speed of up to approx. 20 km/h/12 mph, the steering wheel will not vibrate.

## Safety information

Follow the safety information in the Chapter "Collision warning systems".





#### Sensors

The system is controlled using the following sensors:

- ▶ Camera behind the windscreen.
- > Side radar sensors, rear.

## Turning the Lane Change Warning on/off

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Driver assistance"
- 5. "Safety and warnings"
- 6. "Lane change warning"
- 7. Select the desired setting.

## Adjusting the Lane Change Warning

## Setting the warning time

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Driver assistance"
- 5. "Safety and warnings"
- 6. "Lane change warning"
- 7. Select the desired setting.

## Adjusting the strength of the steering wheel vibration

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Driver assistance"
- 5. "Feedback via steering wheel"
- 6. "Vibration intensity"
- 7. Select the desired setting.

The setting is applied to all collision warning systems.

## Warning function

#### Light in the exterior mirror



The light in the exterior mirror warns of a possible collision.

#### Advance warning

The dimmed light in the exterior mirror indicates when vehicles are in the blind spot or are approaching from the rear.

#### Acute warning

In case of an acute warning, the steering wheel briefly vibrates and the light in the exterior mirror flashes brightly.

An acute warning occurs when the following conditions are met:

- Another vehicle is located in the critical area.
- Your own vehicle is approaching the other lane
- Depending on the system setting when the turn indicator is turned on.

The warning is terminated when the other vehicle has left the critical area or the turn indicator has been switched off.

## Flashing of light

A flashing of the light in exterior mirror during vehicle unlocking serves as system self-test.



#### General

Follow the limits of the system in the chapter "Collision warning systems".

#### Upper speed limit

The system is temporarily disabled at speeds over approx. 250 km/h, 155 mph.

The system is activated again at speeds under approx. 250 km/h, approx. 155 mph.

#### Warning displays

Depending on the selected setting for warnings, for example the warning time, it is possible that more or fewer warnings will be displayed. As a result, there may also be an increased number of premature warnings about critical situations.

#### **Functional limitations**

The system may have restricted functionality in situations such as the following:

- ► The speed of the approaching vehicle is much faster than your own speed.
- ▶ In tight corners or on narrow roads.
- ➤ The bumper is dirty, iced up or covered, for instance by stickers.

A Check Control message may be displayed if functionality is restricted. Depending on the national-market version, a yellow icon is also illuminated.


The system is inactive when the trailer socket is occupied or when the trailer operation is activated, for example, when operating with a trailer or bicycle carrier. A Check Control message is shown.

## Rear Collision Prevention

#### Principle

Depending on vehicle equipment and nationalmarket version, Rear Collision Prevention can respond to vehicles approaching from behind.

#### General



Radar sensors monitor the area behind the vehicle.

If a vehicle is approaching from behind at a relevant speed, the system can respond as follows:

- ► The hazard warning lights are switched on if appropriate.
- PreCrash functions are triggered if appropriate.

## Safety information

Follow the safety information in the Chapter "Collision warning systems".

## Sensors

The system is controlled via the radar sensors at the side in the rear.

# Switching Rear Collision Prevention on/off

The system is automatically activated at the start of each journey.

The system is deactivated in the following situations:



- ▶ When reversing.
- ▶ If the trailer socket is occupied or trailer operation is activated, for example when operating with a trailer or bicycle carrier.

## System limits

#### General

Follow the limits of the system in the chapter "Collision warning systems".

#### **Functional limitations**

The system may have restricted functionality in the following situations:


- ▶ The speed of the approaching vehicle is much faster than your own speed.
- ▶ The speed of the approaching vehicle is very slow.

## Crossing-traffic Warning

#### Principle

At blind exits or when leaving bay parking spaces, the Crossing-traffic Warning detects other road users approaching from the side earlier than is possible from the driver's seat.

#### General



The area behind to the vehicle is monitored by sensors.

The system indicates when other road users are approaching.

Follow the information in the Chapter "Parking assistance systems".

## Safety information

#### ↑ WARNING

The system does not relieve you of your personal responsibility to assess the traffic situation correctly. Due to system limits, it cannot respond independently and appropriately in all traffic situations. There is a risk of accident. Adapt your driving style to the traffic conditions. Observe the traffic situation, be ready to take over steering and braking at any time, and actively intervene if the situation warrants it.

#### Sensors

The system is controlled via the radar sensors at the side in the rear.

## Switching on/switching off the Crossing-traffic Warning manually

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Driver assistance"
- 5. "Parking and manoeuvring"
- 6. "CROSSING-TRAFFIC WARNING"
- 7. Select the desired setting.

## Turning on the Crossing-traffic Warning automatically

If the system was activated on the control display, it is automatically turned on as soon as the Park Distance Control or a camera view is active and a selector lever position is engaged.

The system is switched on at the rear when reverse gear is engaged.

Depending on the national-market version, the system is automatically active when the vehi-

# Turning off the Crossing-traffic Warning automatically

The system is automatically turned off, for example, in the following situations:

- ▶ If walking speed is exceeded.
- When a certain distance covered is exceeded.

## Warning function

#### General

cle is started.

The control display shows the corresponding image, an acoustic signal sounds, if necessary, and the light in the exterior mirror flashes.

#### Visual warning

#### Light in the exterior mirror




The light in the exterior mirror flashes if other vehicles are detected by the rear sensors when the vehicle is reversing.

#### Display in the Park Distance Control view



In the Park Distance Control view, the relevant boundary area flashes red if the sensors detect vehicles.

## Depending on the equipment: display in the camera image



The relevant boundary area, arrow 1, in the camera view flashes red if the sensors detect vehicles.

Yellow lines, arrow 2, indicate the bumper of your vehicle.

#### Acoustic warning

In addition to the visual warning, an acoustic signal sounds if your own vehicle moves into the respective direction.

Depending on the national-market version, the acoustic signal will already sound when the drive position is engaged.





## System limits

#### System limits of the sensors

For further information:

Sensors in the vehicle, see page 41.

#### **Functional limitations**

The function can be restricted, for example, in the following situations:


- ▶ In tight bends.
- Crossing objects are moving at a very slow or a very fast speed.
- ▶ Other objects that hide cross traffic are in the capture range of the sensors.
- If the trailer socket is occupied or trailer operation is activated, the Crossing-traffic Warning is not available for the area behind the vehicle.

## Dynamic brake lights

## Principle

The brake lights flash to warn road users behind the vehicle that emergency braking is being performed.

#### General



- Normal braking: brake lights illuminate.
- ▶ Heavy braking: brake lights flash.

Shortly before the vehicle comes to a standstill, the hazard warning lights are activated.

To switch off the hazard warning lights:

- Accelerate.
- Press the hazard warning lights button.

## BMW Drive Recorder

#### Principle

The BMW Drive Recorder saves short video recordings of the vehicle surroundings in order to document the traffic situation, for example.

#### General

Video recordings can be saved in different ways:

- Automatic saving of recordings.
   The function makes it possible to document the circumstances of an accident.
- Manual saving of recordings.
   The function makes it possible to document traffic situations.

The cameras of the assistance systems are used for recording, e.g. panorama view.

In addition, the following journey parameters are saved:

- Date.
- ▶ Time.
- Speed.
- GPS coordinates.

#### Data protection

The reliability of the recording and the use of video recordings depend on the legal regulations in the country where the system is to be used. The user is responsible for the use of the system and for complying with the provisions that apply in each case.

Before using for the first time, the vehicle manufacturer recommends checking that there are no legal or official restrictions on using the system in the state or country in question. Additionally, the legality of using the system should



Other drivers of the vehicle must be informed of the system. Information about the system must also be provided if the vehicle is passed on to anyone else.

#### Operating requirements

- Standby state or drive-ready state is switched on.
- ▶ BMW Drive Recorder is activated.
- ▶ Privacy Policy has been accepted.
- ▶ Recording type was selected.
- ▶ Recording duration was selected.

## Activating/deactivating the BMW Drive Recorder

The BMW Drive Recorder must be activated before using the recording function for the first time.

- 1. "MENU"
- 2. "All apps"
- 3. "Drive Recorder"
- 4. Accept data protection policy.
- 5. "Settinas"
- 6. "Allow recordina"
- 7. Select the desired setting.

#### Recording functions

## Automatic recording

The recording is automatically saved when the vehicle sensors detect an accident.

The system records for up to 20 seconds before and after the save function was activated.

#### Manual recording

#### Using the button





Press and hold the button.

#### Via iDrive

Start the recording:

- "MENU"
- 2. "All apps"
- 3. "Drive Recorder"
- 4. "Recording"
- 5. "Start recording"

The recording can also be started using the widget on the control display.

The system saves recordings up to 20 seconds before and after the save function was triggered.

## Playing and managing recordings

Saved video recordings can be played, exported and deleted.

For your own safety, the video recording is only shown on the control display if the speed is below approximately 3 km/h, 2 mph. In the case of some national-market versions, the video recording is only shown with the parking brake applied or with the selector lever in position P.

- 1. "MFNU"
- 2. "All apps"





- 3. "Drive Recorder"
- 4. "Recordings"
- 5. Select the desired recording.

If the cameras switched during the recording, it is possible to select different sections of the video.

## Settings

#### General

Various settings can be made.

#### Recording type

- 1. "MENU"
- 2. "All apps"
- 3. "Drive Recorder"
- 4. "Settings"
- 5. Select the desired setting.

#### Recording duration

- 1. "MENU"
- 2. "All apps"
- "Drive Recorder"
- 4. "Settings"
- 5. Select the desired setting.

#### Cameras

Different cameras can be selected.

- 1. "MFNU"
- 2. "All apps"
- 3. "Drive Recorder"
- 4. "Settings"
- 5. "Cam. selection"
- 6. Select the desired camera.

In the event of an accident, the system switches to "All" cameras automatically.

If driver assistance systems are active, their camera views are selected automatically.

## System limits

In the event of a serious accident, recordings may not be saved if, for example, the damage to the vehicle is too extensive or the power supply was interrupted.

## Active Protection

#### Principle

In critical situations, Active Protection prepares the passengers and the vehicle for a potential imminent accident.

#### General

Depending on the equipment and the nationalmarket version, Active Protection consists of different PreCrash functions.

The system detects critical driving situations which could potentially lead to an accident. Such critical driving situations include:

- ▶ Full braking.
- Severe understeering.
- Severe oversteering.

Certain functions of some systems installed in the vehicle can – within the system limits – cause Active Protection to trigger:

- ▶ Collision Warning with braking function: automatic brake intervention.
- ▶ Collision Warning with braking function: brake power assistance.
- ▶ Rear Collision Prevention: detects impending rear collisions.

## Safety information



#### ↑ WARNING

The system does not relieve you of your personal responsibility. System limits may mean that critical situations are not detected reliably or in good time. There is a risk of accident. Adapt your driving style to the traffic

conditions. Observe the traffic situation and intervene actively if the situation warrants it.

**Function** 

Depending on the equipment, in critical accident situations, the following individual functions become active as required:

- ▶ The windows are automatically closed. The windows remain open by a gap.
- Automatic closing of the glass sunroof/panoramic glass sunroof. The sun protection is also closed.
- Automatic positioning of the backrest of the front passenger seat.

Following a critical driving situation where no accident has occurred, the systems can be restored to the desired setting.

## PostCrash - iBrake

## Principle

In certain accident situations, PostCrash iBrake can automatically bring the vehicle to a standstill without the driver having to intervene.

#### General

PostCrash iBrake can reduce the risk of another collision and its consequences.

#### At a standstill

Once the vehicle has come to a halt, the brake is released automatically.

## Decelerating the vehicle harder

In certain situations, it may be necessary to bring the vehicle to a standstill more quickly than is possible with automatic braking.

To do so, brake quickly and firmly. This will briefly increase the brake pressure to a higher level than that achieved with the automatic

brake function. Automatic braking is interrup-

## Cancelling automatic braking

In certain situations, it may be necessary to cancel automatic braking, for example if avoidance manoeuvre is required.

Cancel automatic braking:

- By depressing the brake pedal.
- By depressing the accelerator pedal.

## Attentiveness Assistant

## Principle

The Attentiveness Assistant can detect decreasing attentiveness or the onset of fatique in the driver on long monotonous journeys, for example on motorways. The system recommends taking a break.

## Safety information



#### ↑ WARNING

The system does not relieve you of your personal responsibility to assess your physical condition correctly. Increasing inattention or fatigue might not be detected, or may not be detected in good time. There is a risk of accident. Make sure that the driver is rested and alert. Adapt your driving style to the traffic conditions.

#### **Function**

The system is switched on every time driveready state is switched on.

Once the journey has started, the system adapts to the driver so that any decrease in attention or fatique can be detected.

This process considers the following criteria:



- 1
- ▶ Personal driving style, for example steering.
- Driving conditions, for example time of day, duration of journey.
- Attentiveness of the driver through the Driver Attention Camera.

The system is active from approx. 70 km/h, 43 mph and can also display a recommendation to take a break.

#### Break recommendation

#### Setting break recommendations

The Attentiveness Assistant is automatically active every time drive-ready state is switched on and can therefore display break recommendation.

Break recommendation can also be switched on or off and adjusted via iDrive.

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Driver assistance"
- 5. "Safety and warnings"
- 6. "Attentiveness Assistant"
- 7. Select the desired setting.

#### Display

If the driver shows signs of decreasing attentiveness or of fatigue, a note is shown on the control display with the recommendation to take a break.

The following settings can be selected during the display.

After a break, another break recommendation cannot be displayed until after approximately 45 minutes at the earliest.

#### System limits

The function of the system may be restricted. If the function of the system is restricted, no warning is issued or a false warning is issued.

The system may have restricted functionality in the following situations:

- ▶ If the time is set incorrectly.
- ▶ When the speed is predominantly below approx. 70 km/h, 43 mph.
- If a sporty driving style is adopted, for example sharp acceleration or fast cornering.
- ▶ In active driving situations, for example frequent lane changes.
- ▶ In poor road condition.
- ▶ In strong crosswinds.

The system is reset approximately 45 minutes after the vehicle is stopped, for example when taking a break during a long motorway journey.

## **Driver Attention Camera**

## Principle

Depending on the equipment, a camera in the instrument cluster monitors the driver activity or the driver's direction of view.

#### General

For support by assistance systems, the attention of the driver is analysed by evaluating the head position and eye opening of the driver.

To guarantee full functionality, ensure that the Driver Attention Camera has an unobstructed field of view.

#### Overview





Depending on the equipment, the instrument cluster has up to 3 infrared light sources. Depending on the light conditions, they can be visible when the vehicle is in the standby state.

## System limits

The Driver Attention Camera may have restricted functionality in situations such as the following:

- ▶ If the Driver Attention Camera is covered by the steering wheel.
- ▶ If the driver is wearing sunglasses with high protection against infrared light.



## Driving stability control systems

## Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

## Anti-lock Braking System

#### Principle

The Anti-lock Braking System prevents the wheels from locking when the brakes are applied.

Steering control is retained even during full braking, which enhances active road safety.

The Anti-lock Braking System is ready whenever you switch on drive-ready state.

## **Brake Assist**

When the brake is pressed quickly, Brake Assist automatically provides the maximum possible braking force assistance. This keeps the stopping distance as short as possible in full braking situations. This takes full advantage of the Anti-lock Braking System.

The pressure on the brake should be maintained for the duration of the full braking process.

## Adaptive brake assist

In combination with Cruise Control with distance control, this system ensures that the

brakes respond even more rapidly when braking in critical situations.

## Drive-off assistant

#### Principle

The drive-off assistant provides support when driving off on upward gradients.

#### Driving off

- Hold the vehicle in place with the foot brake.
- 2. Release the foot brake and drive off without delay.

After the foot brake is released, the vehicle is held in place for approximately 2 seconds.

Depending on the vehicle's load or in trailer operation, the vehicle may roll backwards a little.

## Dynamic Stability Control

#### Principle

The Dynamic Stability Control helps to keep the vehicle on a steady course by reducing drive power and by brake intervention on individual wheels.

#### General

The system detects the following unstable driving conditions, for example:

- ▶ Loss of traction at the rear which can lead to oversteering.
- ▶ Loss of grip at the front wheels which can lead to understeering.

## Safety information



#### MARNING

The system does not relieve you of your personal responsibility to assess the traffic situation correctly. Due to system limits, it cannot respond independently and appropriately in all traffic situations. There is a risk of accident. Adapt your driving style to the traffic conditions. Observe the traffic situation, be ready to take over steering and braking at any time, and actively intervene if the situation warrants it.



#### ↑ WARNING

When driving with a roof load, for example with a roof rack, the higher centre of gravity can mean that driving safety is no longer guaranteed in critical driving situations. There is a risk of accident or material damage. Driving with roof load only with activated Dynamic Stability Control.

#### Overview

#### Button in the vehicle





DSC OFF

## Activating/deactivating Dynamic Stability Control

#### General

Driving stability during acceleration and cornering is restricted if Dynamic Stability Control is deactivated.

To support driving stability, re-activate Dynamic Stability Control as soon as possible.

## Deactivating/activating the system



button to open the selec-

2. "DSC OFF"

Press the

tion.

The DSC OFF indicator and the Dynamic Stability Control indicator light light up in the instrument cluster.

3. Press the

button again to reactivate Dynamic Stability Control.

In the instrument cluster, the DSC OFF display and the Dynamic Stability Control indicator light go out.

## Display

#### In the instrument cluster

DSC OFF: Display in the instrument cluster when Dynamic Stability Control is deactivated.

## Indicator and warning lights



Indicator light is illuminated: Dynamic Stability Control is deactivated.



Indicator light flashes: Dynamic Stability Control controls the drive and brake forces. The vehicle is being stabilised.

Decrease speed and adjust driving style to the road conditions.





Indicator light is illuminated: Dynamic Stability Control failure or initialising. No driving stabilisation.

Have the system checked immediately by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

#### Automatic programme change

Dynamic Stability Control can be activated automatically by the front-collision warning, depending on the situation.

## **Dynamic Traction Control**

## Principle

Dynamic Traction Control is a drive-optimised variant of Dynamic Stability Control.

In special road conditions, for example on uncleared, snow-covered roads or on loose surfaces, the system ensures maximum drive, but with restricted driving stability.

#### General

Maximum traction is provided when when Dynamic Traction Control is activated. Driving stability is restricted when accelerating and cornering.

Activating Dynamic Traction Control briefly may be useful in the following situations:

- When driving in slush or on uncleared, snow-covered roads.
- When driving off in deep snow or on a loose surface.
- ▶ When driving with snow chains.

#### Overview

#### Button in the vehicle





DSC OFF

## Activating/deactivating Dynamic Traction Control

1. Press the tion.

button to open the selec-

2. "Traction"

The TRACTION display and the indicator lamp for the Dynamic Stability Control light up in the instrument cluster.

3. Press the button again to reactivate Dynamic Stability Control.

The TRACTION display and the indicator lamp for the Dynamic Stability Control go out in the instrument cluster.

## Display

#### In the instrument cluster

TRACTION: Display in the instrument cluster when Dynamic Traction Control is activated.

## Indicator and warning lights



Indicator light illuminates: Dynamic Traction Control is activated.



In certain situations, Dynamic Stability Control is activated automatically:

- Active Cruise Control with distance control is activated.
- In case of a brake intervention by the frontcollision warning.
- ▶ If the suspension control system fails.
- ▶ In the event of a flat tyre.

Irrespective of the current speed, the variable sport steering reacts to the steering angle with varying steering ratios.

## **xDrive**

#### Principle

xDrive is the all-wheel drive system of the vehicle. Concerted action by the xDrive and and other suspension control systems, for example, Dynamic Stability Control, further optimises traction and driving dynamics.

#### General

xDrive distributes the driving power variably to the front and rear axles according to the driving situation and road condition.

Efficient4x4 reduces consumption by deploying all-wheel drive as required.

## M Sport differential

The active M differential steplessly locks the rear axle differential according to the driving situation. This prevents an individual rear wheel from spinning, thus providing optimum traction in all driving situations.

It is the driver's responsibility to adopt a driving style that is appropriate to the situation.

## Variable sport steering

The variable sport steering facilitates direct and agile drivability with less steering effort.



## Driver assistance systems

## Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

## Speed limit warning

#### Principle

The speed limit warning can be used to set a speed limit. A warning will be issued when this speed limit is exceeded.

#### General

The warning is repeated if the set speed limit is exceeded again after dropping below it by 5 km/h/3 mph.

# Activating/deactivating the speed limit warning

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Driver assistance"
- 5. "Safety and warnings"
- 6. "Speed warning"

## Setting the speed

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Driver assistance"
- 5. "Safety and warnings"

- 6. "Speed warning"
- 7. "Warning above:"
- 8. Select the desired setting.

# Setting the current speed as the speed limit warning

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Driver assistance"
- 5. "Safety and warnings"
- 6. "Speed warning"
- 7. "Adopt current speed"

# Speed Limit Display with no-overtaking indicator

## Speed Limit Info

#### Principle

Speed Limit Info shows the currently valid speed limit in the instrument cluster and, if necessary, the Head-up display and possibly supplementary signs.

#### General

The camera located near the interior mirror detects road signs at the edge of the road as well as variable overhead signs.

Depending on the national-market version, road signs with supplementary signs, for example, for wet road conditions, are taken into account and compared with the vehicle's onboard data, for example, the windscreen wiper signal. The road sign and associated supplementary signs are then displayed in the instrument cluster and the Head-up display, if appli-

cable, or ignored, depending on the situation. Some supplementary signs are taken into account in the speed limit evaluation, but are not displayed in the instrument cluster.

The system may also show speed limits that apply to routes that are not marked if the navigation system has current map data.

For information on the current map version and map update, see Map update in the chapter Navigation system.

Speed limits for trailer operation are displayed when the trailer socket is occupied or when the trailer operation has been activated via iDrive.

For further information:

- Owner's Handbook for Navigation, Entertainment, Communication, see page 6.
- ▶ Trailer operation, see page 269.

## No-overtaking indicator

#### **Principle**

Overtaking restriction signs and end of restriction signs which have been detected by the camera are indicated by corresponding icons in the instrument cluster and, if applicable, the Head-up display.

#### General

The system considers overtaking restrictions and ends of restrictions that are indicated by means of road signs.

It will not display anything in the following situations:

- ▶ In countries where overtaking restrictions are primarily shown by road markings.
- On routes without road signs.
- ▶ In the case of railway crossings, lane markings and other situations which indicate an overtaking restriction but which are not signposted to this effect.

Overtaking restrictions for trailer operation are not shown.

Depending on the equipment, an additional icon with distance information may also be displayed to indicate the end of the no-overtaking indicator.

## Safety information

#### ↑ WARNING

The system does not relieve you of your personal responsibility to assess the traffic situation correctly. Due to system limits, it cannot respond independently and appropriately in all traffic situations. There is a risk of accident. Adapt your driving style to the traffic conditions. Observe the traffic situation, be ready to take over steering and braking at any time, and actively intervene if the situation warrants it.

#### Sensors

The system is controlled by the camera behind the windscreen.

## Displaying Speed Limit Info

#### General

The Speed Limit Info can be shown or hidden via iDrive in the instrument cluster. Depending on the national-market version, Speed Limit Info is continuously displayed in the instrument cluster.

## Displaying Speed Limit Info

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Driver assistance"
- 5. "Driving"
- 6. "Speed Assistant"
- 7. "Speed limits"
- 8. "Show current limit"





## Display

#### General

Depending on the national-market version, supplementary signs and no-overtaking indicators are displayed together with Speed Limit Info.

## Speed Limit Info

Icon	Description
60	Present speed limit.
LIMIT	No data available on the current speed limit.
LIMIT	Speed Limit Info unavailable.

The display flashes if the detected speed limit has been exceeded.

#### No-overtaking indicator

Icon	Description
<del>-</del>	No overtaking.
	End of overtaking restriction.

## Supplementary signs

lcon	Description
(1)	Speed limit with time limit.
	The speed limit only applies in wet conditions.
*	The speed limit only applies in snow.

lcon	Description
臺	The speed limit only applies in fog.
$\leftarrow$	The speed limit applies for the exit junction on the left.
$\rightarrow$	The speed limit applies for the exit junction on the right.
<b>P</b>	The speed limit only applies when towing a trailer.
!	Depending on the equipment: speed limit with unrecognised supplementary sign.

## Speed Limit Display with Anticipatory Indicator

Depending on the equipment and nationalmarket version, an additional icon with distance information may indicate that a change in speed limit is ahead. The Anticipatory Indicator must be activated for Speed Limit Assist.

Temporary speed limits may also be displayed, for example at construction sites. Temporary speed limits can only be displayed if the following services are selected in the data protection menu for the navigation system:

- ▶ "Learning map"
- "Map update"

For further information:

- ▶ Speed Limit Assist, see page 212.
- ▶ Data protection, see page 67.

## Settings

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Driver assistance"
- 5. "Driving"
- 6. "Speed Assistant"
- 7. Select the desired setting.

## System limits

#### System limits of the sensors

For further information:

▶ Camera, see page 41.

#### **Functional limitations**

Functionality may be restricted or incorrect information may be displayed in some situations such as:

- ▶ Road signs are fully or partially concealed by objects, stickers or paint.
- Road signs do not correspond to the standard.
- ▶ In areas that are not included in the map data of the navigation system.
- ▶ In the event of invalid, outdated or unavailable map data of the navigation system.
- ▶ If there are navigation discrepancies, for example due to changes in road layout.
- ▶ If the vehicle is too close to the vehicle ahead.
- ▶ When overtaking buses or trucks with road sign stickers.
- ▶ If there are electronic road signs.
- ▶ If road signs are detected that apply to a parallel road.
- If the road signs or road layouts are specific to one country.

## Manual Speed Limiter

## Principle

The Manual Speed Limiter can be used to set a speed limit, for instance, to prevent the vehicle from exceeding speed limits.

#### General

The system allows speeds of 30 km/h/20 mph and above to be set as a speed limit. Below

the set speed limit, the vehicle can be driven without restriction.

#### Overview

## Buttons on the steering wheel

#### **Button Function**



System on/off.



To store the current speed.

Speed Limit Assist: to accept the suggested speed manually.



Rocker switch:

To change the speed limit.

## Operation

#### Switching on the speed limiter



Press the button on the steering wheel.

The current speed is adopted as the speed limit

When switching on at a standstill or driving at low speed, 30 km/h/20 mph is set as the speed limit.

The speedometer marker is set to the appropriate speed.

When switching on the speed limit, Dynamic Stability Control may be switched on and the drive mode switched to COMFORT.

## Switching off off the speed limiter



Press the button on the steering wheel.

The system switches off automatically in situations such as the following:



- When switching the engine off.
- ▶ When switching on Cruise Control.
- When activating some drive modes using Driving Experience Control.

The displays goes out.

#### To interrupt the speed limiter

The system is interrupted in reverse gear or when rolling backwards at idle.

#### Changing the speed limit



Press the rocker switch repeatedly up or down until the desired speed limit is set.

- ▶ Each time the rocker switch is tapped to the resistance point, the speed limit is increased or decreased by 1 km/h, 1 mph.
- ▶ Each time the rocker switch is pressed beyond the resistance point, the speed limit changes to the next multiple of 10 km/h on the km/h display or the next multiple of 5 mph on the mph display in the speedometer.

If the set speed limit is reached or unintentionally exceeded, for example when driving downhill, there is no active brake intervention.

If you set a speed during the journey which is below the current speed, the vehicle decelerates to the set speed limit.

The current speed can also be stored by pressing the button:



Press the button on the steering wheel.

## Exceeding of speed limit

The system gives a warning if the vehicle's speed exceeds the set speed limit.

You can intentionally exceed the speed limit.

To intentionally exceed the set speed limit, press the accelerator pedal all the way down.

The limit automatically becomes active again as soon as the current speed falls below the set speed limit.

#### Warning when the speed limit is exceeded

#### Visual warning



If the speed limit is exceeded: the in-LIM dicator light in the instrument cluster I flashes for as long as the set speed

limit is exceeded.

#### Acoustic warning

- ▶ A warning sounds if you inadvertently exceed the set speed limit.
- ▶ If the speed limit is reduced to below the driven speed during the journey, the signal sounds after a little time.
- No signal sounds if you intentionally exceed the speed limit by fully pressing the accelerator pedal.

## Displays in the instrument cluster

## Display in the speedometer

Depending on the equipment, a mark in the speedometer displays the status of the system.



- ▶ Green marker: system is active.
- ▶ Grey mark: the system is interrupted.
- No marker: system is switched off.

#### Indicator light



- ▶ Indicator light illuminates: the system is switched on.
- Indicator light flashes: set speed limit is exceeded.
- ▶ Grey indicator light: the system is interrupted.

## Cruise Control without distance control

## Principle

Cruise Control allows a set speed to be specified using the buttons on the steering wheel. The set speed is then maintained by the system. It does this by automatically accelerating and braking the vehicle as necessary.

#### General

The system can be activated starting at 30 km/h/20 mph.

Depending on the vehicle setting, the characteristics of Cruise Control may change in certain areas, for example acceleration in ECO PRO drive mode is less pronounced.

## Safety information

#### ↑ WARNING

The system does not relieve you of your personal responsibility to assess the traffic situation correctly. Due to system limits, it cannot respond independently and appropriately in all traffic situations. There is a risk of accident. Adapt your driving style to the traffic conditions. Observe the traffic situation, be ready to take over steering and braking at any time, and actively intervene if the situation warrants it.

#### ↑ WARNING

The risk of accident may increase if the system is used in certain situations, such as:

- ▶ On stretches of road with many corners and bends.
- ▶ In heavy traffic.
- ▶ If the road is icy, if there is fog or snow, in wet conditions or on a loose road surface.

There is a risk of accident or material damage. Only use the system if it is possible to drive at a constant speed.



#### ↑ WARNING

The set speed may be set incorrectly by mistake or called up accidentally. There is a risk of accident. Adjust the set speed to the traffic conditions. Observe the traffic situation and intervene actively if the situation warrants it.

#### ↑ WARNING

Individual functions may malfunction when tow-starting or towing away with activated front-collision warning or Cruise Control switched on. There is a risk of accident. Turn off the front-collision warning and Cruise Control before tow-starting or towing away.





#### Overview

## Buttons on the steering wheel

#### **Button Function**



Cruise Control on/off.



RESUME

To resume Cruise Control with last setting.



To interrupt Cruise Control.



To store the current speed.

Speed Limit Assist: to accept the suggested speed manually.



Rocker switch:

To set the speed.

## Turning the Cruise Control on/off

#### Switching on the system



Depending on the equipment, press the corresponding button on the steering wheel.



The indicator lights are illuminated in the instrument cluster and the marker in the speedometer is positioned at the current speed.

Cruise Control is active. The driven speed is maintained and stored as the set speed.

If necessary, the Dynamic Stability Control will be turned on.

#### Switching the system off



Depending on the equipment, press the corresponding button on the steering wheel.



The displays goes out. The stored set speed is deleted.

## To interrupt Cruise Control

## Manually interrupting the system



Press the button while the system is activated.

#### Interrupting the system automatically

The system is interrupted automatically in the following situations:

- ▶ When braking manually.
- ▶ Selector lever position D is disengaged.
- ▶ When Dynamic Traction Control is enabled or Dynamic Stability Control is disabled.
- ▶ When Dynamic Stability Control is regulating.

## Setting the speed

#### Maintaining and saving the speed



While the system is interrupted, press the rocker switch up or down once.

When the system is switched on, the current speed is maintained and stored as the set speed.

The stored speed is displayed on the speedometer.

If necessary, the Dynamic Stability Control will he turned on.

The speed can also be stored by pressing the button.

**SET** 

Press the key.

## Changing the speed



Press the rocker switch repeatedly up or down until the set speed is set.

If the system is active, the displayed speed is stored and the vehicle adjusts to the stored speed when the road is clear.

- ▶ Each time the rocker switch is tapped to the resistance point, the set speed is increased or decreased by 1 km/h, 1 mph.
- ▶ Each time the rocker switch is pressed past the resistance point, the set speed changes by 10 in the km/h display or 5 in the mph display in the speedometer.

The maximum speed which can be set depends on the vehicle.

▶ When the rocker switch is pressed to the resistance point and then held there; the vehicle accelerates or decelerates without the need to press the accelerator pedal.

When the rocker switch is released, the vehicle maintains the final speed. Pressing

beyond the resistance point accelerates the vehicle more rapidly.

## Resuming Cruise Control

If Cruise Control is interrupted, it can be resumed by calling up the stored speed.

Before calling up the stored speed, make sure that the difference between the current speed and the stored speed is not too great. Otherwise, there may be unintentional deceleration or acceleration.



With the system interrupted, press the RESUME button.

Cruise Control is resumed with the stored values.

In the following instances, the stored speed value is deleted and therefore cannot be called up again:

- ▶ When the system is switched off.
- ▶ When drive-ready state is switched off.

## Displays in the instrument cluster

#### Display in the speedometer

Depending on the equipment, a mark in the speedometer displays the status of the system.



- ▶ Green marker: system is active, the marker shows the set speed.
- Grey marker: system is interrupted; the marker shows the stored speed.
- ▶ No marker: system is switched off.



#### Indicator light



- Green indicator light: the system is active.
- Grey indicator light: the system is interrupted.
- No indicator light: the system is switched off.

## Displays in the Head-up display

Some information from the system can also be shown in the Head-up display.



The icon is displayed when the selected set speed has been reached.

#### System limits

The set speed is also maintained when driving downhill. The vehicle may not achieve the set speed on uphill gradients if there is not enough drive power.

In ECO PRO drive mode, it is possible that the vehicle will drive faster or slower than the set speed setting in some situations, for example on downhill or uphill gradients.

## Active Cruise Control with distance control

## Principle

Active Cruise Control allows the driver to specify a set speed and a desired distance from the vehicle in front, using the buttons on the steering wheel.

#### General

When the road ahead is clear, the system maintains the set speed. The vehicle accelerates or brakes automatically.

If there is a vehicle driving in front, the system adapts the speed of your vehicle in order to maintain the set distance from the vehicle

ahead. The speed is adapted as far as the given situation allows.

The distance can be set in several stages and for safety reasons is dependent on the respective speed.

If the vehicle ahead brakes to a standstill and drives off again shortly afterwards, the system is able to comprehend this as far as given conditions allow.

Otherwise, drive off yourself, for example by pressing the accelerator pedal or rocker switch on the steering wheel.

Depending on the vehicle setting, the characteristics of Cruise Control may change in certain areas, for example acceleration in ECO PRO drive mode is less pronounced.

#### Safety information



#### MARNING

The system does not relieve you of your personal responsibility to assess the traffic situation correctly. Due to system limits, it cannot respond independently and appropriately in all traffic situations. There is a risk of accident. Adapt your driving style to the traffic conditions. Observe the traffic situation, be ready to take over steering and braking at any time, and actively intervene if the situation warrants it.



#### ⚠ WARNING

An unsecured vehicle can start moving and roll away. There is a risk of accident. Before leaving the vehicle, secure the vehicle against rolling away.

Observe the following to ensure that the vehicle is secured against rolling away:

- > Apply the parking brake.
- > Turn the front wheels towards the kerb on uphill or downhill gradient.
- Additionally secure the vehicle on uphill or downhill gradient, for example with a chock.

## **⚠** WARNING

The set speed may be set incorrectly by mistake or called up accidentally. There is a risk of accident. Adjust the set speed to the traffic conditions. Observe the traffic situation and intervene actively if the situation warrants it.

#### **⚠** WARNING

There is a risk of accident if the difference in speed relative to other vehicles is too great. This may occur, for example, in the following situations:

- ▶ When quickly approaching a slowly moving vehicle.
- ▶ If another vehicle suddenly veers into the vehicle's own driving lane.
- ▶ When quickly approaching stationary vehicles.

There is a danger of injury or danger to life. Observe the traffic situation and intervene actively if the situation warrants it.

#### **⚠** WARNING

Individual functions may malfunction when tow-starting or towing away with activated front-collision warning or Cruise Control switched on. There is a risk of accident. Turn off the front-collision warning and Cruise Control before tow-starting or towing away.

#### Overview

#### Buttons on the steering wheel

#### Button Function



Cruise Control on/off.



To store the current speed.

Speed Limit Assist: to accept the suggested speed manually.



To resume Cruise Control with last setting.



To interrupt Cruise Control.



To increase the distance.

To switch distance control on/off.



To reduce the distance.

To switch distance control on/off.



Rocker switch:

To set the speed.

#### Sensors

The system is controlled using the following sensors:

- Cameras behind the windscreen.
- ▶ Front radar sensor.

For further information:

Sensors in the vehicle, see page 41.

#### Use

The system can be used to optimum effect on well-constructed roads.

The minimum speed that can be set is 30 km/h, approx. 20 mph.





The maximum speed which can be set is limited and depends on the vehicle and its equipment, for example.

Higher speeds can be set by switching to Cruise Control without distance control.

The system can also be activated when the vehicle is at a standstill.

# Turning the Cruise Control on/off or interrupting it

#### Switching on the system



Press the button on the steering wheel.

The indicator lights are illuminated in the instrument cluster and the marker in the speedometer is positioned at the current speed.

Cruise Control is active. The driven speed is maintained and stored as the set speed.

If necessary, the Dynamic Stability Control will be turned on.

#### Switching the system off

When switching off with the vehicle at a standstill, depress the brake at the same time.



Press the button on the steering wheel.

The displays goes out. The stored set speed is deleted.

## Manually interrupting the system



With the system active, press the button on the steering wheel.

If interrupting the system when the vehicle is at a standstill, depress the brake at the same time.

#### Interrupting the system automatically

The system is interrupted automatically in the following situations:

- ▶ The driver brakes.
- ▶ Selector lever position D is disengaged.
- When Dynamic Traction Control is enabled or Dynamic Stability Control is disabled.
- When Dynamic Stability Control is regulating.
- When the vehicle is stationary, the seat belt is unfastened and the driver's door is opened.
- The system has not detected any objects for an extended period, for example, on a road with very little traffic without curb or shoulder markings.
- The detection range of the radar is impaired, for example, by contamination or heavy precipitation.
- After an extended stationary period, if the vehicle was decelerated to a standstill by the system.

## Setting the speed

## Maintaining and saving the speed



While the system is interrupted, press the rocker switch up or down once. The system is activated.

The current speed is maintained and stored as the set speed.

The stored speed is displayed on the speedometer.

If necessary, the Dynamic Stability Control will be turned on.

The speed can also be stored by pressing the button.



Press the kev.

#### Changing the speed



Press the rocker switch repeatedly up or down until the set speed is set.

If the system is active, the displayed speed is stored and the vehicle adjusts to the stored speed when the road is clear.

- ▶ Each time the rocker switch is tapped to the resistance point, the set speed is increased or decreased by 1 km/h, 1 mph.
- ▶ Each time the rocker switch is pressed past the resistance point, the set speed changes by 10 in the km/h display or 5 in the mph display in the speedometer.

To repeat an action, hold the rocker switch in the relevant position.

## Adjusting the distance

## Safety information



#### ↑ WARNING

The system does not relieve you of your personal responsibility. System limits may mean that deceleration is performed too late. There is a risk of accident or material damage. Pay close attention to the traffic situation at all times. Adapt the distance to suit traffic and

weather conditions and comply with the prescribed safe distance by braking if necessary.

#### Reducing the distance



Press the button repeatedly until the desired distance is set.

The selected distance is displayed in the instrument cluster.

#### Increasing the distance



Press the button repeatedly until the desired distance is set.

The selected distance is displayed in the instrument cluster.

## Resuming Cruise Control

If Cruise Control is interrupted, it can be resumed by calling up the stored speed.

Before calling up the stored speed, make sure that the difference between the current speed and the stored speed is not too great. Otherwise, there may be unintentional deceleration or acceleration.



If the system has been interrupted, press the button on the steering wheel.

Cruise Control is resumed with the stored values.

In the following instances, the stored speed value is deleted and therefore cannot be called up again:

- When the system is switched off.
- When drive-ready state is switched off.



## Switching between Cruise Control with/without distance control

## Safety information



#### MARNING

The system will not respond to traffic travelling in front of you, but instead maintains the stored speed. There is a risk of accident or material damage. Adjust the set speed to the traffic conditions and brake if necessary.

## Switching the Cruise Control mode

To switch Cruise Control without distance control on and off:



Press and hold the button.



Press and hold the button.

Switch on distance control:



Press the hutton.



Press the button.

After switching, a Check Control message is then displayed.

## Displays in the instrument cluster

#### General

Depending on the equipment, the displays in the instrument cluster may vary.

#### Display in the speedometer

Depending on the equipment, a mark in the speedometer displays the status of the system.



- Green marker: system is active, the marker shows the set speed.
- ▶ Grey marker: system is interrupted; the marker shows the stored speed.
- No marker: system is switched off.

#### Indicator and warning lights

Depending on the equipment:

#### **Icon**

#### Description



White vehicle symbol:

No display of distance control because the accelerator pedal is being pressed.



Green icon:

Vehicle ahead detected.

The vehicle symbol goes out if no vehicle in front is detected.

Vehicle symbol flashes green:

Preceding vehicle has driven off.



Grey icon:

System interrupted.



Icon flashes grey:

The requirements for system operation are no longer being met.

The system has been deactivated but will continue to brake until you actively take over by depressing the brake or accelerator pedal.



Vehicle symbol flashes red and an acoustic signal sounds:

Brake and take avoidance manoeuvre if necessary.

## Displays in the Head-up display

#### Set speed

Some information from the system can also be shown in the Head-up display.



The icon is displayed when the selected set speed has been reached.

#### Distance information



The icon is shown if your vehicle is too close to the vehicle ahead.

The distance information is active under the following circumstances:

- Active Cruise Control with Distance control is switched off.
- ▷ Display in the Head-up display selected. Head-up display, see page 142.
- ▶ Distance too close.
- Speed above approximately 70 km/h, 40 mph.


## System limits

## System limits of the sensors

For further information:

- ▶ Cameras, see page 41.
- ▶ Radar sensors, see page 42.

## **Detection range**



The system's detection capability and automatic braking capacity are limited.


For example, two-wheel vehicles may not be detected.

#### Deceleration

The system does not decelerate in the following situations:

- ▶ For pedestrians or similarly slow road users.
- Depending on the equipment and nationalmarket version at red traffic lights.
- ▶ For crossing traffic.
- For oncoming vehicles.


#### Vehicles cutting in



If another vehicle suddenly cuts in front of you, the system might not be able to restore the selected distance automatically. In some circumstances, it may also not be possible to restore the selected distance if you are driving significantly faster than vehicles in front, for example when rapidly approaching a lorry. If a vehicle is clearly detected in front of you, the system prompts you to intervene by braking, and if necessary by taking avoidance manoeuvre.




#### Cornering



If the set speed is too high for cornering, it will be reduced slightly in the bend. However, since bends may not be anticipated in advance, moderate your speed when cornering.

The system has a restricted detection range. Situations can arise on tight bends where a vehicle driving in front will not be detected or will be detected very late.



When your vehicle is approaching a bend, the curvature may cause the system to respond temporarily to vehicles in the other lane. If the system responds by decelerating the vehicle, you may compensate for this by accelerating briefly. When the accelerator pedal is released again, the system will resume control of the vehicle's speed.

## **Driving off**

The vehicle cannot drive off automatically in some situations, for example:

- On steep upward gradients.
- ▶ Before bumps or rises in the road.
- ▶ When towing a heavy trailer.

In such cases, press the accelerator pedal.

#### Weather

In adverse weather and lighting conditions, system functionality may be limited as follows:

- Impaired detection of vehicles.
- ▶ Brief interruptions when vehicles have already been detected.

Pay attention when driving and respond to the prevailing traffic situation. If necessary, intervene actively, for example by braking, steering or taking avoidance manoeuvre.

#### Drive power

The set speed is also maintained when driving downhill. The vehicle may not achieve the set speed on uphill gradients if there is not enough drive power.

In ECO PRO drive mode, it is possible that the vehicle will drive faster or slower than the set speed setting in some situations, for example on downhill or uphill gradients.

## Speed Limit Assist

## Principle

Speed Limit Assist helps the driver to observe speed limits. A suggested speed can be adopted.

#### General

When the systems in the vehicle, for example Speed Limit Info, detect a change in the speed limit, it is possible to adopt this new speed value for the following systems:

- Manual Speed Limiter.
- Cruise Control.
- Active Cruise Control with distance control.

The speed value is proposed as a new set speed for adopting. The relevant system must be activated for the speed value to be adopted.

## Safety information



#### MARNING

The system does not relieve you of your personal responsibility to assess the traffic situation correctly. Due to system limits, it cannot respond independently and appropriately in all traffic situations. There is a risk of accident. Adapt your driving style to the traffic conditions. Observe the traffic situation, be ready to take over steering and braking at any time, and actively intervene if the situation warrants it.



#### ↑ WARNING

The set speed may be set incorrectly by mistake or called up accidentally. There is a risk of accident. Adjust the set speed to the traffic conditions. Observe the traffic situation and intervene actively if the situation warrants it.

#### Overview

## Buttons on the steering wheel

#### **Button Function**



To accept the suggested speed manually.



Rocker switch:

To set the speed; see Cruise Control.

## Switching Speed Limit Assist on/off

- 1. "MFNU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Driver assistance"
- 5. "Driving"

- "Speed Assistant"
- 7. "Speed limits"
- 8. Select the desired setting:
  - "Adjust manually": detected speed limits can be applied manually.
  - ▶ "Show anticipation": Depending on the national-market version: current and upcoming speed limits are displayed on the instrument cluster without being applied.
  - ▶ "Show current limit": current speed limits are displayed without being applied in the instrument cluster.
  - ▶ "Off": depending on the national-market version, Speed Limit Info and Speed Limit Assist will be turned off.
    - Other proactive comfort functions the Route-ahead Assistant, for example may be switched off.

## Displays in the instrument cluster

A message is displayed in the instrument cluster when the system and a driver assistance system are activated.





#### Icon Function



Depending on the equipment, the indicator light illuminates green, together with the icon for a Cruise Control System:

Speed Limit Assist is active and detected speed limits can be adopted manually for the displayed system.



Detected change in speed limit detected with immediate effect.

Remaining distance display shown alongside the icon indicates there might be a change in the speed limit up ahead.



Indicator light is illuminated green: the detected speed limit can be adopted with the SET button.

A green tick is displayed once it has been adopted.

#### Manual adoption

A detected speed limit can be applied manually for the active driver assistance system.



When the SET icon is illuminated, press the button.

## Speed adjustment

## Principle

It is possible to set whether the speed limit will be accepted exactly, or with a tolerance.

#### General

A speed adaptation for all speed limits and an additional speed adaptation for speed limits up to 60 km/h. 40 mph can be set up.

The additional speed adjustment for speeds up to 60 km/h, 40 mph can be activated or deactivated.

#### Setting the speed adjustment

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Driver assistance"
- 5. "Driving"
- 6. "Speed Assistant"
- 7. Select the desired setting:
  - "Adjust speed limits": to set a speed adjustment tolerance that will affect all speeds.
  - > "2nd adjustm. up to": to activate or deactivate additional speed adjustment.
  - "Adjust speed limits": with activated additional speed adjustment, set the tolerance for speed limits up to 60 km/h, 40 mph.

## System limits

Speed Limit Assist is based on the Speed Limit Info system.

Take into account the Speed Limit Info system limits.

Depending on the national-market version, upcoming speed limits may not be available for application or they may only be available to a certain extent, for instance speed information from the map data of the navigation system.

Cruise Control without distance control: depending on the system, it may not be possible to adopt speed limits automatically.

For further information:

- ▶ Limits of the Speed Limit Information system, see page 201.
- ▶ System limits of the sensors, see page 41.

## Parking

## Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

## Park assistance systems

#### General

The parking assistance systems include different individual systems. The individual systems provide support with assistance functions, sensors and different camera views when parking, manoeuvrina or drivina in reverse.

For further information:

- ▶ Reversing Assist Camera, see page 219.
- Automatic camera perspective, see page 220.
- ▶ Flank view, see page 220.
- ▶ 3D view, see page 221.
- ▶ Zoom to trailer tow hitch, see page 221.
- ▶ Washing bay view, see page 221.
- ▶ Panorama View, see page 222.
- ▶ Door opening angle, see page 223.
- ▶ Remote 3D View, see page 224.
- ▶ Park Distance Control, see page 224.
- ▶ Active Park Distance Control, see page 227.
- ▶ Park Assist, see page 229.
- ▶ Reversing Assistant, see page 233.

## Safety information

#### ↑ WARNING

The system does not relieve you of your personal responsibility to assess the traffic situation correctly. Due to system limits, it cannot respond independently and appropriately in all traffic situations. There is a risk of accident. Adapt your driving style to the traffic conditions. Observe the traffic situation, be ready to take over steering and braking at any time, and actively intervene if the situation warrants it.

#### Overview

#### Button in the vehicle





Park Assist button



Panorama View

#### Sensors

The parking assistance systems are controlled by the following sensors:

- ▶ Ultrasonic sensors in the front/rear bumpers.
- Side ultrasonic sensors.



- 1
- ▶ Side radar sensors, rear.
- Front camera.
- Exterior mirror cameras.
- Reversing Assist Camera.

For further information:

Sensors in the vehicle, see page 41.

## Operating concept

The camera-based individual systems are operated with the toolbars on the control display. Choose a camera view by selecting the appropriate icon.

Some parking assistance systems can be configured individually in the Parking menu.

#### Go to Park menu

#### Via Parking Assistant button



Press the button.

- 2. 👸 "Settings"
- 3. Select the desired settings.

#### Via iDrive

- 1. "MENU"
- "Vehicle apps"
- 3. "Driving settings"
- 4. "Driver assistance"
- 5. "Parking and manoeuvring"
- 6. Select the desired settings.

## Display

## Principle

The parking assistance systems display assists with parking and manoeuvring by displaying the Park Distance Control and a variety of camera perspectives.

#### General

Depending on vehicle equipment, one or more cameras record the area from different selectable perspectives.

Depending on the view, the vehicle surroundings or a partial area are displayed.

Depending on the national-market version, the automatic camera perspective or the Reversing Assist Camera is displayed.

#### Turning the display on/off

#### General

When driving forwards, the parking assistance systems display turns off automatically when a certain distance or speed is exceeded.

#### With the reverse gear

The display is automatically turned on if selector lever position R is engaged while driveready state is turned on.

#### Via Parking Assistant button




Press the key.

## Display on the control display

#### General


The display on the control display will vary depending on the equipment and the activated parking assistance system.

#### Without Parking Assistant Plus



- 1 Toolbar, left
- 2 Camera image
- **3** Selection window
- 4 Toolbar, right

#### With Parking Assistant Plus



- 1 Toolbar, left
- 2 Camera image
- **3** Selection window
- **4** Automatic camera perspective
- 5 Flank view
- **6** Reversing Assist Camera
- 7 Toolbar, right

#### Toolbar, left

Depending on the equipment, different views can be selected via the left toolbar.

- ▶ ☐ "Rear view camera"
  The camera image from the Reversing Assist Camera is shown.
- ▶ P<sub>M</sub> "Only park. sensors"

▶ '\$' "Parking"

The view from different camera perspectives is displayed.

▶ ③ "3D view"

A three-dimensional representation is displayed.

▶ → "Tow hitch"

The zoom for the trailer tow hitch can be turned on.

▶ a "Car wash"

The display of your own lane can be turned on for easier driving into the car wash.

#### Toolbar, right

The parking assistance functions are displayed in the right toolbar. The display may vary depending on the equipment.

- ▶ Status of the parking assistance systems.
- ▶ P "Park Assist"
  Park Assist functions.
- ▶ Reversing Assistant"
  Functions of the Reversing Assistant.
- ▶ ☼ "Settings" Settings in the Parking menu.

# Status of the parking assistance systems

The status of active parking assistance systems is indicated by symbols on the right toolbar.





lcon	Meaning
((1/2))	No search for Park Assist services. Park Assist has failed.
(((P)))	Search for Park Assist services is active.
P⊕	Park Assist: when the icon is green, Park Assist is active. The system takes control of the vehicle.
	Reversing Assistant: when the icon is green, Reversing Assistant is active. The system takes control of the steering.

#### Additional displays

#### General

Additional views, e.g. parking assistance lines, can be faded in on the camera image on the parking assistance system display to facilitate parking and manoeuvring.


#### Switching additional displays on/off

Multiple additional displays can be active at the same time.

#### Via Parking Assistant button

- 1. Activate camera image.
- 2. 🚳 "Settings"
- 3. Select the desired settings.

#### Parking assistance lines



Driving lane lines help to estimate the space required when parking and manoeuvring on level roads.

The driving lane lines are continuously adapted to the steering wheel movements depending on the steering wheel angle.



Turning circle lines can only be superimposed on the camera image together with lanes.


The lines show the course of the smallest possible turning circle on a level road.

Once the steering wheel has been turned beyond a certain angle, only one turning circle line is displayed.

#### Using parking assistance lines

- Position the vehicle so that the red turning circle line is within the boundaries of the parking space.
- Turn the steering wheel so that the green driving lane line covers the corresponding turning circle line.

### Obstacle marking



Obstacles are detected by the sensors.

Obstacles detected by Park Distance Control are marked on the camera image.

Coloured gradations of the obstacle markings in green, yellow and red indicate the distances.

#### **Functional limitations**

The system can only be used to a restricted extent in the following situations:

- ▶ With a door open.
- ▶ With open luggage compartment.
- With the exterior mirrors folded in.

Areas with grey hatching with an icon in the camera image identify areas that are currently not shown, for example an open door.

# System limits

#### Safety information



#### ↑ WARNING

Due to system limitations, the system may not respond at all, or may respond too late, incorrectly or for no reason. There is a risk of accident or material damage. Observe the information on the system limits and intervene actively if necessary.

### System limits of the sensors

For further information:

Sensors in the vehicle, see page 41.

#### Non-visible areas

Due to the angle of view, the area under the vehicle cannot be seen by the cameras.

#### **Detection of objects**

The system cannot detect very low obstacles and higher, protruding objects such as ledges.

The objects shown in the control display may be closer than they appear. Do not estimate the distance to the objects on the control display.

Projecting loads, rear luggage racks, or trailers can restrict the detection range of the camera.

#### Malfunction

Failure of one camera is shown on the control display.

The detection range of the failed camera is displayed hatched on the control display.

# Reversing Assist Camera

### Principle

The Reversing Assist Camera assists in reverse parking and manoeuvring. It does this by showing an image of the area behind the vehicle on the control display.

Additional displays can be shown in the display, for example parking assistance lines and obstacle marking.

#### General

Follow the information in the Chapter "Parking assistance systems".

### Operating requirements

- ▶ The luggage compartment is fully closed.
- > The camera area is clean and unobstructed.





# Deactivated Reversing Assist Camera

When the Reversing Assist Camera is deactivated, for example when the luggage compartment is open, the camera image is displayed hatched in arev.

# Automatic camera perspective

#### Principle

The automatic camera perspective displays a steering angle-dependent view looking towards the vehicle's direction of travel.

This perspective adapts to the current driving situation.

#### General

As soon as obstacles are detected, the view switches to a fixed display of the area in front of or behind the bumper or, if necessary, to the Lateral Parking Aid page.

When reverse gear is engaged, the automatic camera perspective is exited if necessary and the view of the Reversing Assist Camera is displayed. If required, select the automatic camera perspective with reverse gear engaged. The automatic camera perspective is retained for the current parking manoeuvre.

Follow the information in the Chapter "Parking assistance systems".

# Lateral Parking Aid

### Principle

The Lateral Parking Aid is automatically displayed when the automatic camera perspective is switched on. This feature shows obstacles located near the vehicle.

#### General

Follow the information in the Chapter "Parking assistance systems".

#### Display



Obstacle markings are displayed at the sides of the vehicle to protect the vehicle's flanks.

- No markings: no obstacles have been detected.
- Coloured markings: warning that obstacles have been detected.

#### System limits

The system only shows stationary obstacles that were previously detected by the sensors when driving past.

The system does not detect whether an obstacle subsequently moves. Consequently, the markings will no longer be shown on the display after the vehicle has been stationary for a while. The area next to the vehicle needs to be scanned again.

# Flank view

### Principle

The flank view displays the area at the side to assist with positioning the vehicle at the kerb or alongside any other obstacles.



Flank view looks from the rear to the front. If there is a hazard, it automatically focuses on possible obstacles.

Flank view can be selected for the right or left side of vehicle.

Follow the information in the Chapter "Parking assistance systems".

### 3D view

### Principle

When the 3D view is selected, a circle is displayed on the control display.

Specified perspectives can be selected on the circle.

#### General

The current perspective is identified by a camera icon.

To exit the feature, select another camera feature on the left toolbar.

Follow the information in the Chapter "Parking assistance systems".

# Zoom to trailer tow hitch

#### Principle

To assist with connecting up a trailer, it is possible to zoom in on the area around the trailer tow hitch.

#### General

When zooming in, remember that the view might no longer show certain obstacles.

Follow the information in the Chapter "Parking assistance systems".

# Turning zoom on trailer tow hitch on/off



Press the button.

2. "Tow hitch"

# Display



Two static circle segments show the distance between the trailer and the trailer tow hitch.

A docking line dependent on the steering wheel angle assists you in lining up the trailer tow hitch with the trailer.

# Washing bay view

#### Principle

The washing bay view assists when entering a car wash.

#### General

Follow the information in the Chapter "Parking assistance systems".

# Turning the car wash view on/off




Press the button.

2. "Car wash"

# 1

#### Display



Your own lane is displayed for easier driving into a car wash.

### Panorama View

#### Principle

The panoramic view gives you an earlier view of crossing traffic at blind driveway exits and road junctions.

#### General

Road users hidden by obstacles at the side may not be seen from the driver's seat until very late. The front camera and the Reversing Assist Camera capture the area around the side of the vehicle to improve the view.

The camera image is subject to varying levels of distortion in some areas and is thus not suitable for estimating distances.

Depending on the equipment, the function can be used when driving forwards or reversing.

Follow the information in the Chapter "Parking assistance systems".

#### Sensors

The system is controlled by the following cameras:

- Reversing Assist Camera.
- Front camera.

## Switching the panorama view on/off



Press the key.

### Display



Yellow lines on the screen mask identify the bumpers of your own vehicle.

Depending on the engaged selector lever position, the camera image of the Reversing Assist Camera or front camera will be displayed.

#### Activation points

#### Principle

Positions at which the panoramic view should switch on automatically can be saved as activation points.

#### General

Up to ten activation points can be saved.

Depending on the national-market version, the activation points can be used for driving forwards and reversing.

Follow the information in the Panorama view chapter.

#### Operating requirements

- ▶ A GPS signal must be received.
- A BMW ID or a driver profile must be activated.
- The direction of travel, selector lever position and vehicle angle must correspond to a saved activation point.

#### Saving activation points

1. Drive the vehicle to the position where the system should switch on and stop.



Press the button.

"Activation point"The current position is shown.

4. "Save activation point"

Activation points are stored with one of the following where possible:

- ▶ Location.
- Location and street.
- GPS coordinates.

### Using activation points

Use of activation points can be switched on and off.



Press the button.

- 2. "Settings"
- 3. "GPS-based"

### Displaying activation points



Press the button.

2. "Manage points"

A list of all activation points is shown.

## **Editing activation points**



Press the button.

2. "Manage points"

A list of all activation points is shown.

- 3. Select an activation point if necessary.
- 4. Select the desired setting.

# Door opening angle

#### Principle

Depending on the equipment, the door opening angle indicator is displayed automatically.

If obstacle marking is activated, the parking view indicates fixed obstacles that obstruct the opening angles of the doors.

The system does not issue warnings about approaching road users.

#### General

Follow the information in the Chapter "Parking assistance systems".

### Display



The maximum door opening angles are displayed when the selector lever is in position P.

#### System limits

For technical reasons, the display of the vehicle surroundings is distorted.





Even if the door opening angle indicator on the control display does not superimpose any other objects, it is necessary to park carefully next to other objects.

The perspective means that protruding objects located higher up may be closer than they appear on the control display.

## Remote 3D View

### Principle

The BMW app and the camera pictures in the parking view, for example automatic camera perspective, enable the display of the vehicle surroundings on a mobile end device.

The function shows a view of the current situation.

#### General

For reasons related to data protection, the function can only be run three times in two hours.

Follow the information in the Chapter "Parking assistance systems".

#### Sensors

The system is controlled by the following cameras:

- > Front camera.
- ▶ Exterior mirror cameras.
- Reversing Assist Camera.

## Operating requirements

- Data transfer must be activated.
   Data protection, see page 67.
- The BMW app must be installed on the mobile device.
- ConnectedDrive countries: a BMW ID with an existing ConnectedDrive account must be activated.

BMW ID/driver profiles, see page 68.

# Activating/deactivating Remote 3D View

The function can be activated or deactivated individually or together with other functions.

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "System settings"
- 4. "Data privacy"
- Select the desired setting.After the activation, Remote 3D View can be accessed in the BMW app.

#### **Functional limitations**

The system may have restricted functionality or may not be available at all in situations such as the following:

- With a door or the luggage compartment open. Areas that the system is not able to record are shown dark on the display.
- If the exterior mirrors have been folded in manually.
- When other camera functions are being run in the vehicle.
- ➤ The vehicle moves faster than at walking speed.
- In case of missing or weak Internet connection.

# Park Distance Control

# Principle

Park Distance Control assists with parking. Obstacles in front of or behind the vehicle are signalled by acoustic and visual warnings.

Obstacles that are detected by the side ultrasonic sensors can also be reported.



The range of the system is approximately 2 m. 6 ft. depending on the obstacle and environmental factors.

An acoustic warning is given when the vehicle is approx. 70 cm, 27 in away from an object and a collision is imminent.

For objects behind the vehicle, the acoustic warning is given sooner, at a distance of approx. 1.50 m, 5 ft.

Follow the information in the Chapter "Parking assistance systems".

## Safety information



#### ↑ WARNING

The system does not relieve you of your personal responsibility to assess the traffic situation correctly. Due to system limits, it cannot respond independently and appropriately in all traffic situations. There is a risk of accident. Adapt your driving style to the traffic conditions. Observe the traffic situation, be ready to take over steering and braking at any time, and actively intervene if the situation warrants it.



#### MARNING

Approaching at high speed when Park Distance Control is activated may result in late warnings due to the physical conditions. There is a danger of injury or material damage. Avoid approaching an object at speed. Avoid driving off at speed while Park Distance Control is not yet activated.

#### Sensors

The system is controlled using the following sensors:

- ▶ Ultrasonic sensors in the front/rear bump-
- Side ultrasonic sensors.

### Turning Park Distance Control on/off

#### Switching on the system automatically

The system switches on automatically in the following situations:

- ▶ When the drive-ready state is turned on when engaging selector lever position R.
- ▶ When approaching detected obstacles, if the speed is less than approximately 4 km/h, approx. 2.5 mph The distance from the obstacle at which the system activates depends on the individual situation.

Automatic switch-on on detection of obstacles can be enabled and disabled.

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Driver assistance"
- 5. "Parking and manoeuvring"
- 6. "Automatic PDC activation"

### Turning off the system automatically

When driving forwards, the system turns off automatically when a certain distance or speed is exceeded, if necessary.

# Switching the system on/off manually



Press the key.

- On: the LED is illuminated.
- ▶ Off: the LED is extinguished.

If the system is manually turned on when reverse gear is engaged, the image of the Reversing Assist Camera is displayed.





Depending on the national-market version, the system cannot be turned off manually when the reverse gear is engaged.

### Acoustic warning

#### General

An intermittent tone indicates that the vehicle is approaching an object. For example, if an object is detected to the rear left of the vehicle, the sound is emitted from the rear left loudspeaker.

The shorter the distance to an object, the shorter the intervals of the intermittent tones.

A continuous tone sounds if the distance to a detected object is less than approximately 20 cm, 8 in.

An alternating continuous tone sounds between the front and rear loudspeakers if there are objects in front and behind the vehicle at the same time and at a distance of less than approximately 20 cm, 8 in.

The intermittent tones and the continuous tone are turned off when selector lever position P is engaged.

Depending on the national-market version, the interval tones are switched off after a short time with the vehicle at a standstill.

If an object approaches when the vehicle is stationary, the acoustic signal is reactivated.

#### Adjusting the volume

The volume of the acoustic warning can be adjusted.

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Driver assistance"
- 5. "Parking and manoeuvring"
- 6. "PDC signal volume"
- 7. Set the desired value.

### Visual warning

#### General

When you are approaching an object, its proximity is displayed on the control display as soon as the system is activated.

Objects that are farther away are already displayed before a signal sounds.

The detection range of the sensors is represented by hatched annular surfaces. Markings in green, yellow and red indicate when obstacles are detected in the detection range.

Depending on the view, driving lane lines, turning circle lines and obstacle markings are shown for a better estimation of the space required.

If the vehicle is equipped with a Crossing-traffic Warning: the display also warns of vehicles approaching from behind.

Obstacle markings are displayed at the sides of the vehicle to protect the vehicle's flanks.

#### Display

Depending on the equipment, warnings may be displayed in front of, next to and behind the vehicle.



Display behind the vehicle.



Display next to the vehicle.

- Hatched area: detection range of the sensors.
- Grey hatched area: no obstacles were detected in the detection range.
- Coloured markings in the hatched area: obstacles were detected in the detection range.
- ► Hatched area interrupted: the area next to the vehicle has not yet been recorded.

#### System limits

#### General

The function to protect the vehicle sides only shows stationary obstacles that were previously detected by the sensors when driving past.

The system does not detect whether an obstacle subsequently moves. The grey hatched areas on the sides are hidden after a certain period of time when the vehicle is at a standstill. The area on the side of the vehicle must be newly captured.

Also observe the limits of the system in the chapter "Parking assistance systems".

# Trailer operation

With a trailer or when the trailer socket is occupied, the rear functions of Park Distance Control are switched off.

Depending on the equipment and nationalmarket version, the rear functions of Park Distance Control remain switched on when the trailer operation is activated.

Obstacles next to the vehicle are not displayed.



An icon is displayed on the control display.

Depending on the equipment, the detection range of the sensors is shown dark on the control display.

For further information:

Operation with a trailer or rear luggage rack, see page 272.

#### False alarms

If the system is approaching its limits, false alarms may occur.

To reduce false alarms, for example in conveyor car washes, switch off automatic activation of Park Distance Control when obstacles are detected if necessary.

#### Malfunction



An icon is displayed on the control display.

The detection range of the sensors is not displayed on the control display.

A Check Control message is shown.

Park Distance Control failure. Have the system checked by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

# Active Park Distance Control

# Principle

The Park Distance Control brake function initiates emergency braking if there is an imminent risk of collision.





#### General

Due to the system limits, a collision cannot be prevented under all circumstances.

The function is available at speeds below walking speed when reversing or rolling back.

Pressing the accelerator pedal suppresses the brake intervention. No emergency braking is performed.

After emergency braking to a stop, it is possible to continue a slow approach to the obstacle. To approach, lightly depress the accelerator pedal and release it again.

If the accelerator pedal is depressed for longer, the vehicle pulls away. Manual braking is possible at any time.

Follow the information in the Chapter "Parking assistance systems".

#### Safety information



The system does not relieve you of your personal responsibility to assess the traffic situation correctly. Due to system limits, it cannot respond independently and appropriately in all traffic situations. There is a risk of accident. Adapt your driving style to the traffic conditions. Observe the traffic situation, be ready to take over steering and braking at any time, and actively intervene if the situation warrants it.

### ▲ WARNING

When the trailer tow hitch is in use, the assistance system cannot react correctly if its sensors are obstructed. There is a risk of accident or material damage. Do not use the assistance system in trailer operation or when using the trailer tow hitch, for example with a bicycle carrier.

#### Sensors

The system is controlled using the following sensors:

- Ultrasonic sensors in the front/rear bumpers.
- Side ultrasonic sensors.

# Temporarily switching off Active Park Distance Control

After emergency braking, the function can be temporarily turned off on the control display.

- 1. "Obstacle detected. Emergency braking."
- 2. "Deactivate temporarily"

If the journey is continued in these environmental conditions, no further emergency braking is performed.

The system will be turned on again automatically for the next drive.

#### Settings

It is possible to set which areas of the vehicle are protected by the system.

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Driver assistance"
- 5. "Parking and manoeuvring"
- 6. "Active PDC emergency braking"
- 7. Select the desired setting.

### Display



As soon as the system detects an obstacle, an icon is displayed with a corresponding message.



# System limits

#### General

Observe the limits of the system in the Chapter "Park assistance systems".

#### **Functional limitations**

The system cannot be used in situations such as the following:

▶ When driving with a trailer.

If applicable, switch off the system temporarily, if needed.

# Park Assist

## Principle

Park Assist supports driving into parallel and bay parking spaces and helps leaving parallel parking spaces.

#### Vehicle equipment

This system may not be available in the vehicle in question, for example due to the selected optional equipment, the national-market version or the possibility of subsequent enabling and software updates. This also applies to the individual functions of the system.

For further information:


Vehicle equipment, see page 8.

#### General


Follow the information in the Chapter "Parking assistance systems".

# Parking methods


The system supports the following functions:



Reverse parking parallel to the road, parallel parking.



Reverse parking transverse to the road, bay parking.



Leaving parallel parking spaces.

#### Operation

The operating principle and operation of the system is divided into the following steps:

- Parking space search.
- Switch on.
- Parking.
- Leaving parking space.



Parking space search is always active when the vehicle is driving forwards slow and straight.

Ultrasonic sensors measure parking spaces on both sides of the vehicle.

When the system is active, the status of the system and necessary instructions are displayed.

#### Parking manoeuvre

The system calculates the best possible option for driving in or driving out of parking spaces with parking lines and takes control of the following functions during the parking manoeuvre:

- Steering.
- Accelerating and braking.
- Changing gear.

When parking, the parking manoeuvre takes place automatically.

When leaving parallel parking spaces, the vehicle manoeuvres automatically until the vehicle reaches a position in which the driver can drive out of the parking space without further steering wheel movements.

## Safety information



#### MARNING

The system does not relieve you of your personal responsibility to assess the traffic situation correctly. Due to system limits, it cannot respond independently and appropriately in all traffic situations. There is a risk of accident. Adapt your driving style to the traffic conditions. Observe the traffic situation, be ready to take over steering and braking at any time, and actively intervene if the situation warrants it.

#### ↑ WARNING

When the trailer tow hitch is in use, the assistance system cannot react correctly if its sensors are obstructed. There is a risk of accident or material damage. Do not use the assistance system in trailer operation or when using the trailer tow hitch, for example with a bicycle carrier.

#### MOTICE

The system can steer the vehicle over or onto kerbs. There is a risk of material damage. Observe the traffic situation and intervene actively if the situation warrants it.

#### Sensors

The Park Assist is controlled by the following sensors:

- ▶ Ultrasonic sensors in the front/rear bumpers.
- Side ultrasonic sensors.

# Operating requirements

# Measurement of parking spaces

- Driving forwards in a straight line up to a maximum speed of approximately 35 km/h, 22 mph.
- Maximum distance from the row of parked vehicles: 1.5 m, 5 ft.

### Suitable parking space

#### General:

- Gap behind an object which is at least 0.5 m, 1.7 ft long.
- ▶ Gap between two objects, each at least 0.5 m, 1.7 ft long.
- ▶ Minimum length of adjoining objects approx. 1 m/3 ft.



- ▶ Minimum length of gap between two objects: own vehicle length plus approximately 0.8 m, 2.6 ft.
- ▶ Minimum depth: approximately 1.5 m, 5 ft. Bay parking:
- ▶ Minimum width of gap: own vehicle width plus approximately 0.7 m, 2.3 ft.
- ➤ Minimum depth: own vehicle length.

  The depth of bay parking spaces must be estimated by the driver. Due to technical limits, the system is only able to gauge the depth of bay parking spaces approximately.

#### Parking manoeuvre

- ▶ Doors and luggage compartment are closed.
- Driver's seat belt is fastened.

#### Leaving parking space

- The vehicle was parked using the Park Assist and an object is detected in the surrounding area of the vehicle.
- ➤ The vehicle was parked manually in reverse and objects in the immediate vicinity of the vehicle are detected. The distance to a detected kerb is at least 15 cm, approx. 6 in.
- ➤ The parking space is at least 0.8 m, 2.6 ft longer than the vehicle.

## Turning Park Assist on/off

#### Via Parking Assistant button



Press the key.

The current status of the parking space search is displayed on the right toolbar.

### With the reverse gear

Engage selector lever position R.

The current status of the parking space search is displayed on the right toolbar.

# Switching the acoustic signal on/off

The acoustic signal for suitable parking spaces can be turned on and off.

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Driver assistance"
- 5. "Parking and manoeuvring"
- 6. "Sound when available"

# Acoustic signal of the Park Distance Control

Depending on the national-market version, an intermittent tone of the Park Distance Control PDC will sound during an automatic parking manoeuvre.

A continuous tone will sound when the distance to a detected object is less than approx. 20 cm, 8 in.

#### Parking space search

- Parking space search is always active when driving forwards at a speed of up to approx. 35 km/h, approx. 22 mph and a distance of max. 1.5 m, approx. 5 ft for vehicles to be parked.
- ▶ ((P)) Park Assist is turned on and the parking space search is activated. Search for suitable parking spaces.
- ➤ Suitable parking spaces are displayed and an acoustic signal sounds.
- ▶ When parallel or bay parking spaces are clearly detected, the system automatically selects the appropriate parking method. If there are parking spaces that are large enough for both parallel and bay parking, both parking spaces are shown on the control display. The parking direction can be selected by selecting the parking space.





## Parking with Park Assist

1. Press the gear.



The display of the parking assistance systems is shown.

(((P))) Parking space search is activated.

The status of the parking space search and possible parking spaces are shown on the control display.

- 2. Select the suggested parking manoeuvre.
  - ${}^{\mbox{\bf P}}_{\mbox{\bf \Theta}}$  Green: the system takes control of the parking manoeuvre.
- 3. Follow the instructions on the control display.

The speed can be reduced with the brake. Other interventions will cancel the system.

When parking manoeuvre is complete, selector lever position P is engaged.

Completion of parking manoeuvre is indicated on the control display.

4. Adjust the parking position yourself if necessary.

### Leaving parking space with Park Assist

1. Switch on drive-ready state.

2. With the vehicle at a standstill, press the button or engage reverse gear.

The display of the parking assistance systems is shown.

- 3. Select the desired parking direction for leaving the parking space on the control display.
- 4. Follow the instructions on the control display.
  - $\mathbf{P}_{\mathbf{\Theta}}$  Green: the system takes control of the parking manoeuvre.

The speed can be reduced with the brake. Other interventions will cancel the system.

A message is displayed at the end of the manaeuvre.

Make sure that it is safe to leave a parking space with the given traffic situation, and drive off as usual.

The Park Assist is turned off automatically.

### Cancelling Park Assist manually

Park Assist can be cancelled manually at any time, for example:

Press the key.

- When the accelerator pedal is pressed lightly and the steering wheel is simultaneously moved gently.
- by depressing the accelerator pedal.

The Park Assist is cancelled without engaging selector lever position P. Driving can continue immediately.

## Cancelling Park Assist automatically

The system automatically cancels in situations such as the following:

- ▶ If the driver grips the steering wheel or steers the vehicle.
- ▶ When operating the accelerator pedal or the selector lever.
- ▶ If the parking brake is applied.
- ▶ When the driver's seat belt is unfastened.
- ▶ With open luggage compartment.
- ▶ With open bonnet.
- ▶ When the doors are open.
- During activation or intervention by driver assistance systems.
- ▶ If you switch to other functions on the control display.
- When the display on the control display is faded due to messages.

- ▶ On snow-covered or slippery road.
- On steep uphill or downhill gradients.
- ▶ If it encounters objects that are difficult to negotiate, for example kerbs.
- ▶ If objects appear suddenly.
- ▶ With insufficient distances, which are indicated by the Park Distance Control.
- When a maximum number of parking moves or the parking time is exceeded.

When the system is stopped automatically, selector lever position P is engaged.

A Check Control message is shown where applicable.

## Continuing the parking manoeuvre

If parking or leaving a parking space has been interrupted, the operation can be continued, if needed.

To do this, switch Park Assist on again and follow the instructions on the control display.

### System limits

#### General

Observe the limits of the system in the Chapter "Park assistance systems".

### No parking assistance

Park Assist does not provide assistance in the following situations:

- ▶ In tight bends.
- ▶ In angled parking spaces.
- ▶ In trailer operation.
- ▶ With parking spaces which are marked by lines on the floor only. The system orients itself on objects.
- For special parking spaces, for example paid parking spaces with automatic locking mechanisms, coin parking, or mechanical parking systems.

#### **Functional limitations**

The system may have restricted functionality in situations such as the following:

- On uneven road surfaces, for example gravel roads.
- On slippery surfaces.
- On steep uphill or downhill gradients.
- ▶ If leaves have collected or snow has drifted or been piled up in the parking space.
- ▶ If an already measured parking space changes.
- ▶ If there are ditches or sudden drops, for example at a quayside.
- In some cases, parking spaces may be detected that are not suitable or suitable parking spaces may not be detected.

#### Malfunction

A Check Control message is shown.

Park Assist has failed. Have the system checked by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

# Reversing Assistant

#### Principle

The Reversing Assistant assists when driving in reverse, for example when driving out of tight or confusing parking or street situations.

## Vehicle equipment

This system may not be available in the vehicle in question, for example due to the selected optional equipment, the national-market version or the possibility of subsequent enabling and software updates. This also applies to the individual functions of the system.

For further information:

Vehicle equipment, see page 8.





#### General

The vehicle saves the driving movements for the last distance covered. This stored distance can be driven back with automated steering.

The system takes control of the steering. The speed must be controlled by the driver using the accelerator pedal and the brake.

A maximum of 50 m, approx. 164 ft are stored. Follow the information in the Chapter "Parking assistance systems".

### Safety information



#### ↑ WARNING

The system does not relieve you of your personal responsibility to assess the traffic situation correctly. Due to system limits, it cannot respond independently and appropriately in all traffic situations. There is a risk of accident. Adapt your driving style to the traffic conditions. Observe the traffic situation, be ready to take over steering and braking at any time, and actively intervene if the situation warrants it.



#### MARNING

When the trailer tow hitch is in use, the assistance system cannot react correctly if its sensors are obstructed. There is a risk of accident or material damage. Do not use the assistance system in trailer operation or when using the trailer tow hitch, for example with a bicycle carrier.



#### ∧ NOTICE

The system can steer the vehicle over or onto kerbs. There is a risk of material damage. Observe the traffic situation and intervene actively if the situation warrants it.

## Operating requirements

- ▶ To save the distance covered, drive forwards without interruption.
- ▶ To store the distance covered, do not drive faster than 35 km/h/22 mph.
- No trailer operation.
- Dynamic Stability Control is activated.

## Reversing with automated steering

1. Switch on drive-ready state.

With the vehicle at a standstill, press 2. the button or engage reverse gear.

The display of the parking assistance systems is shown.

- Follow the instructions on the control dis
  - play as applicable.
- 4. Take your hands off the steering wheel and carefully drive in reverse with the accelerator pedal and the brake.

Green: the system takes control of the steering.

When driving in reverse, observe the vehicle surroundings.

In case of obstacles, stop immediately and take over control of the vehicle. Pay attention to the information on Park Distance Control

5. Shortly before the end of the stored distance covered, an acoustic signal will sound and a message is displayed.

Stop when you reach normal road traffic at the latest and take over control of the vehicle, for example by engaging a forward gear.

# Cancelling the Reversing Assistant manually

The assisted reversing by the Reversing Assistant can be cancelled manually:





Press the key.

# Cancelling the Reversing Assistant automatically

The system automatically cancels in situations such as the following:

- ▶ If the driver grips the steering wheel or steers the vehicle.
- When shifting from reverse gear to another selector lever position.
- During activation or intervention by driver assistance systems.
- ▶ After an extended period of time when the vehicle is stationary.
- ▶ When exiting the stored lane when reversing, for example with a maximum steering wheel angle.
- ▶ When the display on the control display is faded due to messages.
- ▶ In case of a slippery surface.
- ▶ When the vehicle is rolling, for example on a slope.
- ▶ In case of changed environmental factors.
- ▶ When the trailer socket is occupied or trailer operation is activated.
- ▶ At speeds over approximately 9 km/h, approx. 6 mph.

# System limits

The maximum speed when driving in reverse is limited to approx. 9 km/h, approx. 6 mph.

A warning occurs at a speed of approx. 7 km/h/4 mph.

If the maximum speed is exceeded, the function will be cancelled.

▶ After driving a stored distance covered with major steering-wheel angles, the function of the system will be restricted for the return trip.

Various factors can cause the vehicle to deviate sideways when reversing along the saved distance covered. These factors include, for example:

- If the steering wheel is moved with the vehicle stationary while the distance covered is being saved.
- ▶ The speed is not adapted to the distance covered in question.
- ▶ Road characteristics, for examples gradients, inclines or slippery road surface.
- Greatly deviating conditions when storing and driving the distance covered, for example, different tyres or changed environmental factors like the weather.

Also observe the limits of the system in the chapter "Parking assistance systems".





# Driving comfort

# Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

# Suspension components

The suspension components have been optimised for the vehicle and its area of use, thus ensuring the best possible driving experience.

# Adaptive M suspension

## Principle

The adaptive M suspension is an intelligent, controllable sport suspension.

The suspension reduces body movements with a sporty driving style or on an uneven road.

#### General

The intelligent control of the suspension increases the driving dynamics and driving comfort depending on the road condition and driving style.

#### Setting

The system offers various shock absorber settings, from comfortable travel to sporty driving.

The shock absorbers are adjusted depending on the selected drive mode as well as the road condition and driving style.

For further information:

Driving Experience Control, see page 131.

## Performance Control

Performance Control increases the agility of the vehicle.

Individual wheels are braked to increase agility for a sporty driving style.

## Drive sound

Depending on the equipment and nationalmarket version, settings can be made for the drive sound.

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Drivetrain and chassis"
- 5. "IconicSounds"
- 6. Select the desired setting.



# Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

# Air conditioning control

#### Overview

# Functions in the air conditioning menu

lcon	Function
AUTO	Automatic programme.
22.0°C	Temperature.
A/C	Air conditioning function.
MAX A/C	Maximum cooling.
<b>€</b>	Air recirculation function.
⊋ <sub>C</sub> A A	Automatic air recirculation control.
<b>ॅ</b>	Fresh air.

1	E value
lcon	Function
S	Amount of air.
نم	Air distribution.
SYNC	SYNC programme.
( <del>411)</del>	Seat heating.

The functions can also be operated via voice, for example, Temperature.

# Buttons, integrated automatic heating/air conditioning system



Icon	Function
MAX	Defrost function.
REAR (;;;)	Rear window heating.



### Buttons, automatic rear airconditioning system



lcon	Function
AUTO	Automatic programme.
▼ ▲	Temperature.
₹,	Air distribution.
(¥#),	Seat heating.
OFF	To switch off.

### Display in the control display



- 1 Toolbar
- **2** Air conditioning functions, driver's side
- **3** Air conditioning functions

- **4** Air conditioning functions, passenger's side
- **5** Air conditioning bar

## Go to air conditioning functions

Via air conditioning bar:

"CLIMATE MENU" tap in the centre of the air conditioning bar.

Or:

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Climate control"

# Turning the air conditioning system on/off

- 1. "CLIMATE MENU"
- 2. "All climate functions"
- 3. Select the desired setting.

The complete air conditioning system is turned on/off with the last settings.

When the air conditioning system is turned on, individual air conditioning functions can be turned off.

# Turning automatic rear airconditioning system on/off


#### Operating requirements

- Automatic air conditioning is turned on.
- Defrost function is deactivated.

#### Turning automatic rear airconditioning system on/off

#### Via iDrive

- 1. "CLIMATE MENU"
- 2. "Settings"
- 3. "Rear climate control"
- 4. "Rear climate control" activation/deactivation



"Activate with default settings"

#### Switching on using the button

Press one of the following buttons:

- ▶ Temperature.
- Automatic programme.
- ▶ Air distribution, manual.

#### Switching off using the button

OFF

Press the key.

# Locking the rear air-conditioning operating elements

- 1. "CLIMATE MENU"
- 2. "Settings"
- 3. "Rear climate control"
- 4. "Lock rear climate control"

# Automatic programme

### Principle

The automatic programme ensures a comfortable climate, which can be modified with the set temperature and individual settings.

The automatic programme cools, ventilates, or heats the vehicle interior automatically.

#### General

Depending on vehicle equipment, the automatic programme provides the best possible settings for air conditioning functions depending on the outside temperature, interior temperature, sunlight, seat occupancy, and the desired temperature setting:

- Amount of air.
- Air distribution.
- > Temperature.
- Seat heating.

The automatic programme takes the seat occupancy into account to ensure energy-efficient control adapting to the vehicle passengers.

At the same time, a condensation sensor controls the automatic programme in such a way that condensation is avoided as far as possible.

# Switching the automatic programme on/off

- "CLIMATE MENU"
- 2. "Automatic programme"
- 3. Select the desired setting.

### Switching the automatic rear airconditioning system programme on/off

## Using the button

AUTO

Press the key.

The button LED lights up when the automatic programme is switched on.

### Setting the intensity

When the automatic programme is enabled, the intensity of individual air conditioning functions can be individually adjusted.

Each air conditioning function has multiple levels that can be adjusted individually, e.g.:

- ▶ "LOW"
- ▶ "MFDIUM"
- ▶ "HIGH"

Each level has a specific control range of the intensity.





Based on the stored data models, the intensities are dynamically adjusted during the journey. It is not necessary to manually change the desired intensity to lower or higher levels while driving.

#### Functional example

When the automatic programme is turned on. the intensity of seat heating can be adjusted:

- 1. "CLIMATE MENU" tap in the centre of the air conditioning bar.
- 2. Seat heating.
- 3. Select the desired settings, for example, "HIGH"

The individually selected settings of the air conditioning functions are stored and automatically set up again, for example, after the vehicle is started again.

### Display

The indicator in the climate control bar informs of the temperature differential between configured desired temperature and current interior temperature:

- ▶ The red or blue bar next to the temperature display indicates the progress of heating up or cooling.
- ▶ The desired interior temperature is reached as soon as the bar is no longer displayed.

Active air conditioning functions, for example, seat heating are displayed as icons in the climate control bar.

Active air conditioning functions are highlighted in colour in the climate control menu.

# **Temperature**

# Principle

The automatic air conditioning cools or heats to the set temperature and then keeps the temperature constant.

#### General

Avoid switching between different temperature settings in rapid succession. The automatic air conditioning may not have sufficient time to adjust to the set temperature.

### Adjusting the temperature



The temperature can be set individually for driver and front passenger in the air conditioning bar.

Set the desired temperature:

- ► Increase the temperature.
- Reduce the temperature.

## Setting the temperature adjustment

When the automatic programme is switched on, the speed of the heating and cooling process can be adjusted as follows:

▶ "BALANCED".

The setting enables a smooth, low-noise adjustment of the interior temperature.

"DYNAMIC".

The setting enables a quick adjustment of the interior temperature with a high amount of air.

## Setting the automatic rear airconditioning system temperature


#### Via iDrive

- "CLIMATE MENU"
- 2. "Settinas"
- 3. "Rear climate control"
- 4. Set the desired temperature.

### Using the button



Press the left or right side of the button  $\blacksquare$  to set the desired temperature.



#### General

The air temperature in the upper body area can be adjusted.

The set interior temperature for driver and front passenger is not changed by this.

#### Adjusting the upper body temperature

- 1. "CLIMATE MENU"
- 2. "Settings"
- 3. "Temp. adjustment upper body"
- 4. Increase or decrease the temperature.

# Air conditioning function

### Principle

The air in the interior is cooled and dried and then heated again depending on the temperature setting.

# Operating requirements

Standby state or drive-ready state is switched on.

# Switching the cooling function on/off

- "CLIMATE MENU"
- 2. "A/C"
- 3. Select the desired setting.

Depending on the weather conditions, the windscreen and the side windows may mist over for a short time after switching on driveready state.

Cooling produces condensation, which then exits underneath the vehicle.

# Maximum cooling

#### Principle

The function enables quick and intense cooling of the interior.

#### General

The system is set to the lowest temperature, maximum amount of air and air recirculation function.

Automatic rear air-conditioning system:

The function is automatically activated in the rear when the SYNC programme is turned on.

### Operating requirements

The function is available at an outside temperature above approximately 0 °C, 32 °F and when drive-ready state is switched on.

## Turning maximum cooling on/off

- 1. "CLIMATE MENU"
- "MAX A/C"
- 3. Select the desired setting.

The air flows from the air vents for the upper body area. Open the vents.

# Air recirculation function

# Principle

If the air outside the vehicle has an unpleasant odour or contains pollutants, the supply of outside air into the interior of the vehicle can be shut off. The interior air is then recirculated.

#### General

If there is condensation, switch off the air recirculation function.

When the air recirculation function is turned off, outside air is directed into the interior.





In the automatic recirculated-air control, outside air is drawn in or the interior air is circulated, depending on the outside air quality.

The interior filter cleans the incoming outside air or the circulated inside air in air recirculation mode.

# Turning the air recirculation function on/off

- 1. "CLIMATE MENU"
- The current operating mode is displayed in the toolbar. Select the desired setting in the toolbar:
  - "Air recirculation"
  - "Fresh air"
  - "Auto air recirculation"

Depending on the equipment, the air recirculation function will turn off automatically after some time depending on the environmental factors to prevent condensation.

### Amount of air

#### General

The blower-generated air flow can be adjusted individually as needed.

# Adjusting the amount of air

- 1. "CLIMATE MENU"
- 2. & Amount of air.
- 3. Select the desired setting.

The amount of air may be reduced in order to save the vehicle battery power.

# Adjusting the amount of air of the automatic rear air-conditioning system



Press top or bottom side of button repeatedly: reduce or increase amount of air.

The selected amount of air is shown on the climate display.

#### Air distribution

#### General

In manual mode, the air distribution can be adjusted as required.

### Adjusting the air distribution

- 1. "CLIMATE MENU"
- 2. Air distribution.
- 3. Select the desired setting.

The selected air distribution is displayed.

# Adjusting the air distribution, automatic rear air-conditioning system



Press the button repeatedly. Select the desired setting.

The selected air distribution setting is shown on the climate display.

# SYNC programme

# Principle

If the SYNC programme is activated, it can be used to transfer settings on the driver's side to the passenger's side and to the rear.

#### General

The following settings can be transferred:

- ▶ Temperature.
- ▶ Air distribution.
- Automatic programme.



- 1. "CLIMATE MENU"
- 2. "SYNC"
- 3. Select the desired setting.

The programme is switched off automatically if settings are changed on the passenger's side or in the rear passenger compartment.

### Defrost function

### Principle

With the defrost function, ice and condensation are quickly removed from the windscreen and the front side windows.

#### General

The amount of air and air temperature are automatically optimised for the removal of ice and condensation.

The air distribution is directed toward the windscreen and the front side windows.

If there is condensation, turn on the automatic programme to utilise the advantages of the condensation sensor. Ensure that air can flow towards the windscreen.

When the defrost function is switched on, the automatic rear air-conditioning system is deactivated to provide maximum power.

#### Turning the defrost function on/off



Press the key.

The LED in the button is illuminated when the system is switched on.

# Rear window heating

#### Principle

With the rear window heating, ice and condensation are quickly removed from the rear window.

### Operating requirements

Standby state or drive-ready state is switched on.

# Turning the rear window heating on/off



Press the key.

The LED is illuminated when the rear window heating is switched on.

The rear window heating switches off automatically after a while.

# Seat heating

#### General

If a drive is resumed within about 15 minutes after a temporary stop, the functions are automatically switched on at the last temperature setting.

For further information:

Automatic programme, see page 239.





# Automatic air conditioning

#### Overview



#### Turning the seat heating on/off

- 1. "CLIMATE MENU" tap in the centre of the air conditioning bar.
- 2. M Seat heating.
- 3. Select the desired setting.

If ECO PRO is activated, the heater output is reduced.

For further information:

ECO PRO, see page 278.

# Ventilation

### Principle


The ventilation system provides individual ranges of adjustment for direct or indirect ventilation to optimise the movement of air inside the vehicle.

#### General

Open the air vents and position them in a way that ensures effective climate control.


The air flow heats or cools noticeably, depending on the set temperature.

#### Ventilation at front



- ▶ Lever for changing the air flow direction, arrows 1.
- Knurled wheel for the variable adjustment of the air flow on the vents, arrows 2.

# Ventilation in rear passenger compartment



- Lever for changing the air flow direction, arrows 1.
- ▶ Knurled wheel for steplessly opening and closing the air vents, arrow 2.

## Adjusting the ventilation

Depending on the set ventilation, align the air flow directly or indirectly toward the passengers.



#### General

The air quality in the interior is improved by the following components:

- Emissions-tested interior.
- Interior filter.
- Climate control system for regulating temperature, amount of air and air recirculation function.
- Pre-cooling.

#### Interior filter

The interior filter cleans the incoming outside air or the circulated inside air in air recirculation mode.

Depending on the equipment:

- ▶ Dust and pollen are filtered out from the inflowing outside air.
- ▶ Nano-particle emissions are reduced.
- Gaseous pollutants are filtered.
- Microbial particles, viruses, and allergens are filtered.

The vehicle manufacturer recommends having the interior filter replaced when the vehicle is serviced.

# Pre-cooling

## Principle

The pre-cooling allows the temperature of the interior to be adjusted even before the start of the journey. Depending on the set temperature and ambient temperature, the interior is ventilated or heated using any available residual heat from the engine.

#### General

The system can be switched on and off directly or for a preselected departure time.

The switch-on time is calculated based on the outside temperature. The system will switch on in good time before the preselected departure time.

The system switches off automatically after a while. It continues to run for a short time after it has been switched off.

### Operating requirements

- ▶ The vehicle is in rest state or standby state.
- ➤ The vehicle battery must be sufficiently charged.

When activated, the pre-cooling uses power from the vehicle battery. As a result, the maximum operating time is restricted to protect the vehicle battery. After the engine is started or after driving a short distance, the system will be available again.

- ▶ Time and date are set correctly.
- ▶ The air vents of the ventilation are open.

#### Turning the pre-cooling on/off

# Turning on/turning off via iDrive

- 1. "CLIMATE MENU"
- 2. "Settings"
- 3. "Auxiliary ventilation"
- 4. Select the desired setting.

# Departure time

#### General

To ensure a pleasant interior temperature in the vehicle at the start of the journey, it is possible to set different departure times.

- One-off departure time: the time can be set.
   The system is activated once.
- Departure time with day of the week: the time and day of the week can be set.

The system is switched on before the set departure time on the required days of the week.





Preselection of departure time is done in two stages:

- > Set the departure times.
- Activate the departure time.

At least 10 minutes should pass between setting/activating the departure time and the scheduled departure time, so the climate control has enough time to work.

#### Setting the departure time

- 1. "CLIMATE MENU"
- 2. "Settings"
- 3. "Auxiliary ventilation"
- 4. "Departure plan"
- 5. Select the required departure time.
- 6. Set the desired departure time.
- 7. Select the day of the week if necessary.

#### Activating the departure time

To turn on the pre-cooling prior to a departure time, the respective departure time must be activated beforehand.

- "CLIMATE MENU"
- 2. "Settings"
- "Auxiliary ventilation"
- 4. "Departure plan"
- 5. Activate the required departure time.

### Display

lcon	Description
샹	lcon in the upper centre console.
	Icon is illuminated: a departure time is activated.
	Icon flashes: the pre-cooling is turned on.

### Activating with BMW App

Depending on the equipment, an appropriate BMW app with remote function can be used to turn on the pre-cooling via a preselected departure time or directly.

# Pre-conditioning via Remote **Engine Start**

### Principle

Pre-conditioning cools or warms the interior to a comfortable temperature before the start of a journey. The system does this by automatically cooling, ventilating or heating depending on the internal, external and set desired temperature. Any snow and ice can be removed more easily.

The system starts the engine automatically for this purpose and lets it run for a limited time.

### Safety information



#### A DANGER

A blocked exhaust pipe or inadequate ventilation can allow harmful exhaust fumes to pollute the area around the vehicle or enter it. The exhaust fumes contain pollutants which are colourless and odourless. In enclosed spaces or spaces with inadequate ventilation, the exhaust fumes can also build up outside the vehicle. There is a danger to life. Keep the exhaust pipe clear and ensure sufficient ventilation. Do not switch on the pre-conditioning in enclosed or poorly ventilated spaces, for example closed garages.



#### ↑ WARNING

When the pre-conditioning is operating, high temperatures can be generated under the body, for example because of the exhaust system. If flammable materials come into

contact with hot parts of the exhaust system, these materials may ignite. There is a risk of fire. Make sure that no flammable materials, for example leaves, grass, gas, petrol, oil or other flammable objects, can come into contact with vehicle parts when the pre-conditioning is operating.

## Operating requirements

- ▶ Vehicle is in rest state or standby state and not in drive-ready state.
- ▶ Battery must be sufficiently charged.
- ▶ Fuel tank capacity is sufficient.
- Bonnet is closed.
- ▶ Ensure that the date and time are set correctly in the vehicle.
- ▶ Ventilation air vents are open.

# Enabling automatic engine start

The automatic engine start must be enabled before using the system. This enables the engine to switch on automatically in order to control the interior climate.

#### Via iDrive:

- 1. "CLIMATE MENU"
- 2. "Settings"
- 3. "Pre-conditioning"
- 4. "Remote Engine Start"
- 5. "Start engine for climate cont."
- 6. Confirm the disclaimer.

# Turning on/turning off the preconditioning

#### General

For safety reasons, the system switches off automatically after 15 minutes at the latest.

The system can be switched on a maximum of twice in succession.

The system will be available again once the drive-ready state has been activated and deactivated again.

### Switching on via iDrive

- "CLIMATE MENU"
- 2. "Settings"
- 3. "Pre-conditioning"
- 4. "Start now"

### Switching on/off using the vehicle key

The system can be switched on and off using the vehicle key.



Press the vehicle key button three times within 1 second.

After the vehicle key is pressed, it will take around 3 seconds for the engine to switch on.

To switch the system off, press the button again three times.

# Switching off using the Start/Stop button

The system can be switched off directly: press the Start/Stop button without depressing the brake pedal.

#### Air conditioning for departure time

#### General

To ensure a pleasant interior temperature in the vehicle at the start of the journey, it is possible to set scheduled departure times in the system.

- ▶ One-off departure time: the scheduled departure time can be set.
  - The system is switched on as a one-off.
- Departure time with day of the week: the scheduled departure time and day of the week can be set.





Preselection of departure time is done in two stages:

- Set the departure times.
- Activate the departure time.

The system is automatically activated a few minutes before the set departure time. The system remains switched on until just after the set departure time.

For safety reasons, climate control for departure time is only possible once.

The system will be available again once the drive-ready state has been activated and deactivated again.

Observe the information regarding the intended use of the vehicle.

For further information:

Your own safety, see page 9.

#### Setting the departure time

- "CLIMATE MENU"
- 2. "Settings"
- 3. "Pre-conditioning"
- 4. "Departure plan"
- 5. Set the departure time.
- 6. Select the day of the week if necessary.

### Activating the departure time

- "CLIMATE MENU"
- 2. "Settings"
- 3. "Pre-conditioning"
- 4. "Departure plan"
- 5. Activate the required departure time.

## Display



In the instrument cluster:

The engine runs for the purpose of operating the pre-conditioning. The vehicle is not ready to drive.

Icon	Description
<u>ttt</u>	lcon in the upper centre console.
	Icon is illuminated: heating mode is turned on.
&	lcon in the upper centre console.
	lcon is illuminated: a de- parture time is activated.
	Icon flashes: the pre-conditioning is turned on.

### Vehicle acknowledgement signals

The system switch-on is acknowledged by two flashes.

The side lights remain switched on while the system is switched on.

# Interior equipment

# Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

## Sun visor

#### Glare protection

Fold the sun visor downwards or upwards.

### Protection from glare at the side

#### Folding the sun visor out

- 1. Fold down the sun visor.
- 2. Detach the sun visor from its holder and pivot it sideways to the side window.

### Folding the sun visor in

To close the sun visor, proceed in reverse order.

# Vanity mirror

A vanity mirror is located behind a cover in the sun visor.

## Sockets

### Principle

The socket can be used for electronic devices when the standby or drive-ready state is switched on.

#### General

The total load of all sockets must not exceed 140 watts at 12 V.

Do not damage the socket by using unsuitable connectors.

#### Safety information

#### MARNING

Devices and cables, for example portable navigation devices, that are located in the deployment range of the airbags may impede airbag deployment or be thrown around the vehicle interior when the airbag is deployed. There is a danger of injury. Make sure that devices and cables are not in the deployment range of the airbags.



#### ∧ NOTICE

Battery chargers that charge the vehicle battery via sockets or cigarette lighters in the vehicle may overload or damage the 12 V electrical system. There is a risk of material damage. Only connect battery chargers for the vehicle battery to the starting aid terminals in the engine compartment.



#### ∧ NOTICE

If metallic objects fall into the socket, they can cause a short circuit. There is a risk of material damage. After using the socket, re-fit the cigarette lighter or socket cover.





#### Front centre console

1. Press the cover.



2. The socket is located between the cup holders. Pull off the cover.



# **USB** port

#### General

Please comply with the notes on connecting mobile devices to the USB port in the chapter on USB connections.

For further information:

For information on USB connections, see Owner's Handbook for Navigation, Entertainment, Communication.

#### In the centre armrest



There is a USB port in the centre armrest.

#### Properties:

- ▶ USB port type C.
- ▶ For charging mobile devices.
- ▶ Charge current: max. 3 A.

#### In the front centre console



#### ▲ NOTICE

Objects in the storage compartment, for example large USB connectors, can block or damage the cover on opening and closing. There is a risk of material damage. When opening and closing, make sure that the movement range of the cover is kept clear.



Press the cover.



There is a USB port in the centre console. Properties:

- ▶ USB port type A.
- > For charging mobile devices and transferring data.
- ▶ Charge current: maximum 1.5 A.

# Wireless charging tray

### Principle

The wireless charging tray allows wireless charging of mobile phones and other mobile devices certified according to the Qi standard.

## General

When inserting the device to be charged, make sure that there are no objects between the device to be charged and the wireless charging tray.

((4)) The charging process is indicated by the charge indicator on the control display.

### Safety information



#### ↑ WARNING

When charging a Qi-compatible device in the wireless charging tray, any metal objects located between the device and the tray can become very hot. If storage media or electronic cards, for example smart cards, cards with magnetic strips or cards for transmitting signals, are placed between the device

and the tray, their function may be impaired. There is a danger of injury or material damage. When charging mobile devices, make sure there are no objects between the device and the tray.

#### Overview

Dock in the centre console:



- LED
- 2 Dock surface

#### Operating requirements

- ▶ The device to be charged must have been certified according to the Qi standard.
- Standby state is switched on.
- ▶ The maximum size for a mobile phone is approximately 154.5 x 80 x 18 mm, 6.06 x  $3.1 \times 0.7$  in.
- Only use protective sleeves and covers up to a maximum thickness of 2 mm, 0.07 in. otherwise the charging function may be impaired.
- ▶ The mobile phone to be charged is located in the middle of the dock. The display of the mobile phone faces upwards.

### Inserting the mobile phone

- 1. Open the cover of the dock.
- 2. Place the mobile phone in the centre of the dock with the display facing upwards.
- 3. Close the cover of the dock.





## LED displays

Col- our	Meaning
Blue	The mobile phone is charging. The blue LED stays illuminated once the inserted Qi-compatible mobile phone is fully charged.
Or- ange	The mobile phone is not charging. The mobile phone may be exposed to excessively high temperature or there may be foreign bodies in the charging cradle.
Red	The mobile phone is not charging.  Contact a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

- Due to excessive temperatures of the tray and mobile phone.
- When there are objects between the mobile phone and wireless charging tray.
- By settings on the mobile phone, for example for charging. Follow the relevant instructions on the control display and in the instructions for the mobile phone, if applicable.

### Forgotten phone warning

#### General

A warning can be issued if a mobile phone with Qi certification has been left in the wireless charging tray when exiting the vehicle.

The forgotten phone warning is shown in the instrument cluster.

# Activating forgotten warning function

- "MENU"
- 2. "Vehicle apps"
- 3. "System settings"
- 4. "Wireless charging tray"
- 5. "Mobile phone reminder"

### System limits

The charging current may be reduced, and the charging process may be reduced or temporarily interrupted, in the following situations:

# Storage compartments

## Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

## Safety information

#### ↑ WARNING

Devices connected to the vehicle with a cable, e.g. mobile phones, or loose objects can be thrown around the interior while driving, e.g. in the event of an accident, or when braking or performing evasive manoeuvres. There is a danger of injury. Secure devices connected to the vehicle with a cable or loose obiects.



#### ∧ NOTICE

Anti-slip mats can damage the instrument panel. There is a risk of material damage. Do not use anti-slip mats.

## Glove compartment

## Safety information



#### MARNING

The glove compartment protrudes into the interior when it is open. Objects in the glove compartment may be thrown into the interior during the journey, for example in the event

of an accident or when braking or taking avoidance manoeuvre. There is a danger of injury. Immediately close the glove compartment after using it.

## Opening the glove compartment



Pull the handle.

The lighting in the glove compartment comes on.

## Closing the glove compartment

Shut the lid.

## Fold-down compartment

## Safety information



#### ↑ WARNING

The fold-down compartment protrudes into the interior when open. Objects in the folddown compartment may be thrown into the interior while driving, for example in the event of an accident or when braking or performing avoidance manoeuvres. There is a danger of injury. Immediately close the fold-down compartment after use.



## Opening the fold-down compartment



Pull the handle.

## Storage compartments in the doors

#### General

There are storage compartments in the doors.

## Safety information



#### ⚠ WARNING

Breakable objects, for example glass bottles or glasses, may get broken in the event of an accident or when braking or taking avoidance manoeuvre. Splinters may scatter throughout the interior. There is a danger of injury or material damage. Do not use breakable objects during a journey. Only stow breakable objects in closed storage compartments.

## Storage compartments in the centre console

## Opening the storage compartment



Press the cover.

## Closing the storage compartment

Pull back the cover by the the handle strip.

## Front centre armrest

#### General

There is a storage compartment in the centre armrest between the seats.

## Opening the centre armrest



Press the key.

### Close the centre armrest

Press the cover down until it engages.

## Cup holder front

## Safety information



#### ↑ WARNING

Unsuitable containers placed in the cup holders may damage the cup holders or be flung into the interior, for example in the event of an accident or when braking or taking avoidance manoeuvre. Spilt liquids can distract the driver from the traffic situation and lead to an accident. Hot beverages may damage the cup holders or cause scalding. There is a danger of injury or material damage. Do not force objects into the cup holder. Use lightweight, sealable and shatterproof containers. Do not transport hot drinks.

### Opening the cup holder



Press the cover.



There are two cup holders in the centre console.

## Closing the cup holder

Pull back the cover by the the handle strip.

## Cup holder rear

## Safety information



#### MARNING

Unsuitable containers placed in the cup holders may damage the cup holders or be flung into the interior, for example in the event of an accident or when braking or taking avoidance manoeuvre. Spilt liquids can distract the driver from the traffic situation and lead to an accident. Hot beverages may damage the cup holders or cause scalding. There is a danger of injury or material damage. Do not force objects into the cup holder. Use lightweight, sealable and shatterproof containers. Do not transport hot drinks.



#### ⚠ NOTICE


If the cup holder is open, the centre armrest cannot be folded back. There is a risk of material damage. Press back the covers before folding up the centre armrest.






## Opening the cup holder

1. Fold down the centre armrest.



2. To open the cup holder, press the button.



## Closing the cup holder

Press both covers back in one after the other and fold back the centre armrest.

## Coat hooks

#### General

The coat hooks are on the body pillar in the rear.

## Safety information



#### MARNING

Items of clothing on the coat hooks can impair visibility when driving. There is a risk of accident. Hang items of clothing from the coat hooks in such a way that they do not obstruct visibility when driving.

#### MARNING MARNING

Incorrect use of the coat hooks can present a danger, for example if objects are thrown around as a result of braking or avoidance manoeuvres. There is a danger of injury or material damage. Only hang lightweight objects, for example items of clothing, on the coat hooks.



## Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

## Loading

## Safety information

#### ↑ WARNING

A high total weight can make the tyres overheat, causing internal damage and a sudden tyre pressure loss. Handling characteristics may be adversely affected, for example reduced directional stability, longer stopping distance and altered steering characteristics. There is a risk of accident. Please comply with the permitted load index of the tyre, and do not exceed the permitted total weight.

### ↑ WARNING

If the permitted total weight and the permitted axle loads are exceeded, the operational safety of the vehicle is no longer guaranteed. There is a risk of accident. Do not exceed the permitted total weight and permitted axle loads.

#### ↑ WARNING

Devices connected to the vehicle with a cable, e.g. mobile phones, or loose objects can be thrown around the interior while driving, e.g. in the event of an accident, or when braking or performing evasive manoeuvres. There is a danger of injury. Secure devices connected to the vehicle with a cable or loose objects.

#### ↑ WARNING

Incorrectly stowed objects may slip or be thrown into the interior, for example in the event of an accident or when braking or taking avoidance manoeuvre. Vehicle occupants could be struck and injured. There is a danger of injury. Stow and secure objects and the load correctly.

#### ⚠ NOTICE

Liquids in the luggage compartment may cause damage. There is a risk of material damage. Ensure that no liquids leak out into the luggage compartment.

## Stowing and securing loads in the vehicle

- Wrap protective material around any sharp corners and edges on the load.
- ▶ Heavy loads: stow as far forward as possible, low down and directly behind the rear seat backrests.
- Very heavy loads: stow as far forward as possible, low down and directly behind the rear seat backrests. If there are no passen-



gers on the rear seat, insert both outer seat belts into the respective opposite buckles.

- > Fully fold down the rear seat backrests if stowing a large load.
- Do not stack loads above the upper edge of the backrests.
- > Small and lightweight load: secure with tensioning straps or, depending on the equipment, a luggage compartment net or retaining straps.
- ▶ Large and heavy loads: secure with lashing straps.

## Lashing eyes in the luggage compartment

#### General

Load-securing equipment, for example lashing straps, tensioning straps, retaining straps or luggage compartment nets, must be secured to the lashing eyes.

#### Overview



The lashing eyes are located in the luggage compartment.

## Multifunction hook

#### General

Depending on the equipment, a multifunction hook is located on the left and right side in the luggage compartment.

## Safety information



#### ↑ WARNING

Incorrect use of the multifunction hook may present a danger, for example if objects are flung around when performing braking and avoidance manoeuvres. There is a danger of injury or material damage. Only hang lightweight objects from the multifunction hooks. Only transport heavy luggage in the luggage compartment if suitably secured.

### Net

Depending on the equipment, smaller objects can be stowed in the net on the left or right side. Move the net down to transport larger objects.

## Through-loading system

## Principle

The luggage compartment can be enlarged by folding down the rear seat backrests.

## General

The rear seat backrest is split 40-20-40. The right rear seat backrest and the centre section can be folded down individually. The left rear seat backrest can be folded down together with the centre section.

The rear seat backrests can be folded down from the luggage compartment. The centre

section can be folded down separately from the rear.

## Safety information

#### ↑ WARNING

Risk of entrapment when folding down the rear seat backrest. There is a danger of injury or material damage. Before folding down, make sure that the movement range of the rear seat backrest and the head restraint is clear.

#### ↑ WARNING

If a rear seat backrest is not locked, unsecured load may be flung into the interior, for example in the event of an accident or when braking or taking avoidance manoeuvre. There is a danger of injury. Make sure that the rear seat backrest is locked after it has been folded back.

#### ↑ WARNING


If the seat is not set properly or the child seat has been installed incorrectly, the child restraint system may have restricted or no stability at all. There is a danger of injury or danger to life. Make sure that the child restraint system rests firmly against the seat backrest. Wherever possible, adapt the backrest angle of all relevant seat backrests and adjust the seats correctly. Make sure that the seats and their backrests are correctly engaged or locked. If possible and if necessary, adjust the height of the head restraints or remove them.

#### ∧ NOTICE

Vehicle parts can be damaged when folding down the rear seat backrest. There is a risk of material damage. When folding down, make sure that the movement range of the rear seat backrest, including the head restraint, is kept clear.

## Folding down rear seat backrest

### From the luggage compartment



Pull the corresponding lever in the luggage compartment to unlock the rear seat backrest.

- ▶ Left lever: to fold down the left and middle rear seat backrest.
- ▶ Right lever: to fold down the right rear seat backrest.

## Folding back the rear seat backrest

Fold back the rear seat backrest into the seat position and engage.

## 1

## Folding down the centre section



Pull the lever and fold the centre section forwards.





# Driving precautions

## Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

## Running-in instructions

#### General

Moving parts need to adjust to each other.

The following notes will help to maximise the vehicle's lifetime and efficiency.

## Safety information



#### MARNING

New parts and components can cause safety and driver assistance systems to respond with a delay. There is a risk of accident. After new parts have been installed or if the vehicle is new, drive moderately and take action promptly if necessary. Please comply with running-in procedures for the corresponding parts and components.

## Engine, transmission and differential

### Up to 2000 km, 1200 miles

Do not exceed the maximum rotational speed and vehicle speed:

- ▶ With petrol engines, 4500 rpm and 160 km/h, 100 mph.
- ▶ With diesel engine, 3500 rpm and 150 km/h, 93 mph.

Generally avoid kickdown and driving under full load.

#### From 2000 km, 1200 miles onwards

Rotational speed and vehicle speed can be gradually increased.

#### Tyres

Due to the manufacturing process, new tyres do not achieve their full road grip immediately.

Drive moderately for the first 300 km, 200 miles.

### Brake system

Brake discs and pads only achieve their full effectiveness after approximately 500 km, 300 miles. Drive moderately during this running-in period.

## After fitting new parts

Please comply with the running-in procedures again if the components previously referred to are renewed.



## General driving notes

## Closing the boot lid

#### Safety information



#### ↑ WARNING

When open, the boot lid protrudes above the vehicle, and in the event of an accident, braking or avoidance manoeuvre, it can endanger vehicle occupants and other road users, or damage the vehicle. There is also a risk of exhaust fumes entering the vehicle interior. There is a danger of injury or material damage. Do not drive with the boot lid open.

#### Driving with the boot lid open

If the vehicle still needs to be driven with the boot lid open:

- Close all the windows and the alass sunroof.
- ▶ Adjust the blower output to a high setting.
- Maintain a moderate speed.
- > Secure the boot lid, e.g. with a tensioning belt.

#### Ice on the windows



#### ⚠ NOTICE

The window lowers a little when the door handle is pulled. If there is frost, the window may freeze up and cannot then be lowered. There is a risk of material damage. Make sure that the window lowers when the door handle is pulled. Remove any snow or ice from the window. Do not open the door by force.

## Hot exhaust system



#### MARNING

High temperatures may occur under the vehicle body during driving, for example because of the exhaust system. Contact with the exhaust system may cause burns. There is a danger of injury. Do not touch the hot exhaust system, including the exhaust pipe.



#### ↑ WARNING

If flammable materials, for example leaves or grass, come into contact with hot parts of the exhaust system, these materials can catch fire. There is a risk of fire and danger of injury. Never remove the heat shields installed in this area or apply underbody protection to them. Make sure that when driving, idling or parking, no flammable materials can come into contact with hot vehicle parts.

## Exhaust gas particulate filter

#### **Principle**

The exhaust gas particulate filter traps soot particles. The soot particles are burned at high temperatures to clean the exhaust gas particulate filter as when required.

#### General

The cleaning process takes a few minutes, during which the following may occur:

- ▶ The engine may temporarily run a little roughly.
- ▶ A slightly higher rotational speed may be required to achieve the usual power output.
- ▶ Fuel consumption may increase. The increased fuel consumption is shown as the mean value in the current consumption display.

- ▶ There may be a small amount of smoke from the exhaust system, even after stopping the engine.
- ▶ Noise, for example from radiator fan operation, may be heard, even some minutes after stopping the engine.

It is normal for the radiator fan to keep running for several minutes, even after short journeys.

## Cleaning the exhaust gas particulate filter while driving

The diesel particulate filter has a self-cleaning feature. No further action is required, such as adjusting your driving style.

## Climate comfort laminated glass

The vehicle glazing offers full protection against the harmful effects of UV light on the skin. In addition, the vehicle glazing reduces heat radiation and ensures less heating of the interior.

## Radio signals



#### MARNING

Certain vehicle functions may be affected by interference from high-frequency radio signals. Such signals are output from a series of transmission systems, for example from air traffic beacons or relay stations for mobile telecommunications.

We recommend you consult your Service Partner should you experience any difficulties.

## Mobile radio in the vehicle



#### ⚠ WARNING

There is a possibility of reciprocal interference between the vehicle electronics and mobile radio devices. Radiation is generated when mobile radio devices are transmitting.

There is a danger of injury or material damage. If possible, only use mobile radio devices, for example mobile phones, inside the vehicle if they are connected directly to an external aerial or personal eSIM in order to eliminate reciprocal interference and to divert the radiation away from the vehicle interior.

## Aquaplaning

On wet or slushy roads, a water wedge can form between the tyres and the road.

This phenomenon is known as aquaplaning and can cause the tyre to lose contact partially or fully with the road surface, meaning that the vehicle can neither be steered, nor the brakes properly applied.

## Driving through water

#### General

Please comply with the following when driving through water:

- ▶ Deactivate the Automatic Start/Stop function.
- Only drive through still water.
- Only drive through water up to a max. depth of 25 cm, 9.8 in.
- Drive through water at a walking speed of no more than 5 km/h, 3 mph.

## Safety information



#### ∧ NOTICE

Driving too guickly through excessively deep water can cause water to enter the engine compartment, electrical system or transmission. There is a risk of material damage. When driving through water, do not exceed the maximum water depth and maximum speed specified above.



## Safe braking

#### General

The vehicle is equipped with an Anti-lock Braking System as standard.

Perform full braking in situations that require it.

The vehicle remains steerable. Steer as smoothly as possible to avoid any obstacles.

A pulsing of the brake pedal and hydraulic reaulating sounds indicate that the Anti-lock Braking System is functioning.

In certain braking situations, the perforated brake discs can cause functional noise. However, the functional noises have no effect on the efficiency and operational safety of the brake.

#### Objects in the movement range of the pedals



#### MARNING

Objects in the driver's footwell can restrict the pedal travel or block a pedal that has been pressed. There is a risk of accident, Ensure that items in the vehicle are stowed securely and cannot get into the driver's footwell. Only use floor mats that are suitable for the vehicle and can be securely fastened to the floor. Do not use loose floor mats, and do not place several floor mats on top of one another. Make sure that there is sufficient space for the pedals. Ensure that floor mats are securely reattached after removal, for example for cleaning.

#### Wet roads

In wet weather, road salt exposure and in heavy rain, apply the brakes lightly every few kilometres/miles.

Ensure that you do not obstruct other road users when doing so.

The heat generated by braking dries the brake discs and brake pads and protects them against corrosion.

This helps to maintain braking power so that it is available immediately when needed.

### Downhill gradient

#### General

When driving on long or steep downhill stretches, use the gear in which the least braking is required. Otherwise the brake system can overheat and the braking effect is reduced.

Engine braking effect can be additionally increased by manually shifting down, even into first gear where required.

Change gear using shift paddles or selector lever position D/L, depending on the equipment.

#### Safety information



#### MARNING

Even slight but continuous pressure on the brake pedal can cause overheating, brake wear or even brake system failure. There is a risk of accident. Avoid excessive loads on the broke.



#### MARNING

In idle or when the engine is switched off, safety-relevant functions, for example engine braking effect or steering and braking force assistance, are either restricted or not available at all. There is a risk of accident, Do not drive in idle or with the engine switched off.

#### Corrosion of the brake disc

Corrosion of the brake discs and contamination of the brake pads increase in the following circumstances:



- ▶ Low mileage.
- > Extended stationary periods when the vehicle is not used.
- Infrequent use of the brakes.
- Aggressive, acidic or alkaline cleaning agents.

During braking, corroded brake discs may cause juddering which usually cannot be eliminated.

## Condensation when vehicle is parked

When the automatic air conditioning is operating, condensation develops and exits underneath the vehicle.

## Roof rack

#### General

Roof racks are available as optional accessories.

## Safety information



#### MARNING

When driving with a roof load, for example with a roof rack, the higher centre of gravity can mean that driving safety is no longer guaranteed in critical driving situations. There is a risk of accident or material damage. Driving with roof load only with activated Dynamic Stability Control.

## Roof strip with flaps

The mounting points are located on the roof strip above the doors.



Fold the cover outwards.

## Fitting

Follow the installation instructions for the roof rack.

Make sure that there is sufficient space to raise and open the glass sunroof.

## Loading

A loaded roof rack alters the vehicle's road behaviour and steering response by shifting its centre of gravity.

Therefore when loading and driving, bear the following in mind:

- Do not exceed the permitted roof and axle load or the permitted total weight.
- Distribute the roof load evenly.
- ▶ The roof load must not be spread over too large an area.
- ▶ Place heavy items of luggage at the bot-
- Securely fasten the luggage, for example with tensioning straps.
- Do not allow objects to protrude into the swing range of the boot lid.
- Drive cautiously and avoid driving off and braking suddenly or fast cornering.



## Rear luggage rack

## Principle

The ball head of the trailer tow hitch can be used as a mount for rear luggage racks, for example bicycle carrier systems.

#### General


Rear luggage racks which the manufacturer has classified as suitable are available as optional accessories.

Bicycle carrier systems for up to three bicycles can be used.

### Fitting

Follow the installation instructions for the rear luggage rack.

## Loading



The permitted total weight of the rear luggage rack when loaded depends on how far its centre of gravity is from the ball head.

- ▶ If the centre of gravity is up to 30 cm, 11.8 in away from the ball head, the total weight of the rear luggage rack must not exceed 75 ka/165 lbs.
- ▶ If the centre of gravity is 60 cm, 23.5 in from the ball head, the total weight of the rear luggage rack must not exceed 35 kg/77 lbs.

- Stow heavy loads as close as possible to the ball head.
- > Fasten loads securely to the rear luggage rack and secure them against sliding around.

## Before a journey

Before starting the journey, check the function of the rear lights of the rear luggage rack.

The maximum output of the rear lights of the rear luggage rack must not exceed the values for trailer rear lights.

To prevent functional limitations and malfunctions affecting driver assistance systems, activate trailer operation accordingly.

For further information:

- ▶ Power consumption, see page 270.
- Operation with a trailer or rear luggage rack, see page 272.

## Driving with a rear luggage rack

Loaded rear luggage racks change the driving and steering behaviour of the vehicle by shifting the centre of gravity.

Therefore when loading and driving, bear the following in mind:

- Do not exceed the permitted axle load or the permitted total weight.
- Drive cautiously and avoid driving off and braking suddenly or fast cornerings.

## Driving on a racing track



#### ↑ WARNING

The vehicle is not designed for use in M Sport competitions or similar. There is a risk of accident. Do not use the vehicle in M Sport competitions or similar.

The higher mechanical and thermal loads involved when driving on racing tracks lead to

increased wear. This wear is not covered by the warranty.

Before and after driving on a racing track, have the vehicle checked at a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.



# Trailer operation

## Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

## General

The permitted trailer loads, axle loads, trailer nose weights and permitted total weight rating are specified in the technical data.

Consult a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop about options for increasing the loads.

The vehicle is equipped with reinforced springs on the rear axle and, depending on the vehicle type, with a more powerful cooling system.

## For Australia: note

## Towing

The Australian/New Zealand Standards AS 4177.1-2004 Caravan and light trailer towing components – trailer tow hitches and towing brackets includes the following statement which BMW Group Australia herewith adopts: FOR TRAILER TOWING ONLY. The trailer tow hitch supplied with your BMW vehicle should only be used for towing purposes, the trailer tow hitch assembly should not be used in conjunction with any towbar-mounted carrying device, such as, for example, a bicycle carrier.

As all BMW Group towbar assemblies are designed, tested and approved as a single unit,

the practice of modifying or replacing the BMW supplied towball mount assembly is not approved. Use only the genuine BMW towball mount assembly.

BMW Group Australia does not recommend or support the installation and use of a Weight Distribution Hitch or Load Levelling Device on any BMW Group vehicle. The use of such devices may affect the vehicle's warranty status.

We recommend you consult your Authorised BMW Dealer for any further advice or clarification

## Before a journey

## Trailer nose weight

The trailer nose weight should not be less than the minimum trailer nose weight of 25 kg, 55 lb. Utilise the maximum trailer nose weight as far as possible.

The weight of the trailer tow hitch and the trailer nose weight reduce the maximum load of the towing vehicle. The trailer nose weight increases the vehicle weight. Do not exceed the permitted total weight of the towing vehicle.

## Loading

Distribute the load as evenly as possible over the loading area.

Stow the load as low down as possible and as close as possible to the trailer axle. A low centre of trailer gravity makes the car/trailer combination much more stable and safe to drive.

The permitted total weight of the trailer and the permitted trailer load of the vehicle must not be exceeded. The lower value is the limit which should be adhered to.



## Tyre inflation pressure

Check the vehicle's and the trailer's tyre inflation pressures carefully.

On the vehicle, the tyre inflation pressure for higher loads applies.

For the trailer, the regulations of the manufacturer apply.

For further information:

Tyre inflation pressure information, see page 286.

### Flat tyre monitor

Initialise the flat tyre monitor after the tyre inflation pressure has been corrected or a trailer has been attached or detached.

For further information:

Flat Tyre Monitor, see page 304.

## Tyre Pressure Monitor

Reset the Tyre Pressure Monitor after the tyre inflation pressure has been corrected or a trailer has been attached or detached.

For further information:

Tyre Pressure Monitor, see page 297.

### Exterior mirrors

Two exterior mirrors which bring both rear corners of the trailer into your field of view are required by law. Mirrors of this type are available as optional accessories from a Service Partner of the manufacturer or another aualified Service Partner or a specialist workshop.

## Power consumption

#### General

Before the start of a journey, check the function of the trailer rear lights.

When towing a caravan, only operate power consumers briefly to avoid placing an excessive load on the vehicle battery.

## Not Australia/New Zealand: Trailer rear lights

The power output of the trailer's rear lights must not exceed the following values:

- ▶ Turn indicators: 42 watts per side.
- ▶ Rear lights: 50 watts per side.
- Brake lights: 84 watts total.
- ▶ Rear fog lights: 42 watts total.
- ▶ Reversing lights: 42 watts total.

## Australia/New Zealand: Trailer rear lights

- ▶ Turn indicators: 54 watts per side.
- ▶ Rear lights: 100 watts in total.
- Brake lights: 108 watts total.
- Reversing lights: 54 watts total.

## Towing a trailer

#### General

When driving with a trailer or rear luggage rack, some driver assistance systems are unavailable or only available to a limited extent. A Check Control message is shown where applicable.

In order to avoid malfunctions, activate trailer operation.

For further information:

Operation with a trailer or rear luggage rack, see page 269.

## Safety information



#### ↑ WARNING

Speeds in excess of approximately 80 km/h, 50 mph, can be enough to cause trailer snaking, depending on the type of trailer and the load being carried. There is a risk of accident or material damage.



Keep to an appropriate speed when towing a trailer. If the trailer starts to snake, brake immediately and make the necessary steering corrections as carefully as possible.



#### MARNING

The tyre inflation pressure must be adapted because of the increased axle load in trailer operation. Driving with inadequate tyre inflation pressure can damage the tyres. There is a risk of accident or material damage. Do not exceed a speed of 100 km/h / 60 mph. Increase the tyre inflation pressure of the towing vehicle by 0.2 bar. Note the maximum possible tyre inflation pressure stated on the tyre.

## Upward gradients

#### General

In the interest of safety and to avoid holding up other traffic flow, do not attempt to climb upward gradients steeper than 12 % in trailer operation.

If higher trailer loads have been subsequently approved, the limit is 8%.

### Driving off on upward gradients

The parking brake is automatically released when the accelerator pedal is operated.

To prevent the vehicle from rolling back when driving off, use the parking brake.

Shortly before driving off, pull and release the switch.

The parking brake is engaged.

2. To drive off, press the accelerator pedal with sufficient force.

## Downhill gradient

On downward gradients, a car/trailer combination tends to start snaking movement earlier.

Before the downhill gradient, shift down manually to the next-lowest gear and drive downhill slowly.

Change gear using shift paddles or selector lever position D/L, depending on the equipment.

## High loads and high outside temperature



#### ∧ NOTICE

On long journeys with high trailer loads, a high outside temperature and a low fuel tank capacity, the fuel system can overheat leading to reduced engine output. There is a risk of material damage. Refuel in good time. On long journeys with high trailer loads and a high outside temperature, make sure that the fuel tank is more than 1/4 full.

## **Trailer Stability Control**

## Principle

Trailer Stability Control assists in intercepting trailer snaking movements.

The system detects snaking movements and promptly brakes the vehicle so that the vehicle speed falls to below the critical speed range and the outfit is stabilised.

#### General

The system can also activate in extreme driving situations when the trailer socket is occupied without a trailer attached, for example when using a bicycle carrier with lighting.



## Operating requirements

The system is operational from a speed of approximately 65 km/h, 40 mph in trailer operation and with the trailer socket occupied.

### System limits

The system is unable to intervene or intervenes too late, in the following situations for example:

- ▶ If a trailer folds instantly, for example on slippery or loose road surfaces.
- ▶ If a trailer with a high centre of gravity tips over before snaking movement is detected.
- ▶ If Dynamic Stability Control is deactivated or has failed.
- ▶ If the power consumption of a trailer is too low to be detected by the system, for example due to LED rear lights.

## Operation with trailer or rear luggage rack

#### General

When driving with a trailer or load carrier, e.g. rear luggage rack, and if the trailer socket is not occupied, some driver assistance systems may only operate to a limited extent or may malfunction. To avoid malfunctions, activate the operation of the trailer or rear luggage rack manually.

If the trailer socket is occupied, a selection menu is displayed on the control display. In the selection menu, specify whether the vehicle is to be driven with a trailer or rear luggage rack.

## Safety information



#### MARNING

If incorrect settings are made on the control display, some driver assistance system functions may be restricted or faulty. There is a risk of accident. Ensure that the relevant setting is activated when operating with a trailer or rear luggage rack.

### Activating trailer operation manually

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Driver assistance"
- 5. "Trailer mode"
- 6. Select whether the vehicle is driven with a trailer or rear luggage rack.

## Not for Australia: Trailer tow hitch

## Safety information



#### MARNING

Parts of the body can become trapped when inserting the ball head. There is a danger of injury. When inserting the ball head, make sure that the movement range is kept clear.



#### ↑ WARNING


If the ball head is not locked, unstable driving conditions or accidents can result. There is a risk of accident or material damage. Before a journey with a trailer or load carrier, check that the ball head is correctly locked.



## Storage

The removable ball head is located on a lashing eye on the luggage compartment floor.

#### Ball head bracket




The bracket for the ball head is on the underside of the vehicle.

Follow the service messages.

For further information:


Care of special parts, see page 345.

#### Overview



- 1 Lock display
- 2 Lock
- **3** Handwheel

## Display on the ball head



The colour of the display on the ball head shows the locking status.

Colour	Locking status
Red	Lock open, ball head can be inserted or removed.
Green	Lock closed, ball head is fitted firmly.

## Attaching ball head

## Operating requirements

The ball head can be inserted if the following conditions are met:

- ▶ The lock is open.
- ▶ Key is inserted in the lock.
- ▶ The display on the handwheel is red.

## Opening the lock

Open the lock with the key supplied.

- 1. Fold up the lock cover.
- 2. Insert the key.
- 3. Unlock the lock in the handwheel.

The lock is unlocked if the handwheel can be pressed.

## **(i)**

## Pre-tensioning the handwheel

If the display is green, pre-tension the handwheel:


- 1. Hold ball head firmly.
- Press the handwheel, arrow 1, and turn in direction of the arrow as far as it will go, arrow 2.



3. Handwheel engages.

## Inserting ball head

1. Pull bracket cover downwards and store in the vehicle.



2. Insert the ball head from underneath into the bracket and press upwards, arrow 1.



3. Pull the ball head backwards until it engages, arrow 2.

The ball head is inserted correctly if the display on the handwheel is green.

## Locking the lock

The lock is used for theft-proofing.

- 1. Lock the lock in the handwheel.
- 2. Remove the key.

### Checking the interlock

Ensure that the ball head is properly engaged by shaking it.

If the ball head is not fitted firmly, check the following points:

- ▶ The display on the handwheel is green.
- ▶ Ball head is lying flush in the bracket.
- ▶ The lock is locked and the key is removed.



If the display on the handwheel is not green, pre-tension the handwheel.

If the ball head is not flush with the fixture, clean the fixture and the ball head.

If the lock is locked, open it.

Check with a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop if all points are met and the ball head is not firmly fitted.

### Removing ball head

- 1. Fold up the lock cover.
- 2. Insert key and unlock the lock in the handwheel.
- 3. Hold ball head firmly.
- 4. Press the handwheel, arrow 1, and turn in direction of arrow as far as it will go, arrow 2.



- 5. Pull the ball head out of the bracket.
- 6. Release the handwheel.
- 7. Insert cover in bracket.

Remove the ball head when driving without a trailer or load carrier.

#### Trailer socket

#### General

The socket is underneath the bumper next to the bracket for the ball head.

## Safety information

#### ↑ WARNING

The socket for the trailer or rear luggage rack can heat up due to exhaust gases. There is a danger of injury. Allow the trailer socket to cool before swivelling out.

#### ↑ WARNING

The socket for the trailer or rear luggage rack is located near to protruding parts of the vehicle body. There is a danger of injury. Do not touch any parts of the body when swivelling the trailer socket in and out.


## Swivelling in and out



- 1. Grip the socket at the side.
- 2. Swivel the socket out or in up to the end position.



## Eye for securing cable



There is an eye on the trailer tow hitch mount for attaching the trailer securing cable.

For increased safety when towing a trailer, attach the trailer securing cable to the eye.

Check that the securing cable can move freely

and is not dragging on the ground.

# Operating rear luggage racks

Depending on the equipment, the ball head of the trailer tow hitch can be used as a mount for rear luggage racks, for example bicycle carrier systems.

Note the information on rear luggage racks when operating the rear luggage rack.

For further information:

Rear luggage rack, see page 267.



# Saving fuel

## Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

## Reducing fuel consumption

#### General

The vehicle has a wide range of technologies for reducing consumption and emissions.

Fuel consumption depends on various factors.

A number of measures, such as a moderate driving style and regular maintenance, can influence fuel consumption and reduce the burden on the environment.

### Remove unnecessary loads

Extra weight increases fuel consumption.

## Remove mounted parts after use

Remove auxiliary mirrors, roof racks or rear carriers after use if they are no longer required.

Parts mounted on the vehicle can adversely affect its aerodynamics and increase fuel consumption.

## Closing windows and glass sunroof

An open glass sunroof or open window increases drag and consequently fuel consumption.

#### Tyres

#### General

Tyres can have different effects on the consumption values, for example, consumption can be influenced by the tyre size.

### Check tyre inflation pressure regularly

Check and, if necessary, correct the tyre inflation pressure at least twice a month and before setting off on a longer journey.

Insufficient tyre inflation pressure increases rolling resistance and consequently fuel consumption and tyre wear.

For further information:

Tyre inflation pressure information, see page 286.

## Drive off immediately

Do not warm up the engine with the vehicle at a standstill, but instead set off straight away, driving at moderate rotational speed.

This brings the cold engine up to operating temperature as quickly as possible.

#### Think ahead

Anticipating the road situation and adopting a smooth driving style will reduce fuel consumption.

Avoid accelerating and braking unnecessarily.

To do so, keep an appropriate distance from the vehicle ahead.

## Avoid high rotational speeds

Driving at low rotational speed reduces fuel consumption and wear.

Pay attention to the optimum shift indicator in the vehicle, if fitted.



## Make use of coasting overrun mode

When approaching a red traffic light, take your foot off the accelerator and allow the vehicle to roll to a stop.

On downward stretches, take your foot off the accelerator and allow the vehicle to roll.

The fuel supply is interrupted in coasting overrun mode.

# Switch off the engine if stopping for longer periods

#### Stopping the engine

Switch off the engine if stopping the vehicle for a longer period of time, for example at traffic lights, railway crossings or in traffic jams.

### **Automatic Start/Stop function**

The Automatic Start/Stop function of the vehicle shuts off the engine automatically when stationary.

Switching the engine off and on again reduces fuel consumption and emissions compared with a permanently running engine. Savings can be made just by shutting down the engine for a few seconds.

Fuel consumption also depends on other factors, such as driving style, road condition, maintenance or environmental factors, for example.

# Switch off functions which are not currently required

Functions such as seat heating or rear window heating require a great deal of energy and increase fuel consumption, especially when driving around town and in stop-and-go traffic.

Switch these functions off if they are not required.

The ECO PRO drive mode supports energysaving use of comfort functions. These functions are automatically deactivated wholly or partially.

#### Have maintenance work carried out

For optimum economy and service life, have the vehicle serviced regularly. BMW recommends having maintenance work carried out by a BMW Service Partner.

Please also comply with the BMW Maintenance System.

## FCO PRO

## Principle

ECO PRO supports an efficient driving style. To achieve this, the engine control and comfort functions, for example the air conditioning output, are adapted.

The engine is disconnected from the transmission in selector lever position D when certain conditions are met. The vehicle rolls in idle to optimise consumption. Selector lever position D remains engaged.

In addition, situational notes, ECO PRO tips, can be displayed which help you to drive with optimum efficiency.

The extended range that is achieved by adopting these tips is shown in the instrument cluster as a bonus range.

#### General

The system comprises the following EfficientDynamics functions and EfficientDynamics displays:

- ▶ ECO PRO seat climate control.
- ▶ ECO PRO air conditioning.
- ▶ ECO PRO view.
- ▶ Route-ahead Assistant.
- Driving style analysis.



#### Overview

#### Button in the vehicle



ECO PRO

## Selecting the drive mode

ECO PRO

Press the key. ECO PRO is displayed in the instrument cluster.

## Configuring ECO PRO INDIVIDUAL

#### Via iDrive

- 1. "MFNU"
- 2. "Vehicle apps"
- 3. "Driving settings"
- 4. "Drivetrain and chassis"
- 5. "ECO PRO INDIVIDUAL"
- 6. Select the desired setting.

# Activating/deactivating ECO PRO functions

The following ECO PRO functions can be activated/deactivated:

- ▶ ECO PRO seat heating.
- ▶ ECO PRO air conditioning.
- ▶ ECO PRO light.

#### ECO PRO seat climate control

The output of the seat heating is reduced when ECO PRO is activated.

## ECO PRO air conditioning

The air conditioning is adjusted for efficient consumption.

To achieve this, the set temperature is adjusted slightly and the interior is heated or cooled more slowly to reduce consumption.

### ECO PRO light

The power output of the exterior mirror heating and the rear window heating is reduced.

Depending on the equipment, the dynamic ECO lighting function is activated additionally.

### Resetting settings



Press the button.

- 2. "Settings"
- 3. "Reset to ECO PRO STANDARD"

## Using ECO PRO efficiently

## Optimising driving style

### Power display

When activating the ECO PRO drive mode, the display changes to a special display.



When driving efficiently, the power display is coloured blue.

The display will change to grey if the driving style is inefficient.



For efficient driving style, activate adaptive recuperation

## Display inefficient driving style



When driving above the efficient range, an arrow will be displayed.

For example, the display occurs in the following situations:

- Excessive acceleration.
- Excessive speed.
- Special route section, for example roundabout, ahead.

In addition, a deceleration notification is displayed.

#### Route-ahead Assistant

#### Principle

The display informs the driver about decelerations ahead, for example, speed limit reductions or roundabouts, even when they are not yet visible. The situation-specific information and distance to the route section ahead is shown above the current speed limit in the instrument cluster. If there is a notice, the speed can be reduced in an energy-saving way by coasting using the corresponding accelerator pedal position until the section of road is reached.

### Display in the instrument cluster



A note regarding a section of the route ahead is given as a recommendation to allow the vehicle to roll.

An icon, for example a turn, indicates the detected section of the route:

# Icon Section of the road in front



Turning.



Speed limit or town entrance.



Roundabout.



Departure.



Corner.

### System limits

For example, the display of the upcoming route sections is not available in the following situations:

- ▶ With temporary and variable speed limits, for example, at road works.
- ▶ In the case of navigation data that is invalid, outdated or not available.
- ▶ If there are country-dependent restrictions on map-based route sections.



## Driving style analysis

## Principle

The function helps you to develop a particularly efficient driving style and to save fuel.

It does this by analysing your driving style. The evaluation is performed in various categories and is shown on the control display.

Using this display, the individual driving style can be adjusted to save fuel.

#### General

Adapting the driving style can increase the range of the vehicle.

The current trip is analysed.

This gain in range is shown as a bonus range on the instrument cluster and control display.

## Operating requirements

The function is available in ECO PRO drive mode.

## Go to efficiency evaluation

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Live Vehicle"

For further information:

Live Vehicle, see page 141

## Display on the control display

The display of the efficiency analysis shows the efficiency of the driving style.

The more efficient the driving style, the larger the area that is displayed in colour and the faster the bonus range increases.

In contrast, a reduced area will be displayed with an inefficient driving style.

## Adaptive recuperation

## Principle

Adaptive recuperation supports an anticipatory and comfort-oriented driving style.

Map data and various sensors analyse the current driving situation, for example the distance to the vehicle in front.

#### General

Adaptive recuperation is available depending on vehicle equipment and national-market version.

Based on the situation, the system decides whether energy is recovered through recuperation, or how the vehicle rolls.

In vehicles with mild hybrid technology, the power of recuperation is adaptive, which causes the vehicle to decelerate at different rates while coasting.

## Operating requirements

The system is active under the following conditions:

- Brake not pressed.
- Accelerator pedal not activated.
- > HYBRID ECO PRO drive mode is activated.
- Dynamic Stability Control DSC is activated.

# Activating/deactivating adaptive recuperation

Adaptive recuperation is deactivated in the following cases:

▶ By activating drive mode: "SPORT".



Press the hutton.

When changing to another drive mode, adaptive recuperation is activated.



## Display

### Display in the instrument cluster

Adaptive recuperation can be displayed on the instrument cluster.

For further information:

Power display, see page 150.

### Display on the control display

Adaptive recuperation can be displayed on the control display.

For further information:

Current driving condition, see page 157.

# Engine-off coasting/coasting

### Principle

The drivetrain allows efficient coasting in the D selector lever position with minimal deceleration. This drive state is called coasting. This reduces fuel consumption.

Vehicles with mild hybrid technology do not consume fuel while coasting.

### General

An anticipatory driving style helps to use the function frequently and supports the consumption-reducing effect of coasting.

Coasting is automatically adapted to the driving situation in question.

the coasting drive state is displayed in the Live Vehicle menu as efficient coasting.

For further information:

Live Vehicle, see page 141.

## Examples of driving situations

If a distance can be covered without foreseeable braking, it is advantageous to roll this distance.

The following examples of driving situations may be suitable for this:

- Rolling on straight downhill gradient with no obstacles.
- Rolling to a stop on a section of route without obstacles.

Avoid late or heavy braking.

## Operating requirements

- ▶ Selector lever position D is engaged.
- ▶ Brake is not depressed.
- Accelerator pedal is not operated.
- System detects a calm and smooth driving style.
- ▶ Engine and transmission are at operating temperature.
- The system does not detect any obstructive traffic situations or routes.

The function is available in the speed range from approx. 25 km/h, 16 mph to 160 km/h, 100 mph.

## Operation via shift paddles

### Principle

Depending on the equipment, the coasting drive state can be controlled via the shift paddles.

# Activating/deactivating coasting via shift paddles

Operate the right-hand shift paddle for longer to activate.

Operate the left-hand shift paddle to deactivate.

## System limits

- ▶ In the case of navigation data that is invalid, outdated or not available.
- ▶ If there are country-dependent restrictions on map-based route sections.



- ▶ With a temporary and variable speed limit, such as at road works.
- ▶ If Cruise Control is active.
- ▶ If the sensors are faulty, soiled or covered.
- ▶ Driving in the handling limit range or on steep uphill or downhill gradients.
- ▶ Battery charge state temporally too low or too high power requirement in the electrical system.
- ▶ Trailer operation.



# Refuelling

## Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

## Things to consider when refuelling

#### General

Before refuelling, take note of the fuel grade information.

On vehicles with diesel engine, the fuel filler neck is designed for refuelling at diesel pumps.

When topping up, hook the fuel pump nozzle fully into the filler pipe. Lifting the fuel pump nozzle while topping up will cause the following to happen:

- ▶ The supply is stopped too soon.
- Fuel vapour recovery is less effective.

The fuel tank is full when the fuel pump nozzle cuts out for the first time.

Please comply with the safety regulations displayed at filling stations.

For further information:

Fuel grade, see page 314.

## Safety information



#### ∧ NOTICE

If the range drops below 50 km, approx. 30 miles, the engine may no longer be supplied with sufficient fuel. The engine functions are no longer ensured. There is a risk of material damage. Refuel in good time.

#### ⚠ NOTICE

Fuels are poisonous and aggressive substances. Overfilling the fuel tank can damage the fuel system. If fuel comes into contact with paintwork, it can damage it. The environment is polluted. There is a risk of material damage. Avoid overfilling.

## Fuel filler cap

## Opening

1. To open the fuel filler flap, press on the rear edge, arrow. The fuel filler flap opens.



2. Turn the fuel filler cap anticlockwise.



3. Place the fuel filler cap in the holder on the fuel filler flap.



## Closing


#### MARNING

The retaining strap of the fuel filler cap may become trapped and crushed when turning the cap to close it. As a result, the cap may not be closed properly. Fuel or fuel vapours can leak out. There is a danger of injury or material damage. Make sure that the retaining strap does not get trapped and crushed when closing the cap.

- 1. Fit the fuel filler cap and turn clockwise until it is clearly heard to click into place.
- 2. Press on the fuel filler flap until it engages.

## Emergency release

In certain situations, it may be necessary to unlock the fuel filler flap manually, for example if there is an electrical fault.





## Wheels and tyres

## Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

## Tyre inflation pressure

#### General

The tyre condition and tyre inflation pressure influence the following:

- Tyre service life.
- Driving safety.
- Driving comfort.
- Fuel consumption.

## Safety information



#### MARNING

A tyre with too little or no tyre inflation pressure can heat up significantly and sustain damage. Handling characteristics, for example steering and braking, will be impaired as a result. There is a risk of accident. Check the tyre inflation pressure regularly, for example twice a month or before any long journey. and correct as necessary.

## Tyre inflation pressure information

#### On the body pillar



The tyre inflation pressure information is located on the body pillar of the driver's door.

The tyre inflation pressures apply to all tyre sizes and recommended tyre makes that have been rated by the vehicle manufacturer as suitable for the vehicle type concerned. The list can also include tyre sizes that are only suitable in combination with specific equipment.

Information about approved wheels and tyres for the vehicle can be requested from a Service Partner of the manufacturer, or another auglified Service Partner or specialist workshop.

The tyre inflation pressure appropriate for the respective load conditions should be used. For partially loaded vehicles, the specified tyre inflation pressure for a partially loaded vehicle, for example, is the optimum tyre inflation pressure.

#### For Australia/New Zealand



#### MARNING

The inflation pressures on the tyre label are applicable only for tyre types explicitly mentioned on the label. Tyre inflation pressures that may be covered by the label – by size, speed category and load rating/load index –



but not explicitly mentioned on the label may be different. Please obtain adequate inflation pressures in accordance with the tyre manufacturer's specifications from your tyre dealer.

## On the control display

The current tyre inflation pressures and the specified tyre inflation pressures for the installed tyres can be displayed on the control display.

To ensure that they are displayed correctly, the tyre sizes must be stored in the system and must have been set for the fitted tyres.

The current tyre inflation pressure value is shown on each tyre.

The specified tyre inflation pressure value is located towards the bottom of the control display.

## Checking the tyre inflation pressure

#### General

Tyres heat up while driving. The tyre inflation pressure increases with the temperature of the tyre.

Tyres have a natural, uniform tyre pressure loss.

The pressures displayed by some pressure gauges may be up to 0.1 bar too low.

## Checking using tyre inflation pressure information on the body pillar

- 1. Determine the specified tyre inflation pressures for the tyres installed on the vehicle.
- 2. Check the tyre inflation pressure in all four tyres, using a pressure gauge, for example.
- 3. Correct the tyre inflation pressure if the current tyre inflation pressure deviates from the specified tyre inflation pressure.
- 4. Check whether all valve caps are screwed onto the tyre valves.

The tyre inflation pressure information on the tyre pressure label on the body pillar only relates to cold tyres or tyres at the same temperature as the ambient temperature.

Only check the tyre inflation pressures when the tyres are cold, i.e.:

- ▶ If the vehicle has been driven a distance of no more than 2 km. 1.25 miles.
- ▶ If the vehicle has not moved again for at least 2 hours after a journey.

If equipped with an emergency tyre: check the tyre inflation pressure of the emergency wheel in the luggage compartment regularly and correct if necessary.

### Checking using the tyre inflation pressure information on the control display

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Vehicle status"
- 4. "Tyre Pressure Monitor"
- 5. Check if the current tyre inflation pressures match the specified tyre pressure value.
- 6. Correct the tyre inflation pressure if the current tyre inflation pressure deviates from the specified tyre inflation pressure.

The current tyre inflation pressure display may be restricted when the vehicle is stationary. The tyre inflation pressure is updated after a short drive.

#### After adjusting the tyre inflation pressure

If equipped with a Tyre Pressure Monitor, tyre inflation pressure corrections are applied automatically. Make sure that the tyre settings are correct. For tyres that are not listed in the tyre inflation pressure information on the control display, reset the Tyre Pressure Monitor.

If equipped with a Flat Tyre Monitor, reinitialize the Flat Tyre Monitor.



## Speed code letter

Designation	Maximum speed
Q	up to 160 km/h, 100 mph
R	up to 170 km/h, 106 mph
S	up to 180 km/h, 112 mph
Т	up to 190 km/h, 118 mph
Н	up to 210 km/h, 131 mph
F	up to 240 km/h, 150 mph
W	up to 270 km/h, 167 mph
Υ	up to 300 km/h, 186 mph
(Y)	above 300 km/h/186 mph

## Tyre tread

### Summer tyres

The tyre tread depth should not be less than 3 mm, 0.12 in, otherwise there is a high risk of aquaplaning.

### Winter tyres

The tyre tread depth should not be less than 4 mm, 0.16 in, otherwise its suitability for winter use is restricted.

### Minimum tread depth



There are wear indicators from the tyre manufacturer distributed over the tyre circumference with a height of at least 1.6 mm, approx. 0.06

in, which serve as an indicator of tyre tread wear.

The positions of the wear indicators are identified on the tyre sidewall by TWI, Tread Wear Indicator.

Irrespective of the wear indicators, observe the legal requirements on minimum tread depth.

## Tyre damages

#### General

Inspect tyres regularly for damage, the presence of foreign bodies and wear.

Vehicle behaviour that may indicate tyre damage or other faults:

- Unusual vibrations.
- Unusual tyre or running noises.
- ▶ Unusual vehicle response, such as pronounced pulling to the left or right.
- ▶ Uneven wear pattern, for example increased wear near the tyre shoulder.

Damage can be caused by situations such as the following:

- Driving over kerbs.
- Road damage.
- > Tyre inflation pressure too low.
- Overloading the vehicle.
- Incorrect tyre storage.

### Safety information



#### ↑ WARNING

If the tyres are damaged, the tyre inflation pressure may be reduced, causing you to lose control of the vehicle. There is a risk of accident. If you suspect tyre damage while you are driving, immediately reduce speed and bring the vehicle to a stop. Have the wheels and tyres checked. To do so, carefully drive to a Service Partner of the manufacturer



or another qualified Service Partner or a specialist workshop. If necessary, have the vehicle towed or transported there. Do not repair damaged tyres. Have them replaced.



#### MARNING

Tyres can become damaged by driving over obstacles, for example kerbs or damaged road surfaces, at high speed. Larger wheels have a smaller tyre cross-section. The smaller the tyre cross-section, the higher the risk of tyre damage. There is a risk of accident and material damage. If possible, drive around obstacles or drive over them slowly and carefully.

## Tyre age

#### Recommendation

Irrespective of the tyre tread depth, change tyres after 6 years at the latest.

## Date of manufacture

The date of manufacture of the tyre can be found on the tyre sidewall.

Designation	Date of manufacture
DOT 1922	19th week of 2022

# Replacement of wheels and tyres

## Fitting and balancing

Have the wheel fitted and balanced by a Service Partner of the manufacturer or another aualified Service Partner or a specialist workshop.

## Permissible wheels and tyres

#### General

The following are recommended and approved by the manufacturer of the vehicle for the approved wheels and tyres per vehicle type and special equipment:

- ▶ Wheel and tyre combinations.
- Rim designs.
- Tyre sizes.
- Tyre makes.

Information on the approved wheels and tyres for the vehicle, as well as the special equipment, can be obtained from a Service Partner of the manufacturer, another qualified Service Partner or a specialist workshop.

## Safety information



#### MARNING

Wheels and tyres that are not suitable for the vehicle can damage parts of the vehicle. For example they could come into contact with bodywork on account of their dimensional tolerances, despite having the same nominal size. There is a risk of accident. The manufacturer of the vehicle recommends using wheels and tyres that have been rated as suitable for the vehicle type concerned.



#### ↑ WARNING

Mounted steel wheels can lead to technical problems, for example wheel bolts may work loose and brake discs may be damaged. There is a risk of accident. Do not install steel wheels.



## ↑ WARNING

Incorrect wheel and tyre combinations will impair the vehicle's driving characteristics and a variety of system functions, for example the Anti-lock Braking System or Dynamic Stability Control. There is a risk of accident. To maintain good vehicle handling, always fit tyres of the same make and tread pattern to all wheels. The manufacturer of the vehicle recommends using wheels and tyres that have been rated as suitable for the vehicle type concerned. After a tyre has been damaged, refit the same wheel/tyre combination as the original.

## Recommended makes of tyre



Certain makes of tyre are recommended by the manufacturer of the vehicle for each tyre size. The tyre brands can be identified by a star on the tyre sidewall.

## New tyres

Due to the manufacturing process, new tyres do not achieve their full road grip immediately. Drive moderately for the first 300 km. 200 miles.

## Retreaded tyres

#### MARNING MARNING

Retreaded tyres may have different tyre carcasses. Their durability may be restricted due to their advanced age. There is a risk of accident. The vehicle manufacturer advises against the use of retreaded tyres.

## Winter tyres

#### General



Winter tyres are recommended if driving in winter conditions.

The winter tyres can be identified by the mountain and snowflake icon, as well as the M+S marking on the tyre sidewall.

Although tyres known as all-season tyres with M+S marking but without a mountain and snowflake icon have better winter characteristics than summer tyres, they do not normally match the performance of winter tyres.

## Maximum speed of winter tyres

If the vehicle is capable of maximum speed higher than the speed permitted for the winter tyres, a sign stating the permitted maximum speed for the tyres fitted must be displayed in the driver's field of view. The sign is available from a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.



If winter tyres are fitted, observe and do not exceed the relevant permitted maximum speed.

## Changing from run-flat tyres

When changing from run-flat tyres to standard tyres, make sure that a emergency spare wheel or a flat tyre kit is available in the vehicle. Additional information is available from a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

## Wheel change between axles



#### ↑ WARNING

Wheel change between axles on vehicles with different tyre sizes or rims on the front and rear may cause tyre damage and damage to the vehicle. There is a risk of accident. Do not swap wheels between axles on vehicles with different tyre sizes or rims on the front and rear.

Depending on the individual operating conditions, the tyre tread wears differently on the front and rear axles. To achieve even abrasion. the tyres can be swapped in pairs between the axles. Additional information is available from a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop. After changing the wheels, check the tyre inflation pressure and correct if necessary.

## Storing tyres

## Tyre inflation pressure

Do not exceed the maximum tyre inflation pressure indicated on the tyre sidewall.

### Storage

- > Store wheels and tyres in a cool, dry and dark place when not in use.
- Protect the tyres against contamination from oil, grease and solvents.
- Do not leave tyres in plastic bags.
- Remove dirt from the wheels or tyres.

# Run-flat tyres

## Principle

In the event of a complete tyre pressure loss, run-flat tyres enable you to continue driving, with certain restrictions.

## General

The wheels are fitted with tyres which are selfsupporting to a limited degree. The wheels may also have special rims.

The reinforced sidewall means that the tyre keeps the vehicle mobile to a degree, even if tyre inflation pressure has been lost.

Observe the notes on continuing driving with a flat tyre.

## Safety information



#### MARNING

A run-flat tyre with too little or no tyre inflation pressure will change the vehicle's handling characteristics, for example there may be reduced directional stability when braking, longer braking distances and different selfsteering properties. There is a risk of accident. Drive with care and do not exceed a speed of 80 km/h, 50 mph.



## ↑ WARNING

Continuing to drive with a flat tyre can cause heavy trailers to start snaking. There is a risk of accident or material damage. When driving with a trailer and a flat tyre, do not exceed the speed of 60 km/h, 35 mph. If the trailer starts to snake, brake immediately and make the necessary steering corrections as carefully as possible.

#### Label



The icon identifying run-flat tyres is a circle with the letters RSC on the tyre sidewall.

# Remedying flat tyre

## Safety measures

- > Park the vehicle on a firm surface and as far away from moving traffic as possible.
- Switch on the hazard warning lights.
- Apply the parking brake to prevent the vehicle rolling away.
- ▶ Engage the steering wheel lock with the wheels in the straight-ahead position.
- ▶ Have all vehicle occupants get out of the vehicle and guide them out of the danger area, for example behind the crash barrier.
- ▶ Where required, set up the warning triangle an appropriate distance away.

# Tyre repair kit

## Principle

With the tyre repair kit, minor tyre damage can be quickly sealed to allow the driver to continue driving.

### General

- ▶ To allow the driver to continue driving, tyre sealant is pumped into the tyres which seals the damage from the inside when it hardens.
- Please observe the notes on using the tyre repair kit which are on the compressor and the tyre sealant bottle.
- ▶ The use of the tyre repair set can be ineffective in the event of tyre damage from a size of approx. 4 mm, approx. 0.16 in.
- Contact a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop if you are unable to put the tyre back in operation.
- Foreign bodies that have penetrated the tyre should remain inside the tyre. Only remove foreign objects if they are visibly protruding from the tyre.
- ▶ Remove the speed limit sticker from the tyre sealant bottle and attach to the steering wheel.
- ▶ When checking the tyre pressure: using sealant can damage the wheel electronics. In this case, have the electronics replaced at the next opportunity.
- ▶ The compressor can be used to check the tyre inflation pressure.


## Overview

## Storage

Storage for the tyre repair set kit is provided on the left side of the luggage compartment.




## Tyre sealant bottle



- ▶ Tyre sealant bottle, arrow 1.
- ▶ Filler hose, arrow 2.

Note the use-by date on the tyre sealant bottle.

## Compressor



- 1 To unlock tyre sealant bottle
- 2 Tyre sealant bottle holder
- **3** Tyre inflation pressure indicator
- **4** Button for reducing the tyre inflation pressure
- **5** On/Off button
- **6** Compressor
- **7** Plug/cable for socket
- 8 Connecting hose

## Safety measures

- > Park the vehicle on a firm surface and as far away from moving traffic as possible.
- ▶ Switch on the hazard warning lights.

- > Apply the parking brake to prevent the vehicle rolling away.
- ▶ Engage the steering wheel lock with the wheels in the straight-ahead position.
- ▶ Have all vehicle occupants get out of the vehicle and guide them out of the danger area, for example behind the crash barrier.
- ▶ Where required, set up the warning triangle an appropriate distance away.

## Filling with tyre sealant

## Safety information

#### ⚠ DANGER

A blocked exhaust pipe or inadequate ventilation can allow harmful exhaust fumes to enter the vehicle. The exhaust fumes contain pollutants which are colourless and odourless. In enclosed spaces, exhaust fumes can also build up outside the vehicle. There is a danger to life. Keep the exhaust pipe clear and ensure sufficient ventilation.



#### ∧ NOTICE

The compressor can overheat if operated for too long. There is a risk of material damage. Do not let the compressor run for longer than 10 minutes.



### Filling

1. Shake the tyre sealant bottle.



2. Pull filler hose completely out of the cover of the tyre sealant bottle. Do not kink the hose.



3. Push the tyre sealant bottle into the holder on the compressor housing, until it audibly engages.



4. Screw the filler hose of the tyre sealant bottle onto the tyre valve of the faulty wheel.



5. With the compressor switched off, insert the plug into the socket inside the vehicle interior.



6. Switch on the compressor with standby state or drive-ready state switched on.



Let the compressor run for max. 10 minutes to fill in the tyre sealant and reach a tyre inflation pressure of 2 bar.

While the tyre is being filled with tyre sealant, the tyre pressure can briefly rise to approx. 5 bar. Do not switch off the compressor during this step.



## Checking and adjusting the tyre inflation pressure

## Checking

- 1. Switch off compressor.
- 2. Read off the tyre inflation pressure as shown on the tyre pressure indicator.

To continue the journey, a tyre inflation pressure of at least 2 bar must be reached.

## Removing and storing the tyre sealant hottle

- 1. Unscrew the filler hose of the tyre sealant bottle from the tyre valve.
- 2. Press the red unlocking device.
- 3. Remove the tyre sealant bottle from the compressor.
- 4. Pack and store the tyre sealant bottle to avoid soiling the luggage compartment.

## Minimum tyre inflation pressure is not reached

- 1. Remove the plug from the socket inside the vehicle interior.
- 2. Drive forwards and backwards by 10 m. 400 inches, to distribute the tyre sealant in the tyre.
- 3. Screw the connecting hose of the compressor directly onto the tyre valve.



4. Insert the plug into the socket inside the vehicle interior.



5. With standby or drive-ready state turned on, turn on the compressor and let it run for a maximum of 10 minutes.

If a tyre pressure of at least 2 bar is not reached, contact a Service Partner of the manufacturer, or a qualified Service Partner, or a specialist workshop.

If a tyre pressure of at least 2 bar is reached, see Minimum tyre inflation pressure is reached.

- 6. Unscrew the connecting hose of the compressor from the tyre valve.
- 7. Remove the plug from the socket inside the vehicle interior.
- 8. Stow the tyre repair kit in the vehicle.

## Minimum tyre inflation pressure is reached

- 1. Unscrew the connecting hose of the compressor from the tyre valve.
- 2. Remove the plug from the socket inside the vehicle interior.
- 3. Stow the tyre repair kit in the vehicle.
- 4. Immediately drive for approximately 10 km/5 mi to evenly distribute the tyre sealant in the tyre.

Do not exceed a speed of 80 km/h/50 mph.

If possible, do not drive slower than 20 km/h/12 mph.



## Adjusting

- 1. Stop in a suitable area.
- 2. Screw the connecting hose of the compressor directly onto the tyre valve.



3. Insert the plug into the socket inside the vehicle interior.



- 4. Correct the tyre inflation pressure to at least 2 har
  - ▶ Increase tyre pressure: with standby or drive-ready state turned on, turn on the compressor and let it run for a maximum of 10 minutes.
  - ▶ To reduce tyre inflation pressure: press the button on the compressor.
- 5. Unscrew the connecting hose of the compressor from the tyre valve.
- 6. Remove the plug from the socket inside the vehicle interior.
- 7. Stow the tyre repair kit in the vehicle.

## Resuming a journey

Do not exceed the permitted maximum speed of 80 km/h, 50 mph.

Re-initialise the flat tyre monitor or reset the Tyre Pressure Monitor.

Have the punctured tyre and the tyre sealant bottle of the tyre repair kit replaced as soon as possible.

For further information:

- ▶ Flat Tyre Monitor, see page 304.
- ▶ Tyre Pressure Monitor, see page 297.

## Snow chains

## Safety information



#### ↑ WARNING

If snow chains are fitted to unsuitable tyres, the snow chains can come into contact with parts of the vehicle. There is a risk of accident or material damage. Only fit snow chains on tyres which have been approved by the manufacturer as being suitable for snow chains.



#### MARNING MARNING

Insufficiently tensioned snow chains can damage tyres and vehicle components. There is a risk of accident or material damage. Ensure that snow chains are always adequately tensioned. Re-tension them if necessary in accordance with the snow chain manufacturer's instructions.

## Fine-link snow chains

The vehicle manufacturer recommends using fine-link snow chains. Certain fine-link snow chains have been tested, found safe for use in traffic and rated as suitable by the manufacturer of the vehicle.

Information regarding suitable snow chains is available from a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.



#### Use

Use only in pairs on the rear wheels, equipped with the tyres of the following wheel/tyre sizes:

Tyre size	Wheel size	Rim offset (IS)
225/50 R17	7.5J x 17	30
225/45 R18	7.5J x 18	25

The information on wheel size and rim offset is located on the inside of the wheel.

The list can also include wheel/tyre sizes that are only suitable for certain models.

Information about approved wheels and tyres for the vehicle can be requested from a Service Partner of the manufacturer, or another qualified Service Partner or specialist workshop.

Observe the snow chain manufacturer's instructions.

If equipped with a Tyre Pressure Monitor: do not reset the Tyre Pressure Monitor when using snow chains. Otherwise, incorrect values may be displayed.

If equipped with a Flat Tyre Monitor: do not initialise the Flat Tyre Monitor when using snow chains. Otherwise, incorrect values may be displayed.

When driving with snow chains, briefly activate Dynamic Traction Control as needed to optimise propulsion.

## Maximum speed with snow chains

When snow chains are fitted, do not exceed 50 km/h, 30 mph.

# Tyre Pressure Monitor

## Principle

The Tyre Pressure Monitor monitors the tyre pressure and issues a warning if the tyre pressure has dropped.

#### General

Sensors in the tyre valves measure the tyre inflation pressure and tyre air temperature.

Depending on the tyres detected or entered, the system displays the specified nominal pressures on the control display and compares them to the current tyre inflation pressures.

If the vehicle is fitted with tyres which are not listed in the tyre inflation pressure information on the vehicle, for example tyres with special approval, the system must be actively reset. The current tyre inflation pressures are then accepted as the nominal pressures.

When operating the system, please also comply with the information and notes in the chapter on tyre inflation pressure.

For further information:

Tyre inflation pressure, see page 286.

## Safety information



The display showing the nominal pressures does not replace the tyre inflation pressure information on the vehicle. If incorrect data has been entered into the tyre settings, the specified tyre inflation pressures will also be incorrect. As a result, reliable message of a tyre pressure loss can no longer be guaranteed. There is a danger of injury or material damage. Make sure that the tyre sizes of the fitted tyres are displayed correctly and that they match the specifications on the tyres and in the tyre inflation pressure information.

## Operating requirements

The following requirements must be met for the system, otherwise reliable message of a tyre pressure loss is not ensured:

▶ After each tyre or wheel change, the system has detected the fitted tyres, updated



the relevant information and, after a short journey, shown it on the control display.

If the system does not detect the tyres automatically, enter the specifications for the fitted tyres in the tyre settings.

- ▶ The Tyre Pressure Monitor only becomes active after driving for several minutes:
  - After tyre/wheel change.
  - > After a reset, For tyres with special approval.
  - After changing the tyre setting.
- > For tyres with special approval:
  - > After every tyre or wheel change, the system must be reset once the tyre inflation pressure is correct.
  - ▶ A reset must be carried out after the tyre inflation pressure has been adjusted to a new value.
- ▶ Wheels with wheel electronics.

## Tyre settings

#### General

If the system does not detect the tyres automatically, the specifications for the fitted tyres can be entered in the tyre settings.

The tyre sizes of the fitted tyres can be found in the tyre inflation pressure information on the vehicle or directly on the tyres.

The tyre data does not have to be re-entered if the tyre inflation pressure is being corrected.

For summer and winter tyres, the tyre data last entered for each type is saved. This means that the settings can be selected again after a tyre or wheel change.

## Adjusting the settings

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Vehicle status"
- 4. "Tyre Pressure Monitor"

- "Tyre settings"
- 6. "Tyre selection"
- 7. "Manual"
- 8. "Tyre type"
- 9. Select the tyre dimension that is mounted on the rear axle.

For tyres with special approval:

"Other tyres"

See the Performing a reset section for how to proceed.

- 10. After selecting the tyre size, select the load status of the vehicle.
- 11. "Save tyre settings"

The measurement of the current tyre inflation pressure is started. The progress of the measurement is shown.

## Status display

#### Current status

The status of the system, for example whether the system is active, can be shown on the control display.

- 1. "MENU"
- "Vehicle apps"
- 3. "Vehicle status"
- 4. "Tyre Pressure Monitor"

The current status is displayed.

## Current tyre inflation pressure

The current tyre inflation pressure is displayed for each tyre.

The current tyre inflation pressures can vary depending on vehicle operation or outside temperature.

## Current tyre air temperature

Depending on the model, the current tyre air temperatures are shown.



The current tyre air temperatures can change as a result of driving the vehicle or the outside temperature.

## Nominal pressure

The nominal pressure for the tyres on the front and rear axle is displayed.

The stated nominal pressure takes account of the temperature effects caused by driving the vehicle and the outside temperature. The appropriate nominal pressure is always displayed irrespective of the weather conditions, tyre air temperatures and length of journey.

The displayed nominal pressure may vary and differ from the value stated in the tyre inflation pressure information on the body pillar of the driver's door. The tyre inflation pressure can thus be corrected to the value of the displayed nominal pressures.

The nominal pressure is adjusted immediately if the load status is changed in the tyre settings.

## Tyre statuses

#### General

The status of the system and tyres is indicated by the wheel colour and a message on the control display.

Existing messages may not be deleted if the nominal pressure is not reached when the tyre inflation pressure is corrected.

## All wheels green

- ▶ The system is active and bases any warnings on the nominal pressures.
- ▶ In the case of tyres with special approval: the system is active and bases its warnings on the tyre inflations pressures saved at the last reset.

## One to four wheels yellow

There is a flat tyre or major tyre pressure loss in the tyres shown.

### Wheels grey

Tyre pressure losses might not be detected. Possible causes:

- Malfunction.
- ▶ The tyre inflation pressure is being measured, after confirmation of the tyre settings.
- ▶ For tyres with special approval: a system reset is being performed.

## For tyres with special approval: performing a reset

- 1. "MFNU"
- 2. "Vehicle apps"
- "Vehicle status"
- 4. "Tyre Pressure Monitor"
- 5. Make sure that the tyre settings are correct. Tyre settings, see page 298.
- 6. Switch on drive-ready state but do not drive off.
- 7. Reset the tyre inflation pressure: "Perform reset"
- 8. Drive off.

The wheels are shown grey and the following appears on the display: "Resetting tyre pressure...".

After driving for several minutes, the set tyre inflation pressures are accepted as the specified tyre inflation pressures. The reset is completed automatically during the journey.

If the reset was successful, the wheels are shown in green on the control display and the following appears: "Reset successful."

You can interrupt your journey at any time. The reset resumes automatically when you continue driving.



## Messages: for tyres without special approval

#### General

When a low tyre pressure is indicated, the Dynamic Stability Control may be turned on.

## Safety information



#### ↑ WARNING

A damaged standard tyre with too little or no tyre inflation pressure impairs driving characteristics, for example steering and braking. Tyres with run-flat capabilities allow a limited level of stability to be maintained. There is a risk of accident. Do not continue driving if the vehicle is fitted with standard tyres. Comply with the notes on run-flat tyres and continuing driving with these tyres.

## If a tyre inflation pressure check is required

#### Message

An icon with a Check Control message is shown on the control display.

#### Icon

#### Possible cause



The tyre was not inflated properly, for example insufficient air was added or there was a natural, even tyre pressure loss.

#### Measure

Check the tyre inflation pressure and adjust as necessary.

## If the tyre inflation pressure is too low

#### Message



A yellow warning light is illuminated in the instrument cluster.

In addition, an icon with a Check Control message is shown on the control display.

#### lcon Possible cause



There has been a tyre pressure loss.

#### Measure

- 1. Reduce speed. Do not exceed a speed of 130 km/h, 80 mph.
- 2. At the next opportunity, for example at a filling station, check the tyre inflation pressure in all four tyres and correct if necessarv.

## If there is a significant tyre pressure loss

### Message



A yellow warning light is illuminated in the instrument cluster.

In addition, an icon indicating which tyre is affected is shown in a Check Control message on the control display.

#### Possible cause lcon



There is a flat tyre or substantial tyre pressure loss.

#### Measure

- 1. Reduce your speed and carefully stop the vehicle. Avoid heavy braking and sudden steering manoeuvres.
- 2. Check whether the vehicle is equipped with standard tyres or run-flat tyres.
  - The icon identifying run-flat tyres is a circle with the letters RSC on the tyre sidewall.
  - Run-flat tyres, see page 291.
- 3. Follow the description of what to do when the vehicle gets a flat tyre.



What to do in the event of a flat tyre, see page 302.

## Messages: for tyres with special approval

#### General

When a low tyre pressure is indicated, the Dynamic Stability Control may be turned on.

## Safety information



#### MARNING

A damaged standard tyre with too little or no tyre inflation pressure impairs driving characteristics, for example steering and braking. Tyres with run-flat capabilities allow a limited level of stability to be maintained. There is a risk of accident. Do not continue driving if the vehicle is fitted with standard tyres. Comply with the notes on run-flat tyres and continuing driving with these tyres.

## If a tyre inflation pressure check is required

#### Message

An icon with a Check Control message is shown on the control display.

#### Possible cause lcon



The tyre was not inflated properly, for example insufficient air was added.

The system has detected a wheel change, but no reset has been performed.

The tyre inflation pressure has dropped compared to the last reset.

No reset has been performed on the system. System warning is based on the tyre inflation pressures saved during the last reset.

#### Measure

- 1. Check the tyre inflation pressure and adjust as necessary.
- Perform a system reset.

## If the tyre inflation pressure is too low

### Message



A yellow warning light is illuminated in the instrument cluster.

In addition, an icon with a Check Control message is shown on the control display.

#### Possible cause lcon



There has been a tyre pressure loss. No reset has been performed on the system. System warning is based on the tyre inflation pressures saved during the last reset.

#### Measure

- 1. Reduce speed. Do not exceed a speed of 130 km/h, 80 mph.
- 2. At the next opportunity, for example at a filling station, check the tyre inflation pres-



sure in all four tyres and correct if neces-

3. Perform a system reset.

## If there is a significant tyre pressure loss

#### Message



A yellow warning light is illuminated in the instrument cluster.

In addition, an icon indicating which tyre is affected is shown in a Check Control message on the control display.

#### Icon Possible cause



There is a flat tyre or substantial tyre pressure loss.

No reset has been performed on the system. System warning is based on the tyre inflation pressures saved during the last reset.

#### Measure

- 1. Reduce your speed and carefully stop the vehicle. Avoid heavy braking and sudden steering manoeuvres.
- 2. Check whether the vehicle is equipped with standard tyres or run-flat tyres.
  - The icon identifying run-flat tyres is a circle with the letters RSC on the tyre sidewall.
  - Run-flat tyres, see page 291.
- 3. Follow the description of what to do when the vehicle gets a flat tyre.
  - What to do in the event of a flat tyre, see page 302.

## What to do in the event of a flat tyre

## Standard tyres

1. Identify the damaged tyre.

Check the tyre inflation pressure in all four tyres, for example using the tyre inflation pressure indicator of a tyre repair kit.

For tyres with special approval: if all four tyres are inflated to the correct tyre inflation pressures, the Tyre Pressure Monitor might not have been reset. Perform a reset.

If no tyre damage can be found, contact a Service Partner of the manufacturer or another aualified Service Partner or a specialist workshop.

2. Repair the flat tyre, for example using a tyre repair kit or by changing the wheel.

The use of tyre sealant, for example a flat tyre kit, can damage the wheel electronics. Have the electronics replaced at the next opportunity.

### Run-flat tyres

#### Safety information



#### MARNING

A run-flat tyre with too little or no tyre inflation pressure will change the vehicle's handling characteristics, for example there may be reduced directional stability when brakina. longer braking distances and different selfsteering properties. There is a risk of accident. Drive with care and do not exceed a speed of 80 km/h, 50 mph.

#### ↑ WARNING

Continuing to drive with a flat tyre can cause heavy trailers to start snaking. There is a risk of accident or material damage. When driving with a trailer and a flat tyre, do not exceed the speed of 60 km/h, 35 mph. If the trailer starts to snake, brake immediately and make the necessary steering corrections as carefully as possible.



#### Maximum speed

If a tyre is damaged you can continue driving, but do not exceed a maximum speed of 80 km/h, 50 mph.

#### Continuing driving with a flat tyre

Observe the following if you continue driving with a flat tyre:

- 1. Avoid heavy braking and sudden steering manneuvres.
- 2. Do not exceed a speed of 80 km/h, 50 mph.
- 3. At the next opportunity, check the tyre inflation pressure in all four tyres.

#### Possible driving distance with a deflated tyre

The possible driving distance varies depending on the load and stresses the vehicle is subjected to, for example speed, the nature of the road surface and the outside temperature. The driving distance may be shorter but can be increased if a careful driving style is adopted.

With a moderate load and with low stress. the vehicle can be driven for up to 80 km, 50 miles.

## Driving properties with damaged tyres

Driving with damaged tyres changes the vehicle's handling characteristics and may lead to situations such as the following:

- ▶ The vehicle losing traction more quickly.
- ▶ Longer stopping distances.
- ▶ Different self-steering properties.

Adapt your driving style. Avoid abrupt steering or driving over obstacles, for example kerbs or potholes.

#### Final tyre failure

Vibration or loud noises during the journey may be an indication that the tyre has finally failed.

Reduce your speed and stop the vehicle. Parts of the tyre may detach, which might lead to an accident.

Do not continue driving, but instead contact a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

## System limits

### **Temperature**

The tyre inflation pressure depends on the temperature of the tyre.

The tyre inflation pressure increases as the tyre air temperature increases, for example while driving or when exposed to sunlight.

The tyre inflation pressure decreases when the tyre air temperature drops.

Due to the given warning thresholds, therefore, this behaviour may cause a warning to be triggered when significant temperature drops oc-

After a temperature-related warning, the nominal pressures are displayed again on the control display after driving a short distance.

## Sudden tyre pressure loss

No warning can be given by the system in the event of extreme, sudden tyre damages caused by external factors.

#### Reset not carried out

Tyres with special approval: the system will not function correctly if a reset has not been carried out, for example, a flat tyre may be reported even though the tyre pressure is correct.

### Malfunction

## Message



The yellow warning light flashes and then illuminates continuously. A Check



Control message is shown. Tyre pressure losses may not be detected.

#### Measure

- A wheel without wheel electronics is mounted: have the wheels checked if necessary.
- > Fault due to systems or devices with the same radio frequency: the system is automatically reactivated upon leaving the field of interference.
- ▶ For tyres with special approval: the system was unable to complete the reset. Perform a system reset again.
- > Tyre Pressure Monitor malfunction: have the system checked by a Service Partner of the manufacturer or another qualified Service Partner or specialist workshop.

## Flat tyre monitor

## Principle

The flat tyre monitor detects a tyre pressure loss while driving and issues a warning if the tyre pressure has dropped.

## General

The system identifies a tyre pressure loss by comparing the rotational speeds of the individual wheels during the journey.

A tyre pressure loss changes the diameter, and with it the rotational speed, of the corresponding wheel. The discrepancy is detected and reported as a flat tyre.

The system does not measure the tyre inflation pressure as such.

## Operating requirements

The following requirements must be met for the system, otherwise reliable message of a tyre pressure loss is not ensured:

- ▶ After a tyre or wheel change, an initialisation was carried out at the correct tyre inflation pressure.
- ▶ The system must be initialised after the tyre inflation pressure is adjusted to a new value.

## Status display

It is possible to display the current status of the Flat Tyre Monitor, for example to check whether the Flat Tyre Monitor is active.

- 1. "MFNU"
- 2. "Vehicle apps"
- 3. "Vehicle status"
- 4. "Flat Tyre Monitor"

The status is displayed.

## Initialisation required

An initialisation must be performed in the following situations:

- ▶ After adjusting the tyre inflation pressure.
- After tyre/wheel change.

#### Initialisation

Initialisation saves the set tyre inflation pressures as reference values for subsequent detection of a flat tyre. Initialisation is started by confirming the correct tyre inflation pressures.

Do not initialise the system if driving with snow chains fitted.

- 1. "MFNU"
- 2. "Vehicle apps"
- 3. "Vehicle status"
- 4. "Flat Tyre Monitor"
- 5. Switch on drive-ready state but do not drive
- 6. Start the initialisation: "Perform reset"
- Drive off.

Initialisation is completed while driving which can be interrupted at any time.



Initialisation resumes automatically when you continue driving.

## Messages

#### General

When a flat tyre is indicated, the Dynamic Stability Control is turned on, if needed.

## Safety information



#### MARNING

A damaged standard tyre with too little or no tyre inflation pressure impairs driving characteristics, for example steering and braking. Tyres with run-flat capabilities allow a limited level of stability to be maintained. There is a risk of accident. Do not continue driving if the vehicle is fitted with standard tyres. Comply with the notes on run-flat tyres and continuing driving with these tyres.

### Flat tyre message



A yellow warning light is illuminated in the instrument cluster.

In addition, an icon with a Check Control message is shown on the control display.

#### **Icon**

#### Possible cause



There is a flat tyre or substantial tyre pressure loss.

#### Measure

- 1. Reduce your speed and carefully stop the vehicle. Avoid heavy braking and sudden steering manoeuvres.
- 2. Check whether the vehicle is equipped with standard tyres or run-flat tyres.
  - The icon identifying run-flat tyres is a circle with the letters RSC on the tyre sidewall.

- Run-flat tyres, see page 291.
- 3. Follow the description of what to do when the vehicle gets a flat tyre.

## What to do in the event of a flat tyre

### Standard tyres

1. Identify the damaged tyre.

To do this, check the tyre inflation pressure in all four tyres, for example using the tyre inflation pressure indicator of a tyre repair

If all four tyres are inflated to the correct tyre inflation pressures, the flat tyre monitor might not have been initialised. In this case initialise the system.

If no tyre damage can be found, contact a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

2. Repair the flat tyre, for example using a tyre repair kit or by changing the wheel.

## Run-flat tyres

## Safety information



#### MARNING

A run-flat tyre with too little or no tyre inflation pressure will change the vehicle's handling characteristics, for example there may be reduced directional stability when braking, longer braking distances and different selfsteering properties. There is a risk of accident. Drive with care and do not exceed a speed of 80 km/h, 50 mph.

#### MARNING

Continuing to drive with a flat tyre can cause heavy trailers to start snaking. There is a risk of accident or material damage. When driving with a trailer and a flat tyre, do not exceed the



speed of 60 km/h, 35 mph. If the trailer starts to snake, brake immediately and make the necessary steering corrections as carefully as possible.

#### Maximum speed

If a tyre is damaged you can continue driving, but do not exceed a maximum speed of 80 km/h, 50 mph.

#### Continuing driving with a flat tyre

Observe the following if you continue driving with a flat tyre:

- 1. Avoid heavy braking and sudden steering manoeuvres.
- 2. Do not exceed a speed of 80 km/h, 50 mph.
- 3. At the next opportunity, check the tyre inflation pressure in all four tyres.

If all four tyres are inflated to the correct tyre inflation pressures, the flat tyre monitor might not have been initialised. In this case initialise the system.

### Possible driving distance with a deflated tyre

The possible driving distance varies depending on the load and stresses the vehicle is subjected to, for example speed, the nature of the road surface and the outside temperature. The driving distance may be shorter but can be increased if a careful driving style is adopted.

With a moderate load and with low stress. the vehicle can be driven for up to 80 km. 50 miles.

## Driving properties with damaged tyres

Driving with damaged tyres changes the vehicle's handling characteristics and may lead to situations such as the following:

- ▶ The vehicle losing traction more quickly.
- Longer stopping distances.
- Different self-steering properties.

Adapt your driving style. Avoid abrupt steering or driving over obstacles, for example kerbs or potholes.

#### Final tyre failure

Vibration or loud noises during the journey may be an indication that the tyre has finally failed.

Reduce your speed and stop the vehicle. Parts of the tyre may detach, which might lead to an accident.

Do not continue driving, but instead contact a Service Partner of the manufacturer or another auglified Service Partner or a specialist workshop.

## System limits

In the following situations, the system could be slow to respond or could work incorrectly:

- ▶ A natural, even tyre pressure loss in all four tyres that occurs over time will not be detected. Therefore check the tyre inflation pressure at regular intervals.
- No warning can be given in the event of extreme, sudden tyre damages caused by external factors.
- ▶ The system has not been initialised.
- ▶ When driving on snow-covered or slippery roads.
- Dynamic driving style: drive wheels slipping, high lateral acceleration.
- ▶ When driving with snow chains.

# Wheel change

### General

For run-flat tyres or when using a tyre repair kit, it is not always necessary to change a wheel immediately if tyre inflation pressure is lost due to a flat tyre.

If necessary, wheel change tools, such as the vehicle manufacturer's jack, are offered as



optional accessories by a Service Partner of the manufacturer, or another qualified Service Partner, or a specialist workshop.

## Safety information



#### MARNING

The jack is only intended for raising the vehicle briefly during a wheel change. Even if the safety measures are complied with, there is a risk of the raised vehicle falling over due to the jack slipping. There is a danger of injury or danger to life. If the vehicle is raised with the jack, do not lie underneath the vehicle and do not switch on drive-ready state.



#### MARNING

Supports such as wooden blocks under the jack can prevent it from achieving its load capacity due to the restricted height. The load capacity of the wooden blocks may be exceeded, causing the vehicle to tip over. There is a danger of injury or danger to life. Do not place supports under the jack.



#### MARNING

The jack provided by the vehicle manufacturer is intended for changing a wheel in the event of a breakdown. The jack is not designed for frequent use; for example, changing from summer to winter tyres. Using the jack frequently may cause it to become jammed or damaged. There is a danger of injury or material damage. Only use the jack to change an emergency spare wheel or a spare wheel in case of a breakdown.



#### ↑ WARNING

On soft, uneven or slippery ground, for example snow, ice, tiles or similar, the jack may slip. There is a danger of injury. Change the wheel on a level, firm and non-slip surface if at all possible.



#### MARNING

The jack is only optimised for raising the vehicle and for use with the jacking points on the vehicle. There is a danger of injury. Do not lift another vehicle or other loads with the iack.



### ⚠ WARNING

If the jack has not been guided into the jacking point provided, the vehicle might be damaged when the jack is extended, or the jack could slip. There is a danger of injury or material damage. When extending, make sure that the jack is guided into the jacking point adjacent to the wheel arch.



#### ↑ WARNING

A vehicle raised with a jack can fall from the jack if lateral forces are applied. There is a danger of injury or material damage. If the vehicle is raised, do not apply any lateral forces to the vehicle or pull the vehicle with sudden movements. If the wheel is jammed, have it removed by a Service Partner of the manufacturer or another aualified Service Partner or a specialist workshop.



#### ∧ NOTICE

Using an impact screwdriver to loosen or tighten the locking wheel bolt can damage it. There is a risk of material damage. Only use a wheel bolt wrench to loosen and tighten the locking wheel bolt.

## Securing the vehicle against rolling away

#### General

The vehicle manufacturer recommends that the vehicle should additionally be protected against rolling away during a wheel change.

### On a level surface



Place chocks or other suitable objects in front of and behind the wheel diagonally opposite to the one being changed.

## On a slight downhill gradient



If it is necessary to change a wheel on a slight downhill gradient, place chocks and other suitable objects, for example stones, under the wheels of the front and rear axles against the direction of roll.


## Locking wheel bolts

## Principle

The locking wheel bolts have a special coding. The bolts can only be released with an adapter that matches the coding.

#### Overview

The adapter of the locking wheel bolts can be found in the toolkit or in an oddments tray in the toolkit.



- ▶ Locking wheel bolt, arrow 1.
- ▶ Adapter, arrow 2.

## Unscrewing

- 1. Place the adapter on the locking wheel bolt.
- 2. Unscrew the locking wheel bolt.
- 3. After unscrewing the wheel bolt, remove the adapter again.

## Screwing in


- 1. Place the adapter on the locking wheel bolt. If necessary, turn the adapter until it fits on the locking wheel bolt.
- 2. Screw in the locking wheel bolt. The tightening torque is 140 Nm, 101 lb ft.
- 3. After screwing in the wheel bolt, remove the adapter again and stow it.



## Preparing the vehicle

- > Park the vehicle on firm and non-slip around at a safe distance from traffic.
- ▶ Switch on the hazard warning lights.
- ▶ Apply the parking brake.
- ▶ Engage a gear or select selector lever position P.
- As soon as the traffic flow permits, have all vehicle occupants get out of the vehicle and guide them out of the danger area, for example behind the crash barrier.
- Depending on the equipment, take the tools for changing wheels and, if necessary, the emergency spare wheel out of the vehicle.
- ▶ If applicable, set up warning triangle or flashing light at the correct distance.
- ▶ Additionally secure the vehicle against rolling away.
- ▶ Undo the wheel bolts by half a turn.

## Jacking points



The jacking points are located in the marked positions.

## Raising the vehicle

#### MARNING

Hands or fingers could get trapped when using the jack. There is a danger of injury. Keep your hands in the described position when using the jack, and do not change this position.

1. Hold the jack with one hand, arrow 1, and grasp the jack crank handle or lever with your other hand, arrow 2.



2. Guide the jack into the rectangular recess of the jacking point closest to the wheel to be changed.









3. Turn the jack crank handle or lever clockwise to extend the jack.



- Remove your hand from the jack as soon as the jack is under load and continue to turn the jack crank handle or lever with one hand.
- 5. Make sure that the jack base is extended vertically and at right angles underneath the jacking point.



Make sure that the jack base is vertical and at right angles below the jacking point after extension.



 Raise by cranking until the surface of the jack stands fully on the ground and the wheel in question is a maximum of 3 cm, 1.2 inches off the ground.

## Fitting a wheel

No more than one emergency spare wheel may be fitted.

- 1. Unscrew the wheel bolts.
- 2. Remove the wheel.
- 3. Put on the new wheel or emergency spare wheel and tighten at least two wheel bolts crosswise until finger-tight.
  - If installing non-original light alloy wheels not supplied by the manufacturer, the wheel bolts belonging to the wheels may also have to be used.
- Tighten the remaining wheel bolts until finger-tight and then tighten all the wheel bolts crosswise.
- 5. Turn the jack crank handle anticlockwise to retract the jack and lower the vehicle.
- 6. Remove the jack and stow it securely.

## After wheel change

- 1. Tighten the wheel bolts crosswise. The tightening torque is 140 Nm, 101 lb ft.
- Stow the faulty wheel in the luggage compartment, if necessary.
- 3. Check tyre inflation pressure at the next opportunity and correct as necessary.
- 4. Re-initialise the flat tyre monitor or reset the Tyre Pressure Monitor.
- 5. Check the tight fit of the wheel bolts using a calibrated torque wrench.
- 6. Drive to the nearest Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop to have the damaged tyre replaced.



# Engine compartment


# Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

## Overview



- Jump start, positive battery terminal
- Oil filler neck
- **3** Depending on the motorisation: coolant expansion tank for additional radiator
- 4 Engine coolant expansion tank
- 5 Vehicle identification number
- Filler neck for washer fluid
- **7** Jump start, negative battery terminal



## **Bonnet**

## Safety information

#### MARNING

Incorrectly performed work in the engine compartment can damage components and poses a safety risk. There is a risk of accident or material damage. Have work in the engine compartment undertaken by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

#### ↑ WARNING

The engine compartment contains moving components. Certain components in the engine compartment can also move when the vehicle is switched off, for example the radiator fan. There is a danger of injury. Do not reach into an area where there are moving parts. Keep articles of clothing and hair away from moving parts.

#### MARNING

The bonnet has protruding parts on the inside, for example locking hooks. There is a danger of injury. When the bonnet is open, watch out for protruding parts and keep these areas clear.

#### MARNING

If the bonnet is not correctly locked, it can come open during the journey and impair visibility. There is a risk of accident. Stop immediately and close the bonnet correctly.

#### ↑ WARNING

Parts of the body can become trapped when opening and closing the bonnet. There is a danger of injury. When opening and closing, make sure that the movement range of the bonnet is kept clear.



#### MOTICE

Windscreen wipers which are folded away from the windscreen can become trapped if the bonnet is opened. There is a risk of material damage. Before opening the bonnet, make sure that the windscreen wipers are fitted with wiper blades and are in contact with the windscreen.

#### ∧ NOTICE

When closing, the bonnet must lock into place on both sides. Applying additional pressure can damage the bonnet. There is a risk of material damage. Open the bonnet again and close it firmly. Avoid applying additional pressure.

## Opening bonnet

1. Pull the lever, arrow 1. The bonnet is unlocked.




2. Release the lever and pull it again, arrow 2.



The bonnet can be opened.

3. Watch out for any protruding parts on the bonnet.

## Closing the bonnet



Allow the bonnet to drop from a height of approximately 50 cm, approx. 20 in.

The bonnet must engage on both sides.



# Operating fluids

# Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

# Fuel grade

#### General

Depending on the region, many filling stations sell fuel that is adapted to winter or summer conditions. Fuel that is sold in winter helps with cold starting, for example.

#### Petrol


#### General

For optimal fuel consumption, the petrol should be sulphur-free or have a low sulphur content.

Fuels labelled on the pump as containing metal must not be used.

You can fill up with fuels with a maximum ethanol content of 25 %, for example E10 or F25.

The power and consumption specifications refer to operation with RON 98 E10 fuel



The engine has knock control. This means that different petrol grades can be used.

When using fuel of the minimum quality RON 91 or fuel with ethanol content of more than 10 % to a maximum of 25 %, knocking noises as well as driving and acoustic abnormalities may occur. These have no effect on the engine service life.

## Safety information



#### ∧ NOTICE

The fuel system and engine can be damaged by the wrong fuel, even in small quantities, and by the wrong fuel additives. In addition, the catalytic converter will be permanently damaged. There is a risk of material damage. For petrol engines, do not refuel with or add the following:

- Leaded petrol.
- ▶ Metallic additives, for example manganese or iron.

After filling with the wrong fuel, do not press the Start/Stop button. Contact a Service Partner of the manufacturer or another aualified Service Partner or a specialist workshop.





#### ∧ NOTICE

Fuel below the specified minimum grade can adversely affect engine function or lead to engine damage. There is a risk of material damage. Do not refuel with fuel below the specified minimum grade.

#### ⚠ NOTICE

Incorrect fuels can damage the fuel system and engine. There is a risk of material damage. Do not refuel with fuel with a higher ethanol content than recommended. Do not refuel with fuel containing methanol, for example M5 to M100.

## Petrol grade

The engine is designed to run on petrol complying with DIN EN 228.

Super, RON 95.

## Minimum grade

Unleaded petrol, RON 91.

## Diesel

#### General

The following diesel fuels can be used for refuellina:

- Diesel fuels with a maximum biodiesel content of 10 %, e.g. B7 or B10.
- ▶ Paraffinic diesel fuels, e.g. XTL.







## Safety information



#### ∧ NOTICE

The fuel system and engine can be damaged by the wrong fuel, even in small quantities, and by the wrong fuel additives. There is a risk of material damage.

Note the following with diesel engines:

- ▶ Do not fill up with petrol.
- ▷ Observe the minimum quality.
- ▶ Refuel with sulphur-free fuels or fuels with the lowest possible sulphur content.
- ▶ The vehicle manufacturer recommends only using diesel additives and additives that have been classified as suitable.

After filling with the wrong fuel, do not press the Start/Stop button. Contact a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

## Diesel quality

The engine is designed to run on diesel fuel complying with DIN EN 590 and ASTM D975.

Diesel with up to 7 % biodiesel (B7).

## Minimum grade

Diesel with up to 10 % biodiesel (B10).

Paraffinic diesel fuel as per EN 15940.

# **BMW** recommends Shell Quality Fuels





# **BMW** Diesel with BluePerformance

## Principle

BMW Diesel with BluePerformance reduces nitroaen oxides in the diesel exhaust by injecting the reducing agent AdBlue into the exhaust pipe system. In the catalytic converter, this produces a chemical reaction that reduces nitrogen oxides to a minimum.

#### General

The vehicle has a tank which requires topping up.

There must be a sufficient amount of the reducing agent present in order for drive-ready state to be activated the usual way.

The reducing agent can be topped up at any time.

The reducing agent AdBlue is a registered trademark of the Verband der Automobilindustrie e. V. (VDA).

The reducing agent is available at many service stations.

Preferably top up with reducing agent at a pump dispenser.

## Display on the control display

## Displaying filling level and top-up auantity

The filling level and the exact top-up quantity is shown on the control display.

- "MFNU"
- 2. "Vehicle apps"
- 3. "Live Vehicle"
- 4. "Content"
- 5. "Vehicle status"
- 6. "AdBlue"

If the filling level is too low, a Check Control message is displayed.

## Displays in the instrument cluster

### Fuel reserve indicator light

The fuel reserve indicator light in the instrument cluster notifies you if the reducing agent fill level in the tank is low.

Do not allow the reducing agent tank to run completely empty, as otherwise it will not be possible to switch drive-ready state back on after stopping the engine.



A yellow warning light is illuminated in the instrument cluster: filling level too low. The remaining range is shown in the instrument cluster. Top up with at least 5 litres, 1.3 gal of reducing

agent immediately.

#### AdBlue on the minimum level



The reducing agent tank is empty. Immediately top up with at least 15 litres, 4 gal of reducing agent. The engine will continue to run provided that it is not stopped and all other oper-

ating conditions are met, for example, there is sufficient fuel.

## System fault

If there is a system fault, a Check Control message is displayed.

Visit the nearest Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

## Having AdBlue topped up

BMW recommends having the reducing agent topped up by a Service Partner as part of a regular maintenance schedule.



If you keep to this maintenance schedule, a single top-up is generally required between the maintenance appointments.

As soon as the fuel reserve indicator light is shown in the instrument cluster, have the reducing agent topped up, to avoid problems activating drive-ready state.

## Topping up AdBlue yourself

## Safety information

#### MARNING

When the reducing agent container is opened, small quantities of ammonia vapours can emerge. Ammonia vapours have a pungent smell and irritate the skin, mucous membranes and eyes. There is a danger of injury. Do not inhale ammonia vapours. Do not allow reducing agent to come into contact with clothing, skin or eyes, and do not swallow it. Keep children away from reducing agents.

## MARNING

Operating fluids, for example oils, greases, coolants and fuels, can contain substances that are harmful to health. There is a danger of injury or danger to life. Please comply with the instructions on the containers. Do not allow operating fluids to come into contact with clothing, skin or eyes. Do not pour operating fluids into other bottles. Keep operating fluids out of the reach of children.

### **∧** NOTICE

The constituents of the reducing agent are highly aggressive. There is a risk of material damage. Do not allow reducing agent to come into contact with vehicle surfaces.

#### Suitable AdBlue

AdBlue complying with ISO 22241-1

At many service stations, reducing agent is available at a special pump dispenser. Preferably top up with reducing agent at a pump dispenser.

If no pump dispenser is available, reducing agent can be topped up from a container. Reducing agent is available in various containers. Preferably use the special bottle recommended by BMW. With this bottle and its special adapter, reducing agent can be topped up conveniently.

### AdBlue at low temperatures

At outside temperatures below -11 °C/+12 °F, the reducing agent should only be topped up directly before the start of a journey.

## Top-up quantity

As soon as the fuel reserve indicator light is displayed, top up at least 5 litres, approx. 1.3 gal.

## Displaying the top-up quantity

The exact to-up quantity is shown on control display.

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Live Vehicle"
- 4. "Content"
- 5. "Vehicle status"
- 6. "AdBlue"



## Reducing agent tank



The fuel filler cap for the reducing agent is located next to the fuel filler cap for the fuel tank.

# Topping up with reducing agent at the pump dispenser

#### General

When topping up, hook the fuel pump nozzle fully into the filler pipe. Lifting the fuel pump nozzle while topping up will cause the following to happen:

- ▶ The supply is stopped too soon.
- Overflow of reducing agent.

The reducing agent tank is full when the fuel pump nozzle cuts out for the first time.

Please comply with the safety regulations displayed at filling stations.

## Adding reducing agent

- Open the fuel filler flap.
   Fuel filler cap, see page 284.
- Turn the reducing agent tank cap anticlockwise and remove.



3. Place the fuel filler cap in the holder on the fuel filler flap.



Use the fuel pump nozzle to add the recommended top-up quantity as a minimum.
 The tank is full when the fuel pump nozzle cuts out for the first time.



- Put fuel filler cap back on and turn clockwise.
- 6. Press on the fuel filler flap until it engages.

## Filling with an incorrect fluid

#### General

A Check Control message is displayed if the tank has been filled with the wrong fluid.

If the wrong type of liquid has been added, contact a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

### Safety information



#### MARNING

After filling with an incorrect liquid, the system may heat up and catch fire. There is a risk of fire and danger of injury. Only fill with liquids that are intended for the tank. Do not start the engine after filling with an incorrect liquid.

## After filling with reducing agent

#### Fuel reserve indicator light



After topping up, the fuel reserve indicator light continues to be shown with the remaining range.

Drive-ready state can be activa-

ted.

After driving for a short time, the fuel reserve indicator light turns off.

#### AdBlue on the minimum level



After filling up, the display continues to be shown.

Drive-ready state can only be activated when the display is no longer illuminated.

- 1. Press the Start/Stop button three times. The display extinguishes after approximately 1 minute.
- 2. Press the Start/Stop button and switch on drive-ready state.

# Engine oil

#### General

The engine oil consumption and the properties of the engine oil depend on the driving style and operating conditions.

Therefore check the engine oil level regularly each time you fill up with fuel by taking a detailed measurement.

Engine oil consumption may increase due to the following, for example:

- Dynamic driving style.
- While running in the engine.
- Engine idling.
- ▶ Use of engine oil grades rated as unsuita-

Depending on the engine oil level and properties of the engine oil, different Check Control messages are displayed on the control display.

The manufacturer of the vehicle recommends having the engine oil changed by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

## Safety information



#### MOTICE

Too little engine oil causes engine damage. There is a risk of material damage. Top up with engine oil immediately.

#### ∧ NOTICE

Too much engine oil can damage the engine or the catalytic converter. There is a risk of material damage. Do not add too much engine oil. If there is too much engine oil, have the engine oil level corrected by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.





#### ∧ NOTICE

If the engine oil is not changed at the correct time, engine wear may increase which could cause engine damage. There is a risk of material damage. Do not exceed the service date indicated in the vehicle.

#### Electronic oil measurement

#### General

Electronic oil measurement uses two measurina procedures:

- Monitoring.
- Detailed measurement.

When frequently making short journeys or using a sporty driving style, for example fast cornering, perform a detailed measurement at regular intervals.

## Monitoring

#### Principle

The engine oil level is monitored electronically during the journey and can be shown on the control display.

If the engine oil level is outside its permissible operating range, a Check Control message is shown.

## Operating requirements

A current reading is available after approximately 30 minutes of normal driving.

## Displaying the engine oil level

- 1. "MENU"
- 2. "Vehicle apps"
- 3. "Vehicle status"
- 4. "Engine oil level"

The engine oil level is displayed.

#### System limits

When frequently making short journeys or using a sporty driving style, it may not be possible to obtain a measurement. In this case, the measurement for the last, sufficiently long journey is displayed.

#### Detailed measurement

#### Principle

The engine oil level is checked when the vehicle is stationary and is shown on a scale.

If the engine oil level is outside its permissible operating range, a Check Control message is shown.

#### General

During measurement, the idle rotational speed is increased slightly.

#### Operating requirements

- ▶ Vehicle is standing on level ground.
- Drive-ready state is switched on by pressing the Start/Stop button.
- ▶ Engine is at operating temperature.
- ▶ Selector lever in position N or P and accelerator pedal not pressed.

#### Carrying out a detailed measurement

- 1. "MFNU"
- 2. "Vehicle apps"
- 3. "Vehicle status"
- 4. "Engine oil level"
- 5. "Oil level measurement"
- 6. "Start measurement"

The engine oil level is checked and shown on a scale.



## Topping up engine oil

#### General

Do not top up engine oil unless a message is displayed in the instrument cluster. The topup quantity is specified in the message on the control display.

Only top up with suitable engine oil grades. Stop the vehicle safely and switch off driveready state before topping up with engine oil. Do not add too much engine oil.

## Safety information



#### ↑ WARNING

Operating fluids, for example oils, greases, coolants and fuels, can contain substances that are harmful to health. There is a danger of injury or danger to life. Please comply with the instructions on the containers. Do not allow operating fluids to come into contact with clothing, skin or eyes. Do not pour operating fluids into other bottles. Keep operating fluids out of the reach of children.



#### ⚠ NOTICE

Too little engine oil causes engine damage. There is a risk of material damage. Top up with engine oil immediately.



#### 

Too much engine oil can damage the engine or the catalytic converter. There is a risk of material damage. Do not add too much engine oil. If there is too much engine oil, have the engine oil level corrected by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

#### Overview

The oil filler neck is in the engine compartment. For further information:

Overview, see page 311.

## Topping up engine oil

- 1. Open the bonnet. Opening, see page 312.
- 2. Turn the cap anticlockwise to open.



- 3. Add engine oil.
- 4. Tighten cap.

## Engine oil grades for topping up

## General

Engine oil quality is a critical factor in the service life of the engine.

Only top up with the types of engine oil that are listed.

Some engine oil grades may not be available in all countries.

## Safety information



#### ▲ NOTICE

Oil additives can damage the engine. There is a risk of material damage. Do not use oil additives.



#### ∧ NOTICE

Using the wrong engine oil can result in engine malfunctions and damage. There is a risk of material damage. When selecting the engine oil, make sure that it is the correct oil specification.

## Suitable engine oil grades

Up to 1 litre, approx. 2 pints of an engine oil with the following oil specification can be topped up:

#### Petrol engine

BMW Longlife-12 FE.

BMW Longlife-17 FE+.

#### Diesel engine

BMW Longlife-12 FE.

BMW Longlife-17 FE+.

## Alternative engine oil grades

If suitable engine oils are not available, up to 1 litre, approx. 2 pints, of an engine oil with the following oil specification can be used for topping up:

## Petrol engine

ACEA C2.

ACEA C5.

## Diesel engine

ACEA C2.

ACEA C5.

## Viscosity classes

When selecting an engine oil, make sure that the engine oil belongs to one of the following viscosity classes:

## Petrol engine

SAF 0W-20.

SAF 0W-30.

## Diesel engine

SAF 0W-20.

SAF 0W-30.

Viscosity classes with a high viscosity grade can increase fuel consumption.

Further information on suitable engine oil specifications and viscosity classes can be obtained from a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

## BMW recommends Original BMW Engine Oil.

## Coolant

#### General

Coolant is a mixture of water and coolant additive.

Not all commercially available additives are suitable for the vehicle. The vehicle manufacturer recommends using coolant with the BMW LC-18 specification. Do not mix additives of different colours. Comply with the 50:50 mixing ratio of water to additive. Information regarding suitable additives is available from a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.



## Safety information

#### MARNING

If the cooling system is opened when the engine is hot, coolant can escape and cause scalding. There is a danger of injury. Only open the cooling system when the engine has cooled down.



#### ↑ WARNING

Additives are harmful to health and using the wrong additives can damage the engine. There is a danger of injury or material damage. Do not allow additives to come into contact with clothing, skin or eyes, and do not swallow them. Only use suitable additives.

## Coolant level

#### General

On factory delivery, the coolant may be overfilled in the coolant tank. The normal level of the coolant level is achieved by prolonging the operating period.

The target coolant level is indicated by means of the max, mark in the coolant filler neck of the coolant tank.

For further information:

Overview, see page 311.

## Checking the coolant level

- 1. Allow the engine to cool down.
- 2. Open the bonnet. Opening, see page 312.
- 3. Turn cap on coolant expansion tank slightly anticlockwise to allow the excess pressure to escape.
- 4. Open cap on coolant expansion tank.

5. The coolant level is correct if it is just below the max, mark in the filler neck.



6. Tighten cap.

## Topping up the coolant

- 1. Allow the engine to cool down.
- Open the bonnet. Opening, see page 312.
- 3. Turn cap on coolant expansion tank slightly anticlockwise to allow the excess pressure to escape.
- 4. Open cap on coolant expansion tank.
- 5. If required, slowly top up to the correct filling level; do not overfill.
- 6. Tighten cap.
- 7. Have the cause of coolant loss rectified as soon as possible.

## Disposal



When disposing of coolant and coolant additives, comply with the relevant environmental protection regulations.

## Washer fluid

## General

All spray nozzles are supplied from one tank. Use a mixture of tap water and screenwash concentrate for the window washer system, if necessary with the antifreeze additive.



Recommended minimum fill level: 1 litre, 1.7 Imp. pints.

## Safety information

#### ↑ WARNING

Some antifreeze additives can contain toxic substances, and are flammable. There is a risk of fire and danger of injury. Please comply with the instructions on the containers. Keep antifreeze additives away from sources of combustion. Do not pour operating fluids into other bottles. Keep operating fluids out of the reach of children.



#### ↑ WARNING

Washer fluid can ignite on contact with hot parts of the engine and catch fire. There is a danger of injury or material damage. Only top up washer fluid when the engine has cooled down. Afterwards fully close the cap of the washer fluid reservoir.

#### ∧ NOTICE

Silicone additives mixed with the washer fluid for their water beading effect on the windows may damage the car wash. There is a risk of material damage. Do not add silicone additives to the washer fluid.

#### ∧ NOTICE

Mixing different screenwash concentrates or antifreeze additives may damage the car wash. There is a risk of material damage. Do not mix different screenwash concentrates or antifreeze additives. Please comply with the instructions and mixing ratios stated on the containers.

### Overview



The reservoir for the washer fluid is located in the engine compartment.

## Malfunction

Using undiluted screenwash concentrate or antifreeze additive based on alcohol may result in false readings at low temperatures below -15 °C/+5 °F.



## Maintenance

### Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

### **BMW Maintenance System**

The maintenance system indicates what maintenance measures are required and thereby assists in maintaining the road safety and operational safety of the vehicle.

The exact work required and the maintenance intervals may vary depending on the nationalmarket version. Labour, spare parts, operating materials and wear materials are charged separately. Additional information is available from a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

### Condition Based Service

### Principle

Condition Based Service determines the maintenance requirement using sensors and special algorithms which monitor the conditions in which the vehicle is used.

The system therefore allows the scope of the maintenance work to be adapted to the individual usage profile.

### General

Information on service requirements can be shown on the control display.

For further information:

Service requirements, see page 158.

### Service data in the vehicle key

Information on maintenance requirement is continuously stored in the vehicle key. The Service Partner can read out this data and suggest a programme of maintenance for your vehicle.

It is therefore important to give the service advisor the vehicle key that was last used to drive the vehicle.

### Stationary periods

Stationary periods when the vehicle is out of use with its vehicle battery disconnected are not taken into account.

In such cases, have any time-dependent maintenance procedures, for example those concerning the brake fluid and, where applicable, the engine oil and microfilter/active carbon filter, updated by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

## Service history

### Maintenance and repairs

Have maintenance and repairs carried out by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

### **Entries**

The maintenance work carried out is entered in the maintenance records and the vehicle data. As with a Service Booklet, the entries serve as proof of regular maintenance.



When data is entered into the vehicle's electronic service history, any service-relevant data is saved both in the vehicle and in the central IT systems of BMW AG, Munich.

After a change of registered keeper, the new owner will be able to view the data entered in the electronic service history. Similarly, a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop can also view the data entered in the electronic service history.

### Objection

The registered keeper is entitled to contact a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop and request that no entries are made in the electronic service history and that no data relating to his/her time as owner is subsequently stored in the vehicle or transferred to the vehicle manufacturer. In such cases, no entries will be made in the vehicle's electronic service history.

### **Displays**

Service work which has been logged can be displayed on the control display.

For further information:

Service requirements, see page 158.

### For Australia: maintenance

No maintenance work other than normal maintenance is required to keep the emission levels of your vehicle within the design limits.

### Socket for on-board diagnosis

#### General

Devices connected to the on-board diagnostic socket trigger the alarm system after locking the vehicle.

Remove devices connected to the on-board diagnostic socket before locking the vehicle.

### Safety information



#### ∧ NOTICE

Incorrect use of the on-board diagnostic socket can cause malfunctions in the vehicle. There is a risk of material damage. Service and maintenance work involving the onboard diganostic socket must be carried out by a Service Partner of the manufacturer, or another qualified Service Partner, or a specialist workshop, or other authorised persons. Only connect devices that have been tested and found to be safe for use with the socket for on-board diagnosis.

### Position



There is an on-board diagnostic socket on the driver's side for reading out vehicle data.





- When warning light flashes: May have engine failure that may cause damage to the catalyst device. Have the vehicle checked immediately.
- ▶ When warning light illuminates: High exhaust gas value. Have the vehicle checked as soon as possible.

### Recycling vehicle

The manufacturer of the vehicle recommends returning the vehicle to a collection point nominated by the manufacturer at the end of its life cycle. The relevant national legal provisions apply to returns and recycling in general. Information on recycling and sustainability can be found on the manufacturer's country-specific websites. Further information is available from a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.



# Replacing parts

### Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

### **Toolkit**

The toolkit is located on the left in the luggage compartment in the open storage compartment.

### Wiper blades

### Safety information



#### ∧ NOTICE

The windscreen may sustain damage if a windscreen wiper falls onto it without the wiper blade fitted. There is a risk of material damage. Hold the windscreen wiper firmly when changing the wiper blade. Do not fold in or switch on the windscreen wiper without a wiper blade installed.




#### ∧ NOTICE

Windscreen wipers which are folded away from the windscreen can become trapped if the bonnet is opened. There is a risk of material damage. Before opening the bonnet, make sure that the windscreen wipers are fitted with wiper blades and are in contact with the windscreen.

### Replacing the wiper blades

- 1. To replace the wiper blades, move the wipers to the fold-out position.
  - For fold-out position of the windscreen wipers, see page 138.
- 2. Fold out the wiper arm and hold firm.
- 3. Press together securing spring, arrow 1, and fold out the wiper blade, arrow 2.



- 4. Remove the wiper blade forwards out of its catch.
- 5. Insert the new wiper blade in the opposite sequence ensuring that it clips into place.
- 6. Fold in the windscreen wipers.

### Lights and bulbs

#### General

Lights and bulbs are an important aspect of driving safety.

All headlights and other lights use at least LED technology.

Some equipment versions have light-emitting diodes behind a cover as a light source. These light-emitting diodes are called Class 1 lightemitting diodes.

In the event of a fault, the manufacturer of the vehicle recommends having the relevant work carried out by a Service Partner of the manu-



facturer or another qualified Service Partner or a specialist workshop.

### Safety information



#### ↑ WARNING

Intense brightness can irritate or harm the retina of the eye. There is a danger of injury. Do not look directly into the headlights or other light sources. Do not remove covers from LEDs.

### Headlight glass

During cool or humid weather, the headlight glass can mist over on the inside. When driving with the lights switched on, the condensation disappears after a short time. There is no need to replace the headlight glass.

If moisture increases, for example if there are water droplets in the lamp despite the headlights being switched on, have the headlights checked.

### Vehicle battery

### General

The battery is maintenance-free.

More information regarding the battery can be obtained from a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

### Safety information



#### ⚠ DANGER

Touching live components can result in an electric shock. There is a danger of injury or danger to life. Do not touch any components that could be live.

#### ↑ WARNING

Vehicle batteries that are classified as unsuitable may damage systems or result in functions no longer being carried out. There is a danger of injury or material damage. Only use vehicle batteries that have been classified as suitable by the vehicle manufacturer.

### Registering the battery with the vehicle

The manufacturer of the vehicle recommends having a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop register the vehicle battery with the vehicle after the battery has been replaced. Once the battery has been registered again, all comfort functions will be available without restriction and any Check Control messages relating to the comfort functions will no longer be displayed.

### Hazard icons

The following hazard icons can be found on the vehicle battery:

Icon	Meaning
<b>®</b>	No smoking, no naked flames, no sparks.
	Wear protective goggles.
	Keep away from children.
	Risk of acid burns: wear gloves, do not tilt the battery.



#### Meaning Icon



Rinse any splashes of acid with water immediately. If acid comes into contact with eyes or is swallowed, seek medical attention immediately.



No direct sunlight, no frost.



Follow the operating instructions.



Explosive gas mixture. Do not seal any openings on the battery.

### Replacing the battery

#### General

The manufacturer of the vehicle recommends only having the vehicle battery replaced by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop. If the battery is not replaced correctly, the vehicle may not recognise it properly and perfect functioning cannot be guaranteed.

#### Notes on removal

Observe the following notes on removing the vehicle battery:

- Park the vehicle and switch off consumers.
- ▶ First disconnect the power at the negative terminal. Then disconnect the power at the positive terminal.

#### Notes on installation

Observe the following notes on installing the vehicle battery:

- ▶ Remove any foreign bodies from the battery holder.
- > Only install the battery in the intended position in the vehicle.

- Keep the battery and vehicle connection contacts clean.
- ▶ First connect the power at the positive terminal. Then connect the power at the negative terminal.
- ▶ Use the connections, connectors and covers provided.
- Connect a hose to the gas outlet opening if necessary.

### Initial operation

The battery is operational. No special precautions are required for start-up.

### Charging the battery

#### General

To ensure the full service life of the battery, keep the battery sufficiently charged.

Charge the battery under the following situations:

- ▶ If the inspection glass on the top of the battery is black.
- ▶ If there is not enough power to start the

The following conditions can have a negative effect on battery performance:

- ▶ Frequently driving short distances.
- ▶ If the vehicle is not used for a period of one month or longer.

### Safety information



#### MOTICE

Battery chargers that charge the vehicle battery via sockets or cigarette lighters in the vehicle may overload or damage the 12 V electrical system. There is a risk of material damage. Only connect battery chargers for the vehicle battery to the starting aid terminals in the engine compartment.



### **Battery** charger

Battery chargers developed especially for the vehicle and suitable for the electrical system can be obtained from a Service Partner of the manufacturer or another aualified Service Partner or a specialist workshop.

### Charging the battery

Only charge the battery via the starting aid terminals in the engine compartment and with the engine switched off.

With mild hybrid technology: only charge the battery when the bonnet is open.

For further information:

Jump start terminals, see page 338.

### Open circuit

Following an open circuit, some equipment will have to be reinitialised or individual settings will need to be updated, for example:

- ▶ Parking brake, see page 133.
- ▶ With memory function: save positions again.
- ▶ Time: update.
- Date: update.

### Storing the battery

Observe the following information on storing vehicle hatteries:

- > Store the battery in a cool and dry place.
- Protect the battery from direct sunlight and frost.
- Only clean the battery with a damp, antistatic cloth.
- Store the battery upright and secure it against falling over.
- ▶ Install the oldest batteries first.
- Do not remove the protective cap from the contacts.
- ▶ Charge or install the battery by the date on the battery label at the latest. Once fully

charged, the battery will work for another 10 months.

### Mild hybrid technology

#### Principle

The vehicle's mild hybrid technology includes a 48 volt battery. Mild hybrid technology can reduce fuel consumption.


### Safety information



#### ♠ DANGER

Touching live components can result in an electric shock. There is a danger of injury or danger to life. Do not touch any components that could be live

#### Overview




The mild hybrid technology battery is located in the engine compartment, under a cover on the passenger's side.



### Removing the cover

1. Turn the cap to the open padlock icon 🔐 , arrow 1.



2. Remove cover, arrow 2.

#### Notice

Do not replace or work on the mild hybrid technology battery.

### Disposing of the old battery



Dispose of old batteries with a Service Partner of the manufacturer, another qualified Service Partner or a specialist

workshop, or hand them in to an authorised collection point.

Batteries filled with acid should be transported upright. Protect batteries against falling over when in transit.

### Warrantv

See the vehicle purchase contract for information on the battery warranty.

### Fuses

## General

The fuses are located at different positions in the vehicle.

Information on fuse assignment, as well as the positions of the fuse boxes, is available on the Internet: fusecard.hmw.com.

### Safety information



#### MARNING

Incorrect or repaired fuses can overload electrical cables and components. There is a risk of fire. Do not repair blown fuses or replace them with fuses with a different colour or amp rating.

### Replacing fuses

The vehicle manufacturer recommends having fuses changed by a Service Partner of the manufacturer or another aualified Service Partner or a specialist workshop.



# Help in case of a breakdown

### Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

### Hazard warning lights





Hazard warning lights button

The red light in the button flashes when the hazard warning lights are turned on.

### Warning triangle



The warning triangle is housed on the inside of the boot lid.

Press the unlocking mechanism, arrow 1, and swivel the cover down, arrow 2.

For Indonesia: storage for a second warning triangle is provided in a bag on a free lashing eye in the luggage compartment.

### First-aid kit

#### General

Depending on the equipment and the nationalmarket version, the vehicle may have a firstoid kit

Some items in the kit have a limited life.

Check the use-by dates of the contents regularly and replace any items that have expired in good time.

### Storage

The first-aid kit is to be stored on the righthand side of the luggage compartment.

### **BMW Emergency Service**

### Principle

BMW Group Roadside Assistance can be contacted if assistance is needed in the event of a breakdown.

### General

In the event of a breakdown, data on the vehicle's condition is sent to BMW Roadside Assistance. It is possible that malfunctions can be remedied directly.

There are various ways of contacting BMW Roadside Assistance:

Via a Check Control message.



Supplementary text messages, see page 149.

- By calling with a mobile phone.
- Via the BMW app.

Depending on the national-market version and vehicle type, a different roadside assistance provider can be assigned via the Connected-Drive Customer Portal if necessary.

### Operating requirements

- ▶ Active ConnectedDrive contract, equipment with intelligent emergency call or BMW Connected Drive services.
- Mobile reception.
- Standby state is switched on.

### Starting BMW Roadside Assistance manually

When equipped with Teleservices, support is provided first through Teleservice Diagnosis and then by Teleservice help if required.

- 1. "MENU"
- 2. "All apps"
- "BMW Assistance"
- 4. Select the desired service.

A voice contact to the selected service is established.

### Teleservice Diagnosis

Teleservice Diagnostics enables detailed vehicle data, which is necessary for vehicle diagnosis, to be transmitted via mobile communication. This data is transferred automatically. It may be necessary to approve this on the Control Display.

### Teleservice Assistance

Teleservice Assistance is a country-specific feature that allows BMW Roadside Assistance to carry out a more in-depth diagnosis of the vehicle via mobile radio.

Teleservice Assistance can be started after a request by BMW Roadside Assistance.

- 1. Park the vehicle safely.
- 2. Apply the parking brake.
- 3. Turn on control display.
- 4. Consent to Teleservice help.

### **BMW Accident Assistance**

### Principle

BMW Group Accident Assistance can be contacted if assistance is needed in the event of an accident.

#### General

If the vehicle sensors detect a minor to moderately severe accident that did not trigger any airbags, a Check Control message is displayed in the instrument cluster. A corresponding text message also appears on the control display.

When BMW Accident Assistance is activated. data on the vehicle's condition is transferred to RMW.

Depending on the national-market version and vehicle type, a different accident assistance provider can be assigned via the Connected-Drive Customer Portal if necessary.

### Operating requirements

- ▶ Active ConnectedDrive contract, equipment with intelligent emergency call or BMW Connected Drive services.
- Mobile reception.
- Standby state is switched on.

### Starting BMW Accident Assistance

### If an accident is detected automatically

A BMW Accident Assistance text message is shown on the control display.

The connection can be established directly:



"Contact accident assistance"

For a short time, the Check Control message for BMW Accident Assistance can also be retrieved from the saved Check Control messages.

For further information:

Check Control, see page 148.

### Starting BMW Accident Assistance manually

BMW Accident Assistance can also be contacted independently of the automatic accident detection function.

- 1. "MENU"
- 2. "All apps"
- 3. "BMW Assistance"
- 4. If necessary, select the entry for BMW Accident Assistance.

Follow the displays on the control display. A voice contact is established.

### Emergency call

### Statutory emergency call

### **Principle**

In emergency situations, an emergency call can be triggered automatically or manually via the system.

#### General

Depending on the equipment and the nationalmarket version, the vehicle may have an emergency call system.

Press the SOS button in an emergency only.

The emergency call establishes a connection to a public emergency call number.

This depends on factors such as the specific mobile communications network and national regulations, among others.

The emergency call is placed using the integrated SIM card in the vehicle and cannot be switched off.

For technical reasons, it might not be possible to make an emergency call in highly adverse conditions.

#### Overview





SOS button

### Operating requirements

- Standby state is switched on.
- ▶ Emergency call system is functional.
- ▶ If the vehicle is equipped with intelligent emergency call: the integrated SIM card in the vehicle is activated.

### Automatic triggering

Under certain conditions, e.g. if the airbags are deployed, an emergency call is triggered automatically immediately after an accident of appropriate severity. Pressing the SOS button does not affect the automatic emergency call.

### Manual triggering

- 1. Tap the cover flap.
- 2. Press and hold the SOS button until the LED in the button area is illuminated areen.
- ▶ The LED is illuminated green when the emergency call has been activated.



If a cancellation request is shown on the control display, the emergency call can be cancelled.

If the situation permits, wait in the vehicle until voice contact has been established.

> The LED flashes green when the connection to the emergency call has been established.

When an emergency call is made, data is sent to the public rescue coordination centre in order to decide what rescue measures are required, for example the position of the vehicle, if this can be determined.

For information on data transfer and storage:

Statutory emergency call system, see page 16.

Even if the vehicle occupants can no longer hear the rescue coordination centre through the loudspeakers, the rescue coordination centre can still hear the vehicle occupants speak.

The rescue coordination centre ends the emergency call.

#### Malfunction

The emergency call function may be impaired.

The LED in the area of the SOS button flashes. for approximately 30 seconds. A Check Control message is shown.

Have checks performed by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

### Intelligent emergency call

### **Principle**

The system can be used to trigger an emeraency call automatically or manually in emergency situations.

#### General

Depending on the equipment and the nationalmarket version, the vehicle may have an emergency call system.

Press the SOS button in an emergency only.

The intelligent emergency call system establishes a connection with the BMW emergency call centre.

Even if no emergency call through BMW is possible, in some cases an emergency call may still be established to a public emergency call number. This depends on factors such as the specific mobile phone network and national regulations, among others.

For technical reasons, it might not be possible to make an emergency call in highly adverse conditions.

#### Overview





SOS button

### Operating requirements

- Standby state is switched on.
- Emergency call system is functional.
- ▶ If the vehicle is equipped with intelligent emergency call: the integrated SIM card in the vehicle is activated.

### Automatic triggering

Under certain conditions, e.g. if the airbags are deployed, an emergency call is triggered automatically immediately after an accident of



appropriate severity. Pressing the SOS button does not affect the automatic emergency call.

### Manual triggering

- 1. Tap the cover flap.
- 2. Press and hold the SOS button until the LED in the button area is illuminated green.
- ▶ The LED is illuminated green when the emergency call has been activated.
  - If a cancellation request is shown on the control display, the emergency call can be cancelled.
  - If the situation permits, wait in the vehicle until voice contact has been established.
- > The LED flashes green when the connection to the emergency call has been established.

When an emergency call is made through BMW, data such as the vehicle's current position, if this can be determined, is sent to the emergency call centre in order to decide what rescue measures are required.

If questions asked by the emergency call centre remain unanswered, rescue measures are implemented automatically.

Even if the vehicle occupants can no longer hear the emergency call centre through the loudspeakers, the emergency call centre can still hear the vehicle occupants speak.

The emergency call centre ends the emergency call.

#### Malfunction

The emergency call function may be impaired.

The LED in the area of the SOS button flashes for approximately 30 seconds. A Check Control message is shown.

Have checks performed by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

### Fire extinguisher

### Principle

The fire extinguisher can be used to put out vehicle fires.

#### General

Depending on the equipment and the nationalmarket version, the vehicle may have a fire extinguisher.

### Safety information

#### MARNING

Incorrect use of the fire extinguisher can cause injury. There is a danger of injury. Observe the information below when using the fire extinguisher:

- > Do not inhale the extinguishing agent. If the extinguishing agent has been inhaled, move the affected person into fresh air. If the casualty experiences breathing difficulties, contact a doctor immediately.
- > Do not allow the extinguishing agent to come into contact with the skin. Prolonged contact with the extinguishing agent can cause the skin to dry out.
- > Do not allow the extinguishing agent to come into contact with the eyes. In the event of contact with the eyes, rinse them immediately with plenty of water. In case of prolonged discomfort, contact a doctor.



#### ↑ WARNING

Objects in the driver's footwell can restrict the pedal travel or block a pedal that has been pressed. There is a risk of accident. Ensure that items in the vehicle are stowed securely and cannot get into the driver's footwell.



#### Overview

The fire extinguisher is located in the interior, for example under the seat or in the glove compartment.

### Removing the fire extinguisher

Open the buckles on the retaining strap.

### Using the fire extinguisher

To use the fire extinguisher, follow the manufacturer's instructions on the fire extinguisher and the information supplied with it.

### Stowing the fire extinguisher

- 1. Insert the fire extinguisher into the holder.
- 2. Hook in and close the buckles.

### Maintenance and refilling

Have the fire extinguisher checked every 2 years by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

Make a note of the next maintenance date for the fire extinguisher.

Replace the fire extinguisher after use or have it refilled.

### Jump start

#### General

If the vehicle battery is discharged, the engine can be started from another vehicle's battery using two jump leads. Only use jump leads with fully insulated terminal clamps.

### Safety information



#### ♠ DANGER

Touching live components can result in an electric shock. There is a danger of injury or danger to life. Do not touch any components that could be live.



#### ↑ WARNING

Connecting the jump lead in the wrong sequence can cause sparks. There is a danger of injury. Please comply with the correct sequence when connecting.



#### ∧ NOTICE

Contact between the bodywork of the two vehicles when jump-starting can cause a short circuit. There is a risk of material damage. Make sure there is no contact between vehicle hodies.

### **Preparations**

- 1. Check whether the battery in the other vehicle shows 12 V voltage. Information about the voltage is provided on the battery.
- 2. Switch off the engine of the donor vehicle.
- 3. Switch off any power consumers in both vehicles.

### Jump start terminals

The starting aid terminals are located in the engine compartment.

For further information:

Overview, see page 311.

Open the lid of the starting aid terminals.



### Connecting the cables

Before starting, switch off all unnecessary power consumers, for example the radio, on both vehicles.

- 1. Open the cover of the jump start terminal.
- 2. Connect a terminal clamp of the positive/+ jump lead to the positive battery terminal or the corresponding jump start terminal on the donor vehicle.
- 3. Connect the second terminal clamp to the positive battery terminal or to the corresponding jump start terminal on the vehicle being started.
- 4. Connect a terminal clamp of the negative/jump lead to the negative battery terminal or the corresponding engine or body ground on the donor vehicle.
- 5. Connect the second terminal clamp to the negative battery terminal or to a corresponding engine or body ground on the vehicle being started.

### Starting the engine

Never use spray products to start the engine.

- 1. Start the engine of the donor vehicle and allow it to run for a few minutes at a slightly higher idle rotational speed.
  - If starting a vehicle with diesel engine: allow the engine of the donor vehicle to run for approximately 10 minutes.
- 2. Start the engine of the vehicle to be started in the usual way.
  - If an initial start attempt fails, wait a few minutes before trying again to allow the discharged battery to recharge.
- 3. Allow both engines to run for a few minutes.
- 4. Disconnect the jump leads in reverse order to connection.

Check the battery and have it recharged if necessarv.

### Tow-starting/towing away

### Safety information

#### MARNING

Individual functions may malfunction when tow-starting or towing away with activated front-collision warning or Cruise Control switched on. There is a risk of accident. Turn off the front-collision warning and Cruise Control before tow-starting or towing away.

### Steptronic transmission: transporting the vehicle

#### General

The vehicle must not be towed for transport.

### Safety information



#### ∧ NOTICE

If the vehicle is towed away with one axle raised, the vehicle can be damaged. There is a risk of material damage. Only have the vehicle transported on a loading platform.



#### ⚠ NOTICE

The vehicle may be damaged when raising and securing it.

There is a risk of material damage.

- ▶ Use suitable equipment to raise the vehicle.
- ▶ Do not raise or secure the vehicle by its towing eye, body parts or suspension parts.




### Pushing the vehicle

To remove a broken-down vehicle from a danger area, it can be pushed over a short distance at a maximum speed of 10 km/h, 6 mph.

For further information:

For rolling or pushing the vehicle, see page 127.

#### Recovery vehicle



Only have the vehicle transported on a loading platform.

### Towing other vehicles

#### General

Switch on the hazard warning lights in line with local regulations.

If the electrical system of the vehicle being towed has failed, the vehicle must be made identifiable to other road users, for example by placing a sign or the warning triangle in the rear window.

### Safety information



#### ↑ WARNING

If the permitted total weight of the towing vehicle is less than that of the vehicle being towed, the towing eye may be torn off or it may not be possible to control the vehicle. There is a risk of accident. Make sure that the total weight of the towing vehicle is greater than the weight of the vehicle being towed.



#### ↑ WARNING

Different levels of braking may occur during tow-starting/towing away with adaptive recuperation. There is a risk of accident. Deactivate adaptive recuperation before tow-starting/towing away.



#### ∧ NOTICE

If the towbar or the towing rope is not attached correctly, other vehicle parts can be damaged. There is a risk of material damage. Attach the towbar or towing rope to the towing eye correctly.

#### Towbar

The towing eyes of both vehicles should be on the same side.

If it is impossible to avoid attaching the towbar at an angle, note the following:

- ▶ Clearance may be restricted when corner-
- ▶ Lateral force will be generated if the towbar is installed at an angle.

### Towing rope

Note the following if using a towing rope:

- ▶ Use nylon ropes or straps that will allow the vehicle to be towed smoothly.
- ▶ Fasten the towing rope so it is not twisted.
- ▶ Check the towing eye and towing rope fastening regularly.
- ▶ Do not exceed a towing speed of 50 km/h, 30 mph.

- Do not exceed a towing distance of 5 km, 3 miles.
- ▶ Ensure that the towing rope is taut when the towing vehicle drives off.

### Towing eye

#### General



Always keep the screw-on towing eye in the vehicle.

The towing eve can be screwed in at the front or rear of the vehicle.

The towing eye is located in the toolkit.

Observe the following notes when using the towing eye:

- > Only use the towing eye supplied with the vehicle.
- ➤ Turn the towing eye at least 5 turns clockwise and screw it in tight and as far as it will go. If necessary, tighten with a suitable object.
- ▶ After use, unscrew the towing eye in an anti-clockwise direction.
- ▶ Only use the towing eye for towing on paved roads.
- Avoid transverse loads on the towing eve. for example do not raise the vehicle by the towing eye.
- ▶ Check the towing eye mounting regularly.

For further information:

Toolkit, see page 328.

### Safety information

#### ∧ NOTICE

If the towing eye is not used as intended, the vehicle or towing eve may be damaged. There is a risk of material damage. Observe the notes on using the towing eye.

### Thread for towing eye



Press the marking on the edge of the cover to press it out.

### Tow-starting

Do not attempt to tow-start the vehicle.

If necessary, start the engine using the jump start.

Have the cause of the starting problems rectified by a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

For further information:

Jump start, see page 338.



### Care

### Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

### Vehicle wash

#### General

Regularly remove foreign objects, for example, leaves or snow, in the area below the windscreen.

Wash the vehicle frequently, especially in winter. Heavy soiling and road salt can cause damage to the vehicle.

For further information:

For fold-out position of the windscreen wipers, see page 138.

### Safety information



#### ∧ NOTICE

Damages may occur if the fuel filler flap is open while washing. There is a risk of material damage. Close the fuel filler flap before washing. Remove any dirt behind the fuel filler flap with a cloth.

### High-pressure cleaners

### Safety information



#### ⚠ NOTICE

When cleaning with high-pressure cleaners, excessive pressure or excessive temperatures can damage various components. There is a risk of material damage. Maintain a sufficient distance and do not spray for an extended period of time. Comply with the instructions for the high-pressure cleaner.

### Distances and temperature

- ▶ Maximum temperature: 60 °C/140 °F.
- Minimum distance to sensors, cameras, seals, and lights: 30 cm, approx. 12 in.
- ▶ Minimum distance to the glass sunroof: 80 cm, 31.5 in.

### Automatic car washes

### Safety information



#### MOTICE

If high-pressure washers are used, water may penetrate the area around the windows. There is a risk of material damage. Do not drive through high-pressure washers.



#### ⚠ NOTICE

The vehicle can be damaged if automatic car washes are used incorrectly. There is a risk of material damage. Observe the following notes:



- > Textile car washes or systems using soft brushes are preferable, to avoid damage to the paintwork.
- Do not drive into delete car washes or washing bays with guide rails higher than 10 cm, 4 in, to avoid damage to the bodv.
- > Note the maximum tyre width of the guide rail to avoid damage to tyres and rims.
- ▶ Fold in the exterior mirrors to avoid damaging them.
- > Deactivate the windscreen wipers and the rain sensor (if fitted) to avoid damage to the wiper system.

#### Entering a car wash



#### ∧ NOTICE

The selector lever position P is automatically engaged when standby state is switched off. The wheels are locked. There is a risk of material damage. Do not switch off standby state if the vehicle is to roll, e.g. in conveyor car washes.

The vehicle must be able to roll freely while in the car wash.

Some car washes require you to leave the vehicle. It is not possible to lock the vehicle from the outside in selector lever position N. If an attempt is made to lock the vehicle, a signal sounds.

For further information:

For rolling or pushing the vehicle, see page 127.

### Exiting from a car wash

Make sure that the vehicle key is in the vehicle.

Switch on drive-ready state.

For further information:

Drive-ready state, see page 47.

### Lights

Do not rub wet lights dry, and do not use abrasive, alcohol-based, or corrosive cleaning agents.

Soak impurities, for example insect residues, with shampoo and wash off with water.

Remove ice with a de-icer spray; do not use an ice scraper.

#### After vehicle wash

After vehicle wash, briefly apply the brakes to dry them, otherwise braking effect may be temporarily reduced. The heat generated by braking dries the brake discs and brake pads and protects them against corrosion.

Completely remove residues on the windscreens to avoid affecting visibility due to smearing and to reduce wiping noise and wiper blade wear.

### Vehicle care

### Care products

#### General

BMW recommends using care and cleaning products from BMW. Suitable care products are available from a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

### Safety information



#### MARNING

Cleaning agents can contain hazardous substances or pose a health risk. There is a danger of injury. When cleaning the interior, open the doors or windows. Use only products that are intended for vehicle cleaning. Observe the notes on the packaging.



### Vehicle paintwork

#### General

Regular care promotes driving safety and preserves your vehicle's value. Environmental effects in areas with high air pollution or natural contaminants, for example tree resin or pollen, may affect the vehicle paintwork. Take such factors into consideration when deciding on the frequency and scope of vehicle care measures.

Immediately remove aggressive substances, such as spilled fuel, oil, grease, or bird droppings, to prevent the paintwork from being damaged and discoloured.

#### Matt paintwork

Only use cleaning and care products that are suitable for vehicles with matt paintwork.

#### I eather care

Remove dust from the leather at regular intervals with a cloth or vacuum cleaner.

Dust and road dirt will otherwise become worked into pores and folds, resulting in considerable abrasion and causing the leather surface to become prematurely brittle.

To protect against discolouration, for example from clothing, clean and care for the leather approximately every two months.

Clean light-coloured leather more frequently as it has the tendency to soil faster.

Use leather cleaner, otherwise dirt and grease will attack the protective coating of the leather.

Immediately remove aggressive substances, such as sunscreen, to prevent the leather from being altered or discoloured.

### Synthetic leather care

Clean the synthetic leather regularly with a damp microfibre cloth or vacuum cleaner.

Dust and road dirt will otherwise become worked into pores and folds, resulting in considerable abrasion and causing the surface to become prematurely brittle.

In case of major contaminations, use a moist soft sponge or microfibre cloth with a suitable interior cleaners.

Immediately remove aggressive substances, such as sunscreen, to prevent the synthetic leather from being altered or discoloured.

#### Fabric care

#### General

In case of major contaminations, such as beverage stains, use a moist soft sponge or microfibre cloth with a suitable interior cleaners.

Immediately remove aggressive substances, such as sunscreen, to prevent the fabric from being altered or discoloured.

### Safety information



#### ∧ NOTICE

Open hook and loop fasteners on articles of clothing can damage the seat covers and other cloth upholstery in the vehicle. There is a risk of material damage. Make sure that the hook and loop fasteners are closed.

### Care of upholstery fabrics

Vacuum regularly with a vacuum cleaner.

Clean extensively down to the seams. Avoid rubbing vigorously.

#### Textile care

Use a microfibre cloth for cleaning minor contamination.

Dampen the cloth with water.



### Care of special parts

### Displays, operating elements and protective glass of the Head-up display



The surfaces can be damaged by improper cleaning, e.g. with chemical cleaners, moisture or liquids of all kinds. There is a risk of material damage.

- > Avoid applying excessive pressure and do not use abrasive materials.
- ▶ Use a dry, clean antistatic microfibre cloth for cleaning displays.
- ▶ Clean the operating elements and, depending on the equipment, clean the protective glass of the Head-up display using a damp microfibre cloth and commercially available dish-washing soap.

### Light alloy wheels

When cleaning the wheels while they are installed on the vehicle, only use neutral rim cleaner with a pH value between 5 and 9. Do not use abrasive cleaners or high-pressure cleaners above 60 °C/140 °F. Observe the manufacturer's instructions.

Corrosive, acidic or alkaline cleaners may destroy the protective coatings of adjacent parts, for example brake disc.

After cleaning, briefly apply the brakes to dry them. The heat generated by braking dries the brake discs and brake pads and protects them against corrosion.

### Chrome-like surfaces

Chrome-like surfaces, particularly those that have been exposed to road salt, should be cleaned carefully with plenty of water, with added shampoo if required.

### Rubber parts

The surfaces of rubber parts can be contaminated or lose their shine due to environmental influences. Only use water and suitable care products for cleaning.

Rubber parts subjected to high wear and tear should be treated regularly with rubber care products. Do not use silicone-based care products for treating rubber seals, otherwise these could be damaged and become a source of noise.

#### Wiper blades

The wiper blades are cleaned by using the window washer system.

Avoid additional manual cleaning of the wiper blades to prevent a reduction in wipe quality.

#### Fine wood parts

Clean fine wood trim and fine wood parts with a damp cloth only. Then dry with a soft cloth.

#### Kenaf

Treat parts made from kenaf fibres with a suitable care product only.

### Plastic parts



#### ▲ NOTICE

Cleaning agents containing alcohol or solvents, for example nitro thinners, cold cleaners, fuel or similar can damage plastic parts. There is a risk of material damage. Clean with a microfibre cloth. Lightly moisten the cloth with water if necessary.

Clean with a microfibre cloth.

Lightly moisten the cloth with water if necessary.

Do not soak the headliner.



#### Seat belts



#### ↑ WARNING

Chemical cleaners can cause irreparable damage to the fabric of the seat belts. The protective effect of the seat belts will be lost. There is a danger of injury or danger to life. Only use a mild soap and water solution for cleaning the seat belts.

Dirt on the seat belt straps can interfere with the action of the reel and is a safety hazard.

Only clean the seat belt straps with a mild soap solution while still fitted to the vehicle.

Do not allow seat belts to retract until they are dry.

### Carpets and floor mats



#### MARNING

Objects in the driver's footwell can restrict the pedal travel or block a pedal that has been pressed. There is a risk of accident. Ensure that items in the vehicle are stowed securely and cannot get into the driver's footwell. Only use floor mats that are suitable for the vehicle and can be securely fastened to the floor. Do not use loose floor mats, and do not place several floor mats on top of one another. Make sure that there is sufficient space for the pedals. Ensure that floor mats are securely reattached after removal, for example for cleaning.

Floor mats can be removed from the vehicle to enable the interior to be cleaned more thoroughly.

In the event of heavy soiling, clean floor carnets using a microfibre cloth and water or textile cleaner. Rub back and forth in the direction of travel to prevent matting.

### Trailer tow hitch with removable ball head

Keep ball head and bracket clean.

Grease or oil bearing locations, sliding surfaces and the small balls on the bracket pin regularly with resin-free grease or oil.

Before using high-pressure cleaners on the vehicle, remove the ball head and insert the cover into the bracket.

Do not clean ball head with a high-pressure cleaner.

#### Sensors and camera lenses

Clean sensors or camera lenses usina a cloth moistened with a small amount of glass cleaner.

### Laying up the vehicle

Special measures need to be taken if putting the vehicle out of use for longer than three months. Additional information is available from a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.



## Technical data

### Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be of-

fered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

### General

The technical data and specifications in the Owner's Handbook are reference figures. Data relating to a specific vehicle can deviate from this, for example, due to selected optional equipment, national-market versions or country-specific measurement procedures. Detailed values can be found in the permit documents,

on signs on the vehicle or can be requested from a Service Partner of the manufacturer or another qualified Service Partner or a specialist workshop.

The information in the vehicle documents always takes precedence over the information in the Owner's Handbook.

### **Dimensions**

Dimensions can vary depending on the model version, equipment or country-specific measurement method.

In addition, the height of the vehicle may vary, for example, due to tyres and load.

BMW 2 Series Coupé		
Width with mirrors	mm (in)	2068 (81.4)
Width without mirrors	mm (in)	1838 (72.4)
Height	mm (in)	1404 (55.3)
Length	mm (in)	4548 (179.1)
Wheelbase	mm (in)	2741 (107.9)
Smallest turning circle diameter	m (ft)	11.6 (38.1)

# Weights

218i		
Kerb weight ready for use, with 75 kg, 165 lb load, tank 90 % full, no optional equipment	kg (lb)	1560 (3439)
Permitted total weight	kg (lb)	1960 (4321)
Payload	kg (lb)	475 (1047)
Front axle load limit	kg (lb)	960 (2116)
Rear axle load limit	kg (lb)	1105 (2436)
Permitted roof load	kg (lb)	75 (165)

220i		
Kerb weight ready for use, with 75 kg, 165 lb load, tank 90 % full, no optional equipment	kg (lb)	1565 (3450)
Permitted total weight	kg (lb)	1965 (4332)
Payload	kg (lb)	475 (1047)
Front axle load limit	kg (lb)	960 (2116)
Rear axle load limit	kg (lb)	1105 (2436)
Permitted roof load	kg (lb)	75 (165)

230i		
Kerb weight ready for use, with 75 kg, 165 lb load, tank 90 % full, no optional equipment	kg (lb)	1600 (3527)
Permitted total weight	kg (lb)	2000 (4409)
Payload	kg (lb)	475 (1047)
Front axle load limit	kg (lb)	960 (2116)
Rear axle load limit	kg (lb)	1110 (2447)
Permitted roof load	kg (lb)	75 (165)

M240i powered by BMW M		
Kerb weight ready for use, with 75 kg, 165 lb load, tank 90 % full, no optional equipment	kg (lb)	1710 (3770)
Permitted total weight	kg (lb)	2110 (4652)
Payload	kg (lb)	475 (1047)
Front axle load limit	kg (lb)	1035 (2282)
Rear axle load limit	kg (lb)	1160 (2557)
Permitted roof load	kg (lb)	75 (165)

M240i xDrive powered by BMW M		
Kerb weight ready for use, with 75 kg, 165 lb load, tank 90 % full, no optional equipment	kg (lb)	1765 (3891)
Permitted total weight	kg (lb)	2165 (4773)
Payload	kg (lb)	475 (1047)
Front axle load limit	kg (lb)	1090 (2403)
Rear axle load limit	kg (lb)	1160 (2557)
Permitted roof load	kg (lb)	75 (165)

220d		
Kerb weight ready for use, with 75 kg, 165 lb load, tank 90 % full, no optional equipment	kg (lb)	1655 (3649)
Permitted total weight	kg (lb)	2055 (4531)
Payload	kg (lb)	475 (1047)
Front axle load limit	kg (lb)	995 (2194)
Rear axle load limit	kg (lb)	1160 (2557)
Permitted roof load	kg (lb)	75 (165)

### Trailer operation

#### **218i**

Trailer loads according to EU operating permit. Consult an authorised Service Partner or another qualified Service Partner or a specialist workshop about options for increasing the loads.

Trailer load without brake	kg (lb)	750 (1653)
Trailer load with brake on upward gradient up to 12 %	kg (lb)	1300 (2866)
Trailer load with brake on upward gradient up to 8 %	kg (lb)	1300 (2866)
Maximum trailer nose weight	kg (lb)	75 (165)
Minimum trailer nose weight	kg (lb)	25 (55)
Rear axle load limit, towing vehicle	kg (lb)	1215 (2679)
Permitted total weight, towing vehicle	kg (lb)	2035 (4486)

#### 220i

Trailer loads according to EU operating permit. Consult an authorised Service Partner or another qualified Service Partner or a specialist workshop about options for increasing the loads.

Trailer load without brake	kg (lb)	750 (1653)
Trailer load with brake on upward gradient up to 12 %	kg (lb)	1600 (3527)
Trailer load with brake on upward gradient up to 8 %	kg (lb)	1600 (3527)
Maximum trailer nose weight	kg (lb)	75 (165)
Minimum trailer nose weight	kg (lb)	25 (55)
Rear axle load limit, towing vehicle	kg (lb)	1215 (2679)
Permitted total weight, towing vehicle	kg (lb)	2040 (4497)

#### 230i

Trailer loads according to EU operating permit. Consult an authorised Service Partner or another qualified Service Partner or a specialist workshop about options for increasing the loads.

Trailer load without brake	kg (lb)	750 (1653)	

230i		
Trailer load with brake on upward gradient up to 12 %	kg (lb)	1600 (3527)
Trailer load with brake on upward gradient up to 8 %	kg (lb)	1600 (3527)
Maximum trailer nose weight	kg (lb)	75 (165)
Minimum trailer nose weight	kg (lb)	25 (55)
Rear axle load limit, towing vehicle	kg (lb)	1220 (2690)
Permitted total weight, towing vehicle	kg (lb)	2075 (4575)

### M240i powered by BMW M

Trailer loads according to EU operating permit. Consult an authorised Service Partner or another qualified Service Partner or a specialist workshop about options for increasing the loads.

Trailer load without brake	kg (lb)	750 (1653)
Trailer load with brake on upward gradient up to 12 %	kg (lb)	1600 (3527)
Trailer load with brake on upward gradient up to 8 %	kg (lb)	1600 (3527)
Maximum trailer nose weight	kg (lb)	75 (165)
Minimum trailer nose weight	kg (lb)	25 (55)
Rear axle load limit, towing vehicle	kg (lb)	1270 (2800)
Permitted total weight, towing vehicle	kg (lb)	2185 (4817)

### M240i xDrive powered by BMW M

Trailer loads according to EU operating permit. Consult an authorised Service Partner or another qualified Service Partner or a specialist workshop about options for increasing the loads.

Trailer load without brake	kg (lb)	750 (1653)
Trailer load with brake on upward gradient up to 12 %	kg (lb)	1600 (3527)
Trailer load with brake on upward gradient up to 8 %	kg (lb)	1600 (3527)
Maximum trailer nose weight	kg (lb)	75 (165)

M240i xDrive powered by BMW M		
Minimum trailer nose weight	kg (lb)	25 (55)
Rear axle load limit, towing vehicle	kg (lb)	1270 (2800)
Permitted total weight, towing vehicle	kg (lb)	2240 (4938)

### 220d

Trailer loads according to EU operating permit. Consult an authorised Service Partner or another qualified Service Partner or a specialist workshop about options for increasing the loads.

Trailer load without brake	kg (lb)	750 (1653)
Trailer load with brake on upward gradient up to 12 %	kg (lb)	1600 (3527)
Trailer load with brake on upward gradient up to 8 %	kg (lb)	1600 (3527)
Maximum trailer nose weight	kg (lb)	75 (165)
Minimum trailer nose weight	kg (lb)	25 (55)
Rear axle load limit, towing vehicle	kg (lb)	1270 (2800)
Permitted total weight, towing vehicle	kg (lb)	2130 (4696)

## Capacities

BMW 2 Series Coupé		
Fuel tank, approx.	Litres (gal)	51.0 (11.2)

Please observe the additional information about fuel grade, see page 314.

# Seats for child restraint systems

### Vehicle equipment

This chapter describes equipment, systems and functions which are offered or will be offered on a model-specific basis, even if they are not included in the vehicle in question.

For further information:

Vehicle equipment, see page 8.

### Information for manufacturers of child seats

#### General

Information about which child restraint systems can be used on each seat, in accordance with the ECE-R 16 and ECE-R 129 standards.

### Left-hand drive vehicles: Suitability of child restraint systems for each vehicle seat

Seat position	1	3 – Air- bag ON	3 – Air- bag OFF	4	5	6
Seat position suitable for universal fastening with a belt.	No	Yes forward facing	Yes rearward facing	Yes	No	Yes
i-Size seat position.	No	No	No	Yes	No	Yes
Seat position suitable for side mounting: L1/L2.	No	No	No	No	No	No
Largest rear- facing mount- ing: R1/R2X/R2/R3.	No	No	No	R2	No	R2
Largest front-facing mounting: F2X/F2/F3.	No	No	No	F3	No	F3
Largest suitable booster mount: B2/B3.	No	No	No	B3	No	B3

A seat position without i-Size approval is not compatible with an i-Size support stand.

A seat position with lower ISOFIX anchors, but with no top tether, is not available.

There are no seat belt buckles for adults between the two bottom ISOFIX anchors.

Seat number	Position in the vehicle
1	Front left
2	Front centre

Seat number	Position in the vehicle
3	Front right
4	Second-row seating left

Seat number	Position in the vehicle
8	Third-row seating centre
9	Third-row seating right
9	Third-row seating right

# Right-hand drive vehicles: suitability of child restraint systems for each vehicle seat

Seat position	1 – Airbag ON	1 – Airbag OFF	3	4	5	6
Seat position suitable	Yes	Yes	No	Yes	No	Yes
for universal fastening with a belt.	forward facing	rearward facing				
i-Size seat position.	No	No	No	Yes	No	Yes
Seat position suitable for side mounting: L1/L2.	No	No	No	No	No	No
Largest rear- facing mount- ing: R1/R2X/R2/R3.	No	No	No	R2	No	R2
Largest front-facing mounting: F2X/F2/F3.	No	No	No	F3	No	F3
Largest suitable booster mount: B2/B3.	No	No	No	B3	No	В3

A seat position without i-Size approval is not compatible with an i-Size support stand.

A seat position with lower ISOFIX anchors, but with no top tether, is not available.

There are no seat belt buckles for adults between the two bottom ISOFIX anchors.

Seat number	Position in the vehicle
1	Front left
2	Front centre
3	Front right
4	Second-row seating left
5	Second-row seating centre
6	Second-row seating right

Seat number	Position in the vehicle
7	Third-row seating left
8	Third-row seating centre
9	Third-row seating right

# **Appendix**

### General

Here is where any updates to the Owner's Handbook for the vehicle are listed.

### Updates after going to press

After the Integrated Owner's Handbook in the vehicle went to press, the following chapters were updated in the printed Owner's Handbook:

- Operation: Sensors of the vehicle: radar sensors: safety instructions.
- Departion: driving: Launch Control.
- Operation: driving stability control systems: Dynamic Stability Control: activating/deactivating Dynamic Stability Control: deactivating/activating the system.
- Operation: driving stability control systems:
   Dynamic Traction Control: deactivating/activating Dynamic Traction Control.
- Operation: storage compartments: folddown compartment: safety information.
- Mobility: breakdown assistance: warning triangle.

### License Texts and Certifications

#### Brazil

#### Wireless Charging

Este equipamento não tem direito à proteção contra interferência prejudicial e não pode causar interferência em sistemas devidamente autorizados.

Anatel: 13020-21-04457

#### India

#### Telematics Communication Box

WAVE-01-LOW-R1, WAVE-01-HIGH-R1

This product confirms to the relevant Essential Requirements of TEC, Department of Telecommunications, Ministry of Communications, Govt of India, New Delhi-110001

#### Mexico

#### Wireless Charging

IFT: RCPZEWP21-4669


La operación de este equipo está sujeta a las siquientes dos condiciones:

(1) es posible que este equipo o dispositivo no cause interferencia perjudicial y

(2) este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.

#### Serbia

WAVF-11-HIGH-R2



#### South Africa

### Telematics Communication Box

WAVE-11-HIGH-R2



### Taiwan (R.O.C)

### Wireless Charaina



#### CCAR21I P2460T3

取得審驗證明之低功率射頻器材,非經核准,公 司、商號或使用者均不得擅自變更頻率、加大功 率或變更原設計之特性及功能。低功率射頻器材 之使用不得影響飛航安全及干擾合法通信: 經發 現有干擾現象時, 應立即停用, 並改善至無干擾 時方得繼續使用。前述合法通信, 指依電信管理 法規定作業之無線電通信。低功率射頻器材須忍 受合法通信或工業、科學及醫療用電波輻射性電 機設備之干擾。

Product name / 产品名称: 車載無線充電設備

Brand / 品牌介绍: BURY

Model name / 模型名称: WCA CS NFC LCI

Input rating / 输入额定值: 12V = 1,2A

Output rating / 输出等级: 5W (5V = 1A)

Operating temperature range / 操作温度范围:

-40 °C to 80 °C

進口商 / Importer: 汎德股份有限公司

地址 / Address: 臺北市內湖區行愛路 100 號 7 樓

電話 / Tel.: +886 3 42827111

#### Principle /原则

无线充电底座允许以无线方式执行以下功能。

▷为支持 Qi 标准的 Qi 兼容移动?话或其他移动设 备充电。

▷为 BMW 显示键充电。

▷将移动?话与外部天线连接。

安全须知

#### 警告

当用无线充电底座给兼容 Qi 的设备充电时, 位 干设备和底座之间的仟何金属物体都会变得非常 热。如果存储介质或电子卡,例如智能卡、带磁 条的卡或用于传输信号的卡,被放在设备和底座 之间, 卡的功能可能会受到影响。有受伤和材料 损坏的风险。给移动设备充电时,确保设备 和底 座之间没有任何物体。

#### 注意

底座是为一定大小的移动电话设计的。使用过度 的力量插入移动电话可能会损坏底座或移动电 话。这有可能造成物质损失。请遵守移动电话的 最大尺寸。请勿将移动电话强行插入底座。

# Everything from A to Z

### Index

0-9	AdBlue, see BMW diesel with BluePerform- ance 316
3D view 221	AdBlue, topping up 316
48 V technology, see Mild hybrid technol-	Additives, engine oil grades 321
ogy 331	After-run of fan, see Exhaust gas particulate filter 263
A	Airbags 169
	Airbags, indicator/warning light 170
ABS, see Anti-lock Braking System 194	Airbag switch, see Key switch for front passenger airbag 171
Acceleration assistant, see Launch Control 130	Air conditioning function, air conditioning 241
Acceleration sensor, see g-Meter 155	Air distribution, manual 242
Accessories and parts 10	Air pressure, tyres 286
Accident prevention, see Active Protection 190 ACC, see Cruise Control with Distance Con-	Air quality 245
trol 206	Air recirculation function 241
Activated carbon filter, see Interior filter 245	Air vents, see Ventilation 244
Activation, airbag 171	Alarm system 90
Activation points, Panorama View 222	All-season tyres, see Winter tyres 290
Activation, trailer operation 272	All-wheel drive, see xDrive 197
Activation word 57	Ambient lighting 167
Active bonnet, see Active pedestrian protection 172	Amount of air, automatic air conditioning 242 Anticipation, Speed Limit Info 200
Active Cruise Control 206	Antifreeze additive, see Washer fluid 323
Active Guard, refer to Collision warning systems 173	Antifreeze protection, see Washer fluid 323 Anti-lock Braking System 194
Active M Sport differential 197	Anti-theft security system, locking wheel
Active Park Distance Control 227	bolts 308
Active pedestrian protection 172	Anti-trap mechanism, glass sunroof 96
Active Protection 190	Anti-trap mechanism, windows 93
Active shock absorber adjustment, see Adaptive M suspension 236	Apps, see Owner's Handbook for Navigation, Entertainment, Communication 6
Adaptive brake assist 194	Aquaplaning 264
Adaptive brake light, see Dynamic brake	Attentiveness Assistant 191
lights 188	Attentiveness camera, driver, see Driver Atten-
Adaptive lighting functions 163	tion Camera 192
Adaptive M suspension 236	Audio, see Owner's Handbook for Navigation,
Adaptive recuperation 281	Entertainment, Communication 6
AdBlue at low temperatures 317	AUTO H button, see Automatic Hold 134
AdBlue at minimum 316	Automatic air conditioning 237

Automatic camera perspective 220

Automatic car washes 342	BMW Digital Key 84
Automatic dimming, see High-beam Assis-	BMW Drive Recorder 188
tant 164	BMW ID 68
Automatic driving lights 160	BMW iDrive 49
Automatic driving lights control 160	BMW Intelligent Personal Assistant 57
Automatic Hold 134	BMW Live Cockpit Plus, see BMW Curved Dis-
Automatic locking 89	play 52
Automatic parking function, exterior mirror 109	BMW Live Cockpit Professional, see BMW
Automatic programme, automatic air condi-	Curved Display 52
tioning 239	BMW Maintenance System 325
Automatic rear air-conditioning system 237	BMW Operating System, see BMW iDrive 49
Automatic rear air-conditioning system, disa-	BMW Roadside Assistance 333
bling operating elements 239	BMW Services, see Owner's Handbook for
Automatic Stability Control 196	Navigation, Entertainment, Communication 6
Automatic Start/Stop function 123	Bonnet 311
Automatic start-stop function 123	Boot lid, emergency release 83
Automatic time setting 155	Bottle holder, front, see Cup holder, front 255
Automatic transmission, see Steptronic trans-	Bottle holder, rear, see Cup holder, rear 255
mission 126	Brake Assist 194
Automatic unlocking 89	Brake assist, adaptive 194
Automating habits, BMW Intelligent Personal	Brake discs, running in 262
Assistant 60	Brake discs, see Brake system 262
AUTO programme, automatic air condition-	Brake light, adaptive, see Dynamic brake
ing 239	light 188
Average consumption, see Trip data 153	Brake lights, dynamic 188
Axle loads, permitted 349	Brake pads, running in 262
	Brake pads, see Brake system 262
В	Brake system 262
	Braking, notes 265
Backrest angle 100	Braking safely 265
Backrest contour, see Lumbar support 101	Breakdown, help 333
Backrest, seats 98	Break recommendation, see Attentiveness As-
Backrest width 101	sistant 191
Bad weather light 166	Brightness, control display 53
Ball head 272	Button, AUTO H, see Automatic Hold 134
Bar for tow-starting/towing away 340	Button, central locking system 87
Battery, disposal 332	Buttons on the steering wheel 36
Battery, vehicle 329	Button SOS, see Intelligent emergency
Belts, see Seat belts 103	call 336
Biodiesel 315	Button SOS, see Legal emergency call 335
Blower, see Amount of air 242	Button, start/stop 123
Blu-ray, see Owner's Handbook for Naviga-	6
tion, Entertainment, Communication 6	C
BMW Accident Assistance 334	
BMW Curved Display 52	Calendar day, see Date 155

Calibration of the front seats 102

BMW diesel with BluePerformance 316

Camera, instrument cluster, see Driver Attention Camera 192 Camera lenses, care 346 Camera perspective, automatic 220 Camera, Reversing Assist Camera 219 Cameras, see Sensors in the vehicle 41 CANCEL button, Active Cruise Control 206 CANCEL button, Cruise Control 203 Can holder, front, see Cup holder, front 255 Can holder, rear, see Cup holder, rear 255 Care, displays, screens 345 Care, displays, screens 345 Care, light-alloy wheels 345 Care of upholstery fabrics 344 Care products 343 Care, vehicle 343 Care, vehicle 433 Care, vehicle 343 Care, vehicle 343 Carrying children 113 Carrying children 113 Carrying children safely 113 Car wash 342 Car washes, automatic 342 Car wash view 221 Catalytic converter, see Hot exhaust system 263 CBS, see Condition Based Service 325 Central display, see BMW Curved Display 52 Central indication range, instrument cluster 152 Central key, see Vehicle key 74 Central locking switch, see Central locking system 87 Central locking system 87 Central cornsole 39 Chapper to behisel, see Veyra our cafety 0	Communication, see Owner's Handbook for Navigation, Entertainment, Communication (Compartments in the doors 254 Compressor 293 Concierge Service, see Owner's Handbook for Navigation, Entertainment, Communication (Condensation when vehicle is parked 266)
,	Collision Warning, see Front-collision warn-
tem 263	ing 174
	Collision warning systems 173
Central display, see BMW Curved Display 52	Comfort Access 80
Central display, see Control display 52	COMFORT, see Driving Experience Control 13
	_
	·
· ·	
Changes, technical, see Your own safety 9	Condensation, windscreen 243
Change, wheels and tyres 289	Condition Based Service 325
Changing bulbs, see Lights and bulbs 328	ConnectedDrive, see Owner's Handbook for
Changing the battery, vehicle key 75	Navigation, Entertainment, Communication
Charging a smartphone, see Wireless charging	Connecting electrical devices, see Sockets 249
tray 251 Charging cradle for smartphones, see Wireless	Connecting, mobile devices 61 Connecting mobile devices to the vehicle 61
charging tradite for strict thrones, see wheless	Consumption, see Trip data 153
Chassis number, see Vehicle identification	Contacts, see Owner's Handbook for Naviga-
number 20	tion, Entertainment, Communication 6

Continuing driving with flat tyre, see Flat tyre monitor, checking tyre pressure, see Flat tyre	Departure time, pre-conditioning via Remote Engine Start 247
monitor 304	Departure time, pre-cooling 245
Continuing driving with flat tyre, see Tyre Pres-	Destination entry, see Owner's Handbook for
sure Monitor 297	Navigation, Entertainment, Communication 6
Control display 52	Diagnostic connection 326
Control display, brightness 53	Diesel fuel 315
Control display, pop-ups 51	Diesel particulate filter, see Exhaust gas partic-
Control systems, driving stability 194	ulate filter 263
Conveyor car wash 342	Differential lock 197
Coolant 322	Digital Key, see BMW Digital Key 84
Coolant level 323	Digit input, iDrive 51
Coolant temperature, see Engine tempera-	Dimensions 348
ture 151	Dimming exterior mirror 109
Cooling, maximum 241	Dimming interior mirror 110
Cornering light 164	Direct dial buttons, see Shortcuts 52
Corrosion, brake discs 265	Disabling operating elements, automatic rear
Crossing-traffic Warning 186	air-conditioning system 239
Cruise Control with Distance Control 206	Display and operating concept, see BMW
Cruise Control without Distance Control 203	iDrive 49
Cup holder, front 255	Display, current driving condition 157
Cup holder, rear 255	Display, iDrive 51
Current driving condition 157 Curved Display 52	Display in the windscreen, see Head-up display 142
Customer support, see Owner's Handbook for	Display lighting, see Instrument lighting 166
Navigation, Entertainment, Communication 6	Display panel, see Instrument cluster 140 Displays 140
D	Displays and icons 7
	Display, see BMW Curved Display 52
Damages, tyres 288	Display, see Control display 52
Dashboard, see Instrument cluster 140	Displays for the vehicle, see Live Vehicle 141
Dashcam, see BMW Drive Recorder 188	Display, speed limit, see Speed Limit Info 198
Data protection, settings 67	Disposal, coolant 323
Data, see Deleting personal data 67	Disposal, vehicle battery 332
Data storage medium, see Vehicle data and	Disposing of the old battery 332
data protection 10	Distance Control, see Cruise Control 206
Data, technical 348	Distance warning, see Park Distance Con-
Date 155	trol 224
Daytime driving lights 163	Door handle lighting, see Welcome light 162
DCC, see Cruise Control without Distance Con-	Door opening angle 223
trol 203	Downhill gradient 265
Deactivation, airbag 171	Drinks holder, front, see Cup holder, front 255
Defrosting, windscreen 243	Drinks holder, rear, see Cup holder, rear 255
De-icing 243	Drive mode, see Driving Experience Control 131
Deleting, personal data 67	Drive-off assistant 194
Departure schedule, see Pre-cooling 245	

Drive-off Assistant, see Dynamic Stability Con-	Efficient4x4, see xDrive 197
trol 194	Efficient coasting, see Current driving condi-
Orive power reduced 150	tion 157
Driver activity, see Driver Attention Camera 192	Electronic oil measurement 320
Oriver assistance, parking, see Parking assis-	Electronic Stability Programme ESP, see Dy-
tance systems 215	namic Stability Control 194
Oriver assistance systems 198	E-mail, see Owner's Handbook for Navigation,
Oriver Attention Camera 192	Entertainment, Communication 6
Drive-ready state, engine start 47	Emergency assistance, see BMW Accident Assistance 22/
Orive-ready state, see Operating condition of	sistance 334
the vehicle 46 Drive Recorder 188	Emergency assistance, see BMW Roadside Assistance 333
Driver profiles 68	Emergency braking, see PostCrash –
Driver profiles, welcome display 68	iBrake 191
Driver profiles, welcome display 68  Drive sound 236	
Driving 123	Emergency call 335 Emergency release, boot lid 83
Driving Assistant, refer to Collision warning	Emergency release, fuel filler flap 285
systems 173	Emergency release, parking lock 128
Driving comfort 236	Emergency service, see BMW Accident Assis-
Driving condition, display 157	tance 334
Driving Experience Control 131	Engine, automatic start-stop function 123
Driving lane lines, Reversing Assist Cam-	Engine compartment 311
era 218	Engine coolant 322
Oriving lights control, automatic 160	Engine cooling system 322
Driving notes, general 263	Engine idling when driving, see Coasting 282
Driving notes, running in 262	Engine oil filler neck 321
Driving Stability Control Systems 194	Engine oil grades for topping up 321
Oriving, Start/Stop button 123	Engine oil level, checking electronically 320
Oriving style analysis, ECO PRO 281	Engine oil, topping up 321
Driving through water 264	Engine start, see Drive-ready state 47
Oriving tips, see General driving notes 263	Engine start, see Jump start 338
Orying air, see Air conditioning function 241	Engine stop, see Drive-ready state 47
DSC, see Dynamic Stability Control 194	Engine temperature 151
OTC, see Dynamic Traction Control 196	Entering an address, Navigation, see Own-
Dynamic brake lights 188	er's Handbook for Navigation, Entertainment,
Dynamic damping, see Adaptive M suspen-	Communication 6
sion 236	Entering letters and numbers 51
Dynamic ECO light function 163	Entertainment, see Owner's Handbook for
Dynamic Stability Control 194	Navigation, Entertainment, Communication 6
Dynamic Traction Control 196	Entertainment, selection list in the instrument cluster 149
	Equipment, interior 249
	ESP Electronic Stability Programme, see Dy-
ECO light function, dynamic 163	namic Stability Control 194
ECO PRO, driving style analysis 281	Exchange, wheels and tyres 289
FCO PRO, see Driving Experience Control 131	Exhaust gas particulate filter 263

Exhaust, see Exhaust system 263 Exhaust system 263	Flat tyre warning light, see Tyre Pressure Monitor 300
Exterior lights, locked vehicle 162	Flat tyre, wheel change 306
Exterior mirror 108	Flood, driving through 264
Exterior mirror, automatic parking function 109	Floor carpet, care 346
Exterior mirror, datornatic parking ranction 103	Floor mats, care 346
Exterior mirror, malfunction 109	Fold-out position, windscreen wiper 138
Exterior mirror with automatic anti-dazzle	Foot brake 265
function 109	Fording depth, water 264
External start, see Jump start 338	Front airbags 169
Eye for securing cable, trailer operation 276	Front-collision warning 174
Eye for towing 341	Front passenger's mirror, tilting down, see Au-
Eyes, see Lashing eye in the luggage compart-	tomatic parking function 109
ment 258	Front passenger airbag, deactivating/activat-
ment 250	ing 171
F	Front passenger airbag, indicator light 172
· ·	Front seats 98
Factory settings, see Resetting vehicle data 68	Fuel 314
Failure message, see Check Control 148	Fuel filler cap 284
False alarms, see Avoiding false warnings 91	Fuel filler flap 284
False warnings, avoiding 91	Fuel filler flap, unlocking manually 285
Fan run-on, see Exhaust gas particulate fil-	Fuel grade 314
ter 263	Fuel level indicator 155
Fastening seat belts, see Seat belts 103	Fuel recommendation 314
Fatigue Warning, see Attentiveness Assis-	Fuel, saving 277
tant 191	Fuel tank capacity 353
Fault displays, see Check Control 148	Fuel tank, see Capacities 353
Filling pressure, tyres 286	Fuses 332
Filter, see Interior filter 245	
Fine wood, care 345	G
Fine wood parts, care 345	
Fire extinguisher 337	Gear change, Steptronic transmission 126
First-aid kit 333	General driving notes 263
Flank view 220	Glare protection, see Sun visor 249
Flat tyre, continue driving, see Flat tyre moni-	Glass sunroof 94
tor 304	Glass sunroof, initialising system 97
Flat tyre, fixing 292	Glove compartment 253
Flat tyre message, see Flat Tyre Monitor 305	g-Meter 155
Flat tyre message, see Tyre Pressure Moni-	GPS, navigation, see Owner's Handbook for
tor 300	Navigation, Entertainment, Communication 6
Flat tyre monitor 304	Guest profile, see BMW ID 68
Flat tyre, see Flat tyre monitor 304	
Flat tyre, see Tyre Pressure Monitor 297	H
Flat tyre warning light, see Flat Tyre Moni-	

Handbrake, see Parking brake 132

tor 305

Hands-free system, see Owner's Handbook for Navigation, Entertainment, Communica- tion 6 Hazard warning lights 333	iDrive 49 Ignition key, see Vehicle key 74 Important considerations 113 Inclination, backrest 100
Head airbag 169	Indicator light, front passenger airbag 172
Headlight flasher 136	Indicator lights 143
Headlight glass 329	Individual air distribution 242
Headlights, care 343	Individual settings, see BMW ID 68
Headlights, setting, see Right-hand/left-hand traffic 166	Inductive charging, smartphone, see Wireless charging tray 251
Headliner 40	Initialisation, see Flat Tyre Monitor 304
Head restraints and seats 98	Input comparison 51
Head restraints, front 105	Installing child restraint systems 114
Head restraints, rear 107	Instrument cluster 140
Head-up display 142	Instrument cluster switch, see Turn indica-
Head-up display, care 345	tor 135
Head-up Display position, saving, see Memory function 111	Instrument cluster switch, see Wiper system 136
Heavy loads, stowing 257	Instrument lighting 166
Height, vehicle 348	Instrument panel, see Instrument cluster 140
Help in case of a breakdown 333	Integrated key 75
Help in driving off, see Drive-off assistant 194	Integrated Owner's Handbook in the vehicle 6
High-beam Assistant 164	Intelligent emergency call 336
High-beam headlight 136	Intelligent Personal Assistant 57
Hill Start Assist, see Drive-off assistant 194	Intended use 9
Holder for drinks, front 255	Interior equipment 249
Holder for drinks, rear 255	Interior filter 245
Home lights 162	Interior lights 166
Home lights, switching on 162	Interior lights, locked vehicle 162
Home page, see Internet 7	Interior mirror 110
Horn 36	Interior mirror, manual dim 110
Hotel function, see Valet parking mode 88	Interior mirror, outer 108
Hot exhaust system 263	Interior movement detector 91
Hour, see Time 155	Interval Display, see Service requirements 158
I .	i-Size child restraint systems 116 ISOFIX, child safety seat fasteners 116
iBrake – PostCrash 191	J
Ice, see Outside temperature 152	la dila a maiata 200
Ice warning, see Outside temperature 152	Jacking points 309
Iconic sounds, see Drive sound 236	Joystick, Steptronic transmission 126
Icons and displays 7	Jump start 338
Identification number, see Vehicle identification	Jump starting, see Jump start 338
number 20	Jump start terminals 338
Identification of recommended tyres 290 Identification of run-flat tyres 291	

Kenaf, care 345
Key Card 83
Keyless Go, see Comfort Access 80
Key, mechanical 75
Key, see Vehicle key 74
Key switch for front passenger airbag 171
Kickdown, Steptronic transmission 126

## Ĺ

Lane boundary, warning 180 Lane Change Warning 183 Lane Departure Warning 180 Language, setting 59 Lashing eyes in the luggage compartment 258 Lashing straps, see Lashing eyes in the luqgage compartment 258 Last service, see Service history 158 Lateral Parking Aid 220 Launch Control 130 Laying up the vehicle 346 Lavina up. vehicle 346 Leather care 344 LED headlights, replacing, see Lights and bulbs 328 Left-hand traffic, light setting 166 Legal emergency call 335 Length, vehicle 348 Light-alloy wheels, care 345 Light in exterior mirror, see Crossing-traffic Warning 186 Lighting 160 Light in the exterior mirror, see Lane Change Warnina 183 Lights 160 Lights and bulbs 328 Lights, care 343 Light switch 160 LIM button, see Manual Speed Limiter 201 List, instrument cluster, see Selection lists 149 Live Vehicle 141 Load 257 Loading the luggage compartment, see Stow-

ing loads 257

I oads 257 Loads, stowing and securing 257 Local time, see Time 155 Lockina, automatic 89 Locking, see Opening and closing 74 Locking, settings 88 Locking wheel bolts 308 Lock, wheel bolts 308 Low-beam headlight, operation 161 Lower back support, see Lumbar support 101 Luggage compartment 257 Luggage compartment emergency release 83 Luggage compartment, extending 258 Luggage compartment, locking, see Valet parking mode 88 Luggage rack, see Roof rack 266 Lumbar support 101

### M

Maintenance requirement, see Condition Based Service 325 Maintenance System, BMW 325 Make-up mirror 249 Malfunction displays, see Check Control 148 Malfunction, vehicle key 77 Manually unlock doors, see Integrated key 75 Manual mode, transmission 128 Manual operation, air distribution 242 Manual operation, amount of air 242 Manual operation, fuel filler flap 285 Map update, see Owner's Handbook for Navigation, Entertainment, Communication 6 Matt paintwork, care 344 Maximum cooling 241 Maximum speed, display, see Speed Limit Info 198 Maximum speed, winter tyres 290 Medical supplies, see First-aid kit 333 Memory function 111 Menus, operating, see BMW iDrive 49 Messages, see Check Control 148 Methyl ester, see Diesel 315 Metres, see Instrument cluster 140 Microfilter, see Interior filter 245 Mild hybrid technology 331

Minimum tread depth, tyres 288 Mirror position, saving, see Memory function 111 Mirror, vanity 249 Mobile communications in the vehicle 264 Mobile phone, see Owner's Handbook for Navigation, Entertainment, Communication 6 Mobility system, see Tyre repair kit 292 Moisture in the headlights, see Headlight glass 329 Monitoring tyre pressure, see Flat tyre monitor 304 Monitoring tyre pressure, see Tyre Pressure Monitor 297 Monitor, see Control display 52 Mount for rear luggage rack 272 MP3 player, see Owner's Handbook for Navigation, Entertainment, Communication 6 M Sport differential, active 197 M suspension, adaptive, see Adaptive M suspension 236 Multifunction hook 258 Multifunction steering wheel, buttons 36	Obstacle marking, Reversing Assist Camera 218 Octane number, see Petrol grade 315 Odometer, see Trip data 153 OFF display, instrument cluster, see Standby state and Drive-ready state 151 Oil filler neck 321 Oil grades for topping up, engine 321 Oil level, checking electronically 320 Oil service interval, see Service requirements 158 Oil, topping up 321 On-board computer, see Trip data 153 On-board diagnosis 326 On-board monitor, see Control display 52 One-touch signalling 135 Open circuit 331 Opening and closing 74 Opening with a smartphone, see BMW Digita Key 84 Opening with the Key Card 83 Operating condition of the vehicle 46 Operating principle, see BMW iDrive 49
Multimedia, see Owner's Handbook for Navigation, Entertainment, Communication 6	Operating principle, see BMW 1511VE 43 Operating temperature, see Engine temperature 151 Operation by voice control 57 Optimum shift indicator 150
Navigation, see Owner's Handbook for Navigation, Entertainment, Communication 6 Neck restraints, front, see Front head restraints 105	Optional equipment, see Vehicle equipment 8 Outlets, see Ventilation 244 Outside temperature 152 Overheating of the engine, see Engine tempe ature 151
Neck restraints, rear, see Rear head restraints 107 Net, luggage compartment 258	Owner's Handbook on language, BMW Intelligent Personal Assistant 59
Neutral cleaner, see Light-alloy wheels, care 345 No-overtaking indicator 198 No Passing information, see Speed Limit Dis-	Paintwork, vehicle care 344 Panorama View 222
play with no-overtaking indicator 198  Notes 6  Nylon rope for tow-starting/towing away 340	Panorama View, see Panorama View 222 Panoramic glass sunroof, see Glass sunroof 94
0	Park Assist 229 Park Distance Control 224

## 366

OBD, see On-board diagnosis 326

Parking aid, see Park Distance Control 224

Parking assistance lines, Reversing Assist	Pre-cooling 245
Camera 218	Pressure, tyres 286
Parking assistance systems 215	Pressure warning, see Flat tyre monitor, tyre
Parking Assistant 229	pressure warning, see Flat tyre monitor 304
Parking Assistant Plus, see Parking assistance	Pressure warning, see Tyre Pressure Moni-
systems 215	tor 297
Parking Assistant, see Parking assistance systems 215	Prevention of rear-end collision, see Rear Collision Prevention 185
Parking brake 132	Protective function, glass sunroof, see Anti-
Parking brake function, Active Park Distance Control 227	trap mechanism 96 Protective function, windows, see Anti-trap
Parking light 161	mechanism 93
Parking lock, unlocking electronically 128	
Parking with Automatic Hold 134	R
Particle filter, see Exhaust gas particulate fil-	
ter 263	Racing track 267
Particulate filter, see Interior filter 245	Radar sensors, see Sensors in the vehicle 41
Part replacement 328	Radiator fan, see Exhaust gas particulate fil-
Parts and accessories 10	ter 263
Payload, technical data 349	Radio, see Owner's Handbook for Navigation,
PDC, see Park Distance Control 224	Entertainment, Communication 6
Pedestrian protection, active 172	Radio signals 264
Pedestrian Warning, see Front-collision warn-	Rain sensor 137
ing 174	Range 156
Performance Control 236	Rapeseed methyl ester RME, see Diesel 315
Personal Assistant 57	READY display, instrument cluster, see
Personal data, deleting 67	Standby state and Drive-ready state 151
Personal profile, see BMW ID 68	Rear Collision Prevention 185
Personal settings 67	Rear fog light 166
Petrol 314	Rear fog light, replacing, see Lights and
Petrol grade 315	bulbs 328
Petrol particulate filter, see Exhaust gas particulate filter 263	Rear light, replacing, see Lights and bulbs 328 Rear luggage rack 267
Physical units, see Setting units of measurement 156	Rear seat backrests, folding down 258 Rear-view mirror with automatic anti-dazzle
Place for children 113	function 110
Plasters, see First-aid kit 333	Rear window heating 243
Plastic, care 345	Recirculation, see Air recirculation function 241
Plastic parts, care 345	Recommended gear for fuel-efficient driving,
Pop-ups, control display 51	see Optimum shift indicator 150
PostCrash – iBrake 191	Recommended makes of tyre 290
Power display, instrument cluster 150	Recuperation, adaptive 281
Power display, see Sport displays 157	Recycling, see Recycling 327
Powermeter, see Power display 150	Reduced drive power 150
Power window regulators 91	Reducing agent, see BMW diesel with Blue-
Pre-conditioning via Remote Engine Start 246	Porformanco 216

Rerueiling 284	Roadside Assistance, see BMW Accident As-
Remote 3D View 224	sistance 334
Remote control for audio, see Owner's	Roadside Assistance, see BMW Roadside As-
Handbook for Navigation, Entertainment,	sistance 333
Communication 6	Rolling in idle, see Coasting 282
Remote control, see Vehicle key 74	RON, see Petrol grade 315
Remote Engine Start, see Pre-condition-	Roof bars, see Roof rack 266
ing 246	Roof load, permitted 349
Remote services, app, see Owner's Handbook	Roof rack 266
for Navigation, Entertainment, Communica-	Rope for tow-starting/towing away 340
tion 6	Roundabout light 164
Remote Software Upgrade 63	Route, navigation, see Owner's Handbook for
Renewal, wheels and tyres 289	Navigation, Entertainment, Communication 6
Replacement of parts 328	RSC, see Run-flat tyres 291
Replacement, wheels and tyres 289	RTTI, see Owner's Handbook for Navigation,
Replacing bulbs, see Lights and bulbs 328	Entertainment, Communication 6
Replacing front lights, see Lights and	Rubber parts, care 345
bulbs 328	Run-flat capabilities, tyres 291
Replacing headlights, see Lights and	Run-flat tyres 291
bulbs 328	Run-flat tyres, see Run-flat tyres 291
Replacing light-emitting diodes, see Lights and	Running in 262
bulbs 328	
Replacing lights, see Lights and bulbs 328	S
Replacing parts 328	
Replacing rear lights, see Lights and bulbs 328	Safe seating position 98
RES CNCL button, Active Cruise Control 206	Safe Share function, see BMW Digital Key 84
RES CNCL button, Cruise Control 203	Safety and warning, refer to Collision warning
Reserve warning, see Range 156	systems 173
Resetting Tyre Pressure Monitor 299	Safety package, see Active Protection 190
Resetting, vehicle data 68	Safety systems, refer to Collision warning sys-
Reset, Tyre Pressure Monitor 299	tems 173
Reset, vehicle settings 68	Safety systems, see Airbags 169
Restraint systems for children, see Carrying	Saving energy, see Optimum shift indicator 150
children safely 113	Sealing compound, see Tyre repair kit 292
Restricted Driving, see BMW Digital Key 84	Seat belt reminder 105
Rest state, see Operating condition of the vehi-	Seat belts 103
cle 46	Seat belts, care 346
RESUME button, Active Cruise Control 206	Seat belt warning 105
RESUME button, Cruise Control 203	seat calibration 102
Retreaded tyres 290	Seat heating 243
Reversing Assistant 233	Seat position, saving, see Memory function 111
Reversing Assist Camera 219	Seats and head restraints 98
Revolution counter 151	Seats, front 98
Right-hand traffic, light setting 166	Securing, loads 257
RME rapeseed methyl ester, see Diesel 315	Selection list in the instrument cluster 149
	Selector lever, Steptronic transmission 126

Sensors, care 346	Snaking movement of the trailer, see Trailer
Sensors in the vehicle 41	Stability Control 271
Service 325	Snow chains 296
Service history 158	Socket for on-board diagnosis 326
Service performed, see Service history 158	Sockets, electrical devices 249
Service requirements 158	Software update, see Remote Software Up-
Service requirement, see Condition Based	grade 63
Service 325	Software upgrade, see Remote Software Up-
Services, ConnectedDrive, see Owner's	grade 63
Handbook for Navigation, Entertainment,	Software version, see Remote Software Up-
Communication 6	grade 63
Service, see BMW Accident Assistance 334	Soot particulate filter, see Exhaust gas particu-
Service, see BMW Roadside Assistance 333	late filter 263
Service, see Service requirements 158	SOS button, see Intelligent emergency call 336
SET button, Active Cruise Control 206	SOS button, see Legal emergency call 335
SET button, Cruise Control 203	Sound of drivetrain 236
Set clock 155	Sound output, see Owner's Handbook for Nav-
Set day, see Date 155	igation, Entertainment, Communication 6
Set time, see Time 155	Sound, see Owner's Handbook for Navigation,
Setting, control display 53	Entertainment, Communication 6
Settings, locking/unlocking 88	Spanner, see Toolkit 328
Settings, resetting, vehicle 68	Speech recognition 57
Settings, seats and head restraints 98	Speed Limit Assist 212
Settings, steering wheel 110	Speed Limit Device, Manual Speed Limiter 201
Shift Lights, revolution counter 152	Speed limit, display, see Speed Limit Info 198
Shift paddles on the steering wheel 128	Speed limiter, manual 201
Shock absorber adjustment, active, see Adap-	Speed Limit Info 198
tive M suspension 236	Speed Limit Info with anticipation 200
Shortcuts, iDrive 52	Speed limit warning 198
Side airbag 169	Sport displays 157
Side lights 161	Sport programme, transmission 126
Side nozzles, see Ventilation 244	SPORT, see Driving Experience Control 131
Side protection, see Lateral Parking Aid 220	Sport steering, variable 197
Signal horn, horn 36	Sport suspension, see Adaptive M suspen-
Signals on unlocking, see Acknowledgement	sion 236
signals 89	SPRINT display 130
Sizes, see Dimensions 348	Sprint function 130
Slipperiness, see Outside temperature 152	Stability control systems 194
Slippery road, see Outside temperature 152	Standard equipment, see Vehicle equipment 8
Smallest turning radius, vehicle 348	Standby state, see Operating condition of the
Smartphone, operating via voice input 60	vehicle 46
Smartphone, see Owner's Handbook for Navi-	Start/Stop button 123
gation, Entertainment, Communication 6	Starting, see Drive-ready state 47
SMS, see Short messages, see Owner's	Starting the engine, see Drive-ready state 47
Handbook for Navigation, Entertainment,	Starting the engine with the Key Card 83
Communication 6	

Stations, AM/FM, see Owner's Handbook for Navigation, Entertainment, Communication 6 Status indicator, tyres 299 Status information, iDrive 50 Status of the Owner's Handbook 8 Status, vehicle 156 Steering column adjustment 110 Steering wheel, adjusting 110 Steering wheel heating 110 Steering wheel heating 110 Steering wheel position, saving, see Memory function 111 Steptronic sport transmission, see Steptronic transmission 126 Steptronic transmission 126 Stopping the engine, see Drive-ready state 47 Storage compartment, centre console 254 Storage, see Laying up the vehicle 346	Teleservices, see Owner's Handbook for Navigation, Entertainment, Communication 6 Television, TV, see Owner's Handbook for Navigation, Entertainment, Communication 6 Temperature, automatic air conditioning 240 Temperature display, see Outside temperature 152 Tensioning strap, see Lashing eyes in the luggage compartment 258 Terminal, jump start 338 Thigh support 101 Through-loading system 258 Tilt alarm sensor 91 Tilting down, front passenger's mirror, see Automatic parking function 109 Time 155 Time of day, see Time 155 Time setting, automatic 155 Time zone 155
Storage, tyres 291	Toolkit 328
Stowing, loads 257	Tools 328
Summer tyres, tread 288	Torque display, see Sport displays 157
Sun visor 249	Total weight, permitted 349
Supplementary Owner's Handbook 7	Total weight, trailer operation 351
Suspension, electronic, see Adaptive M sus-	Touchpad, Controller 55
pension 236	Tourist function, see Right-hand/left-hand traf
Suspension settings, see Driving Experience	fic 166
Control 131	Towbar 340
Switches, see Vehicle cockpit 36	Tow fitting, see Towing eye 341
Switch for driving dynamics, see Driving Expe-	Towing away 339
rience Control 131	Towing eye 341
SYNC programme, automatic air condition-	Towing rope 340 Towing, see Tow-starting and towing
ing 242 System, alarm, see Alarm system 90	away 339
System language, setting, see Language 59	Tow-starting 339
system language, setting, see Eariguage 33	Traction control system, see Dynamic Stability
Т	Control 194
•	TRACTION, driving dynamics 196
Tank display 155	Traffic information, see Owner's Handbook for
Technical changes, see Your own safety 9	Navigation, Entertainment, Communication 6
Technical data 348	Trailer loads 351
Telephone, see Owner's Handbook for Navi-	Trailer nose weight, technical data 351
gation, Entertainment, Communication 6	Trailer operation 269
Telephone, selection list in the instrument	Trailer operation, activation 272
cluster 149	Trailer operation, technical data 351
	Trailer Stability Control 271

I railer tow hitch 2/2	Unlocking, settings 88
Trailer tow hitch, care 346	Updates after going to press 8
Trailer tow hitch, zoom 221	Upgrade, see Remote Software Upgrade 63
Transmission, see Steptronic transmission 126	Upper retaining strap, top tether 117
Tread, tyres 288	USB port, position in the vehicle 250
Trip data 153	Use, intended 9
Trip odometer, see Trip data 153	,
Turn indicator, high-beam headlight, headlight	V
flasher 135	•
Turn indicator, indicator light 146	Valet parking mode 88
Turn indicator, replacing bulbs, see Lights and	Vanity mirror 249
bulbs 328	Variable light distribution 163
Turn indicator, see Turn indicator 135	Variable light distribution 103  Variable sport steering 197
Turning circle lines, Reversing Assist Cam-	Vehicle acknowledgement signals 89
era 218	Vehicle battery 329
Turning radius, vehicle 348	Vehicle backery 323  Vehicle breakdown, see Help in case of a
Turning up, dimming, see High-beam Assis-	
tant 164	breakdown 333 Vehicle care 343
TV, see Owner's Handbook for Navigation, En-	Vehicle cockpit 36
tertainment, Communication 6	
Tyre age 289	Vehicle data and data protection 10
Tyre change 289	Vehicle data, resetting 68
Tyre damages 288	Vehicle equipment 8  Vehicle identification number 20
Tyre inflation pressure 286	Vehicle key 74
Tyre makes, recommendation 290	,
Tyre pressure 286	Vehicle key, additional 74  Vehicle key, changing the battery 75
Tyre Pressure Monitor 297	Vehicle key, integrated key 75
Tyre Pressure Monitor, reset 299	Vehicle key, loss 74
Tyre pressure warning, see Tyre Pressure	Vehicle key, malfunction 77
Monitor 297	Vehicle paintwork, care 344
Tyre repair kit 292	Vehicle, running in 262
Tyres and wheels 286	Vehicle status 156
Tyre sealant, see Tyre repair kit 292	Vehicle wash 342
Tyre settings 298	Ventilation 244
Tyres with run-flat capabilities 291	Ventilation, see Pre-cooling 245
Tyre tread 288	Video recording, see BMW Drive Recorder 188
.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	Video, see Owner's Handbook for Navigation,
U	Entertainment, Communication 6
	VIN, see Vehicle identification number 20
Ultrasonic sensors, see Sensors in the vehi-	Voice control 57
cle 41	Voice control system 57
Units of measurement, setting 156	Voice input 57
Units, see Setting units of measurement 156	Voice input 37  Voice input, see BMW Intelligent Personal As-
ornics, see setting utilis of measurement 150	voice input, see Diviw intelligent Personal As-

sistant 57

Unloaded weight 349

Unlocking, automatic 89

Unlocking, see Opening and closing 74

#### W

Warning function, rear-end collision 185 Warning light in exterior mirror, see Crossingtraffic Warning 186 Warning light in the exterior mirror, see Lane Change Warning 183 Warning lights 143 Warning messages, see Check Control 148 Warning of crossing traffic 186 Warnings, false 91 Warning systems for collision risk 173 Warning triangle 333 Warranty 9 Warranty Booklet, see Warranty 9 Washer fluid 323 Washer fluid, reservoir 323 Washing fluid, see Washer fluid 323 Wash, vehicle 342 Water on street 264 Water, see Condensation when vehicle is parked 266 Web page, see Internet 7 Website 7 Weights 349 Welcome display, driver profiles 68 Welcome light 162 Wheelbase, vehicle 348 Wheel change 306 Wheels and tyres 286 Wheels and tyres, exchange 289 Widgets, iDrive 50 Widgets, instrument cluster, see Central indication range 152 Width, vehicle 348 Window glass, defrosting 243 Window lifters 91 Windscreen, defrosting 243 Windscreen washing system, see Wiper system 136 Windscreen wiper, fold-out position 138 Windscreen wipers, see Wiper system 136 Winter storage, see Laying up the vehicle 346 Winter tyres 290

Wiper system 136 Wiping fluid, see Washer fluid 323 Wireless charging, smartphone, see Wireless charging tray 251 Wireless charging tray for smartphones 251 Wood, care 345 Wood parts, care 345 Wordmatch principle, see Input comparison 51 Workshop, see Service requirements 158



xDrive 197



Your own safety 9

Winter tyres, tread 288 Wiper blades, changing 328



01405A5E758 en

# BMW DRIVER'S GUIDE APP.

YOUR DIGITAL VEHICLE INFORMATION.

The BMW Driver's Guide app tells you all about your vehicle's equipment and offers additional content and functions:



Everything you need to know about navigation, entertainment and communication

Photo-realistic animated content demonstrating various vehicle functions

Keyword search

360° View: An interactive virtual tour of the interior and exterior of your vehicle

Smart Scan for Apple iPhone: Icon and optical character recognition on the buttons inside the vehicle

Available in more than 30 languages

Can be downloaded and used offline



